

[Manuals.plus](#) /

› [EDJO](#) /

› EDJO Foldable Bluetooth Keyboard Instruction Manual

EDJO Foldable Bluetooth Keyboard

EDJO Foldable Bluetooth Keyboard Instruction Manual

Model: Foldable Bluetooth Keyboard

1. PRODUCT OVERVIEW

The EDJO Foldable Bluetooth Keyboard is a portable wireless input device designed for use with various operating systems and devices. It features a sensitive touchpad, which can also function as a number pad, and connects via Bluetooth 5.1. Its foldable design makes it convenient for travel and mobile use.

MULTI-DEVICE BLUETOOTH KEYBOARD

Supports 3 Bluetooth Channels




Image: The EDJO Foldable Bluetooth Keyboard in its unfolded state, displaying the full QWERTY layout, integrated touchpad, and dedicated number pad.

Package Contents:

- 1 x EDJO Foldable Bluetooth Keyboard
- 1 x Type-C Charging Cable
- 1 x User Manual

2. SETUP

2.1 Initial Charging

Before first use, it is recommended to fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port and a compatible USB power source. The power indicator light will show charging status.

RECHARGEABLE & AUTO-SLEEP KEYBOARD



Image: The keyboard being charged via its Type-C port, highlighting its battery life and auto-sleep feature.

2.2 Bluetooth Pairing

The keyboard supports simultaneous connection with up to three devices. Follow these steps to pair your device:

1. Ensure Bluetooth is disabled on your device before starting the pairing process.
2. Turn on the keyboard using the power switch. The power indicator will light up.
3. Enter pairing mode: Press **Fn + C** simultaneously. The Bluetooth indicator light will flash, indicating it is ready for pairing.
4. Select your device's operating system:
 - For Windows: Press **Fn + A**
 - For iOS/Mac: Press **Fn + S**
 - For Android: Press **Fn + D**
5. Activate Bluetooth on your device (smartphone, tablet, laptop).

6. Search for available Bluetooth devices and select "Bluetooth 5.1 Keyboard" from the list.
7. If prompted, enter the pairing code displayed on your screen using the keyboard and press **Enter**.




Image: Visual guide for Bluetooth connection steps, including system selection and device pairing.

2.3 Switching Between Devices

To switch between paired devices (BT1, BT2, BT3), press **Fn + Q** for BT1, **Fn + W** for BT2, or **Fn + E** for BT3.



Image: The keyboard connected to multiple devices, demonstrating the ease of switching between them.

3. OPERATING INSTRUCTIONS

3.1 Touchpad Functionality

The integrated touchpad allows for mouse-like navigation and supports multiple gesture commands. It functions as a mouse replacement for precise control.

3.2 Number Pad Functionality

The touchpad can be converted into a number pad. To activate the number pad, press **Fn + Space**. Press **Fn + Space** again to switch back to touchpad mode.

TOUCHPAD & NUMBER PAD



Image: Detailed view of the touchpad and its conversion to a number pad.

3.3 Auto-Sleep Function

To conserve battery, the keyboard will automatically enter sleep mode after 10 minutes of inactivity. To wake it up, press any key.

3.4 Quiet Scissor-Switch Keys

The keyboard features quiet scissor-switch keys, providing a comfortable and silent typing experience.

QUIET & SOFTER TOUCH SCISSOR SWITCH



Image: A close-up illustrating the scissor-switch key mechanism, emphasizing quiet operation.

4. MAINTENANCE

4.1 Charging

Recharge the keyboard when the battery indicator is low. Use the provided Type-C cable for optimal charging. A full charge typically takes approximately 2 hours.

4.2 Cleaning

To clean the keyboard, gently wipe the surface with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure the keyboard is powered off before cleaning.

5. TROUBLESHOOTING

5.1 Keyboard Not Pairing

- Ensure the keyboard is fully charged.
- Verify Bluetooth is enabled on your device and disabled on other nearby devices that might interfere.
- Make sure the keyboard is in pairing mode (Bluetooth indicator flashing after pressing **Fn + C**).
- Select the correct operating system mode (**Fn + A** for Windows, **Fn + S** for iOS/Mac, **Fn + D** for Android).
- Restart both the keyboard and your device, then attempt pairing again.

5.2 Touchpad Not Responding (iOS)

Note: The touchpad functionality may not be fully supported on iOS versions below 13.4.1. Ensure your iOS device is updated to a compatible version for full touchpad functionality.



Image: The keyboard in use with mobile devices, highlighting the iOS compatibility note for the touchpad.

5.3 Keys Not Responding or Sticky

- Ensure the keyboard is fully charged and connected.
- Clean around the affected keys to remove any debris.
- If certain keys (e.g., 'T', 'V') feel less responsive due to the folding design, adjust your typing style to ensure full key press.

6. SPECIFICATIONS

Feature	Detail
Brand	EDJO
Model	Foldable Bluetooth Keyboard
Connectivity Technology	Bluetooth 5.1
Compatible Devices	Laptop, PC, Smartphone, Tablet
Compatible Operating Systems	Windows, Android, iOS, MacOS
Special Features	Foldable, Rechargeable, Touchpad, Number Pad
Battery Capacity	140mAh Lithium Battery
Charging Interface	Type-C
Charging Time	Approx. 2 hours
Working Time	Up to 48 hours (uninterrupted)
Auto-Sleep	After 10 minutes of inactivity
Product Dimensions (Folded)	6"L x 3.9"W x 0.8"H
Keyboard Layout	QWERTY
Number of Keys	59
Material	Plastic

7. WARRANTY AND SUPPORT

The EDJO Foldable Bluetooth Keyboard comes with a 12-month warranty service. If you encounter any issues with the product, please contact EDJO customer support through the Amazon email system. Our support team aims to provide a quick response within 24 hours and a satisfactory solution.

For further assistance, please refer to the contact information provided in your purchase documentation or on the official EDJO store page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question