

Mikikin Mikikin

Mikikin Dehumidifier User Manual

Model: Mikikin

1. INTRODUCTION

Thank you for choosing the Mikikin Dehumidifier. This compact and efficient appliance is designed to reduce excess moisture in small spaces, helping to create a more comfortable and healthy environment. It features quiet operation, automatic shut-off, and colorful LED lighting. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image: The Mikikin Dehumidifier effectively reduces humidity, as shown by the comparison of water droplets before and after use in a bathroom setting.

2. PRODUCT FEATURES

- **High Efficiency Dehumidification:** Capable of extracting up to 16 ounces (450ml) of water per day at 86°F and 80% RH. Effective for areas up to 285 sq.ft.
- **Automatic Shut-off & Memory Function:** Automatically turns off when the 35oz (1000ml) water tank is full to prevent overflow, indicated by a red flashing light. Resumes previous settings after the tank is emptied and reinserted.
- **Super Quiet Operation:** Designed with normal and sleep modes. Sleep mode ensures quiet operation, ideal for bedrooms and nurseries.
- **7 Colorful LED Lights:** Features 7 automatically changing RGB LED lights. Users can select and lock a preferred color or turn off the lights.
- **Portable Design:** Compact size (6"D x 6"W x 9.8"H) and lightweight (1.3kg) with a built-in handle for easy portability.



Image: The dehumidifier contributes to a healthier living space by addressing common humidity-related issues such as condensation, mold, and odors.

3. PACKAGE CONTENTS

- Mikikin Dehumidifier Unit
- Power Adapter
- User Manual

4. SETUP

1. **Unpack:** Carefully remove the dehumidifier and all accessories from the packaging.
2. **Placement:** Place the dehumidifier on a flat, stable surface. Ensure the top air inlet and rear air outlet are not blocked to allow for proper airflow. Keep the unit away from walls or obstructions.
3. **Power Connection:** Connect the power adapter to the dehumidifier's power port, then plug the adapter into a suitable electrical outlet.



Image: The compact design of the Mikikin Dehumidifier allows for versatile placement in different rooms, such as a living room.



Image: Proper placement of the dehumidifier in a bathroom, ensuring its back is clear of obstructions for efficient operation.

5. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the **ON/OFF** button on the top panel to turn the unit on or off.
2. **Light Control:** Press the **LIGHT** button to cycle through the 7 colorful LED lights. Press again to lock a specific color. Long press the button to turn off the lights.
3. **Sleep Mode:** Press the **SLEEP** button to activate sleep mode. In this mode, the dehumidifier operates at a lower fan speed for quieter performance, and the lights are typically dimmed or turned off.
4. **Water Tank Full Indicator:** When the water tank is full (700-800ml), the dehumidifier will automatically shut off, and the light will flash red to alert you.
5. **Emptying the Water Tank:** Carefully pull out the water tank from the bottom of the unit. Discard the collected water. Reinsert the empty tank firmly until it clicks into place. The unit will resume operation with its previous settings.

7 COLORFUL LED LIGHTS



Image: The dehumidifier offers customizable ambient lighting with 7 LED colors, allowing users to choose automatic cycling, a fixed color, or no light.



Image: The auto shut-off feature activates when the water tank reaches 80% capacity, indicated by a red warning light, preventing overflow.

6. MAINTENANCE

- **Cleaning the Water Tank:** Regularly empty and clean the water tank to prevent mold and mildew growth. Use mild soap and water, then rinse thoroughly.
- **Cleaning the Unit:** Wipe the exterior of the dehumidifier with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Filter Cleaning:** The dehumidifier includes a removable filter. Periodically clean the filter by gently brushing off dust or rinsing with water. Ensure it is completely dry before reinserting.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Dehumidifier does not turn on.	No power, power adapter not connected, or water tank not properly inserted.	Check power connection. Ensure the power adapter is securely plugged in. Verify the water tank is fully inserted.

Problem	Possible Cause	Solution
Unit is running but not collecting water.	Room temperature is too low (below 17°F), humidity is too low, or air inlets/outlets are blocked.	Ensure room temperature is above 17°F. Check and clear any obstructions from air inlets/outlets. The unit may not collect water if humidity is already low.
Red light is flashing.	Water tank is full.	Empty the water tank and reinsert it properly.
Excessive noise.	Unit is on an uneven surface or air filter is dirty.	Place the unit on a flat, stable surface. Clean the air filter.

8. SPECIFICATIONS

Feature	Specification
Brand	Mikikin
Model Name	Mikikin
Floor Area Coverage	Up to 285 Square Feet
Dehumidification Capacity	0.45 Liters per Day (approx. 16 oz)
Tank Volume	800 Milliliters (approx. 35 oz)
Product Dimensions (D x W x H)	6"D x 6"W x 9.8"H
Material	Acrylonitrile Butadiene Styrene (ABS)
Wattage	35 watts
Operation Mode	Normal, Sleep
Special Features	Automatic Shutoff, Quiet Operation, 7 Colorful LED Lights
Recommended Uses	Home (Bathroom, Bedroom, Basement, RV, Closet)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Mikikin customer service directly. Keep your purchase receipt for warranty claims.