Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Famiworths 2200

Famiworths Coffee Pod Holder for Coffee Maker Model 2200 Instruction Manual

Model: 2200

Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your Famiworths Coffee Pod Holder, designed specifically for the Famiworths Coffee Maker Model 2200. Please read this guide thoroughly before use to ensure optimal performance and longevity of your product.

Product Overview

The Famiworths Coffee Pod Holder is an accessory designed to facilitate the use of single-serve coffee pods with your Famiworths Coffee Maker Model 2200. It ensures correct placement and piercing of the coffee pod for brewing.



Image 1: The Famiworths Coffee Pod Holder shown alongside two single-serve coffee pods. This image illustrates the holder's design and its compatibility with standard coffee pods.

Setup Instructions

1. **Unpack:** Carefully remove the coffee pod holder from its packaging. Inspect for any damage.
2. **Locate Coffee Maker Slot:** Identify the designated slot within your Famiworths Coffee Maker Model 2200 where the pod holder is inserted. This is typically located under the brewing head.
3. **Insert Pod Holder:** Align the Famiworths Coffee Pod Holder with the slot in the coffee maker. Gently push it down until it clicks securely into place. Ensure it is seated firmly to prevent leaks during brewing.



Image 2: The Famiworths Coffee Maker Model 2200 with the coffee pod holder correctly inserted. This image also shows a brewed cup of coffee, demonstrating the holder in its operational context.

Operating Instructions

1. **Prepare Coffee Maker:** Ensure your Famiworths Coffee Maker Model 2200 is filled with water and powered on according to its own instruction manual.
2. **Open Brewing Chamber:** Lift the handle or open the brewing chamber lid of your coffee maker.
3. **Insert Coffee Pod:** Place a single-serve coffee pod into the Famiworths Coffee Pod Holder. Ensure the pod is oriented correctly, usually with the foil lid facing upwards.
4. **Close Brewing Chamber:** Close the brewing chamber lid firmly. You may hear a slight piercing sound as the coffee pod is punctured.
5. **Brew Coffee:** Select your desired brew size and press the brew button on your coffee maker.
6. **Remove Used Pod:** After brewing is complete, carefully open the brewing chamber and remove the hot, used coffee pod from the holder. Dispose of the used pod responsibly.

Maintenance and Cleaning

Regular cleaning of your Famiworths Coffee Pod Holder is essential for hygiene and optimal performance.

- **Daily Cleaning:** After each use, remove the pod holder from the coffee maker. Rinse it under warm running water to remove any coffee grounds or residue.
- **Weekly Cleaning:** For a more thorough clean, wash the pod holder with warm, soapy water. Use a soft brush if necessary to clean any hard-to-reach areas, especially around the piercing needle. Rinse thoroughly to remove all soap residue.
- **Drying:** Allow the pod holder to air dry completely before reinserting it into the coffee maker or storing it.
- **Caution:** Be careful when cleaning around the piercing needle, as it is sharp. Do not use abrasive cleaners or scouring pads, as these can damage the plastic.

Troubleshooting

- **Coffee Not Brewing / Water Everywhere:**
  - Ensure the pod holder is correctly and firmly seated in the coffee maker. A loose holder can cause water to bypass the pod.
  - Verify that a coffee pod is properly inserted into the holder and that the lid is closed completely.
  - Check if the piercing needle is clear of any obstructions.
- **Pod Holder Does Not Fit:**
  - This pod holder is specifically designed for the Famiworths Coffee Maker Model 2200. Confirm that your coffee maker is indeed this model. Compatibility with other models is not guaranteed.
- **Accidental Disposal:**
  - The pod holder is a reusable component of your coffee maker. Avoid discarding it with used coffee pods.

Specifications

Feature	Detail
Brand	Famiworths
Model	2200
Special Features	Coffee Pod Compatible

Feature	Detail
Mounting Hardware	Filter (refers to the pod holder's function)
Number of Items	1
Product Dimensions	9.65 x 6.6 x 6.1 cm
Item Weight	18 g
ASIN	B0BZDDXLR9
Date First Available	23 March 2023

Note: Specifications are subject to change without notice.

Warranty and Support

For information regarding warranty coverage, technical support, or replacement parts, please refer to the documentation included with your original Famiworths Coffee Maker Model 2200 or visit the official Famiworths website. Keep your purchase receipt for warranty claims.

© 2024 Famiworths. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I buy a replacement coffee pod holder for my Famiworths Coffee Maker Model 2200?

To purchase a replacement coffee pod holder for your Famiworths Coffee Maker Model 2200, you have a few options based on the product documentation and user feedback: Amazon: The specific part is listed under...

Read full answer

Open the live page

https://manuals.plus/asin/B0BZDDXLR9

More documents and user manuals: **https://manuals.plus/**