Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 838-368V00BN

HOMCOM 67-inch Pinewood Kitchen Pantry Storage Cabinet

Model: 838-368V00BN

Introduction | Safety Information | Package Contents | Assembly | Operation | Maintenance | Troubleshooting | Specifications

1. Introduction

Thank you for choosing the HOMCOM 67-inch Pinewood Kitchen Pantry Storage Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read it thoroughly before beginning assembly and retain it for future reference.

This freestanding cabinet is crafted from durable pinewood with varnished surfaces, offering a natural aesthetic and robust construction. It features four tiers of shelving, two doors with a soft-close mechanism, and adjustable shelves to accommodate various storage needs. An anti-tipping strap is included for enhanced safety.



Figure 1: The HOMCOM 67-inch Pinewood Kitchen Pantry Storage Cabinet, showcasing its natural wood finish and two doors, positioned in a kitchen environment next to a counter.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always secure the anti-tipping strap to the wall to prevent the cabinet from tipping over. This is crucial for household safety, especially in homes with children or pets.
- Do not overload the cabinet, as this could cause it to become unstable and tip over. Distribute weight evenly across shelves.
- Always follow the assembly instructions carefully to ensure the cabinet is assembled correctly and safely. Incorrect assembly can compromise stability.
- Keep all small parts and packaging materials away from children to prevent choking hazards.
- Ensure the cabinet is placed on a flat, level surface to prevent wobbling and ensure stability.
- Do not climb on or lean heavily on the cabinet doors or shelves.



Figure 2: An image showing the anti-tipping strap attached to the top rear of the cabinet, designed to secure it to the wall and prevent accidental tipping.

3. Package Contents

Before beginning assembly, please verify that all parts listed in the included assembly guide are present and undamaged. The package typically includes:

- Cabinet panels (sides, top, bottom, back, doors)
- Adjustable shelves (4 included)
- Hardware kit (screws, dowels, cam locks, hinges, door knobs, shelf pins, anti-tipping strap)
- Assembly Instructions Manual

If any parts are missing or damaged, please contact customer support before proceeding with assembly.

4. Assembly Instructions

Detailed step-by-step assembly instructions are provided in the separate assembly manual included with your product. Please follow these instructions carefully. General steps include:

1. **Unpack and Identify Parts:** Lay out all components and hardware.
2. **Assemble the Frame:** Attach side panels to the base and top panels using the provided hardware.
3. **Install Back Panel:** Secure the back panel to the assembled frame.
4. **Attach Hinges and Doors:** Mount hinges to the doors and then attach the doors to the cabinet frame.
5. **Install Door Knobs:** Secure the door knobs to the cabinet doors.
6. **Insert Shelves:** Place shelf pins at desired heights and insert the adjustable shelves.
7. **Secure Anti-Tipping Strap:** Attach the anti-tipping strap to the top rear of the cabinet and secure it to a wall stud.

Ensure all connections are tight and secure before using the cabinet.



Figure 3: A detailed view of the cabinet with its dimensions labeled: 67.25 inches height, 30.75 inches width, and 12.25

inches depth. The interior shelf depth is 10.25 inches.

5. Operating Instructions

5.1 Adjusting Shelves

The cabinet features adjustable shelves, allowing you to customize the storage space. To adjust a shelf:

1. Remove all items from the shelf.
2. Carefully lift the shelf and remove the four shelf pins supporting it.
3. Reinsert the shelf pins into the desired holes at the new height. Ensure all four pins are securely in place and level.
4. Place the shelf back onto the pins.



Figure 4: This diagram demonstrates the adjustability of the shelves within the cabinet, allowing users to customize shelf height to accommodate items of different sizes.

5.2 Using Soft-Close Doors

The cabinet doors are equipped with soft-close hinges. This mechanism allows the doors to close gently and quietly, preventing slamming and reducing wear and tear. Simply push the door gently to close, and the soft-close feature will engage automatically.



Figure 5: A close-up shot of the soft-closing hinge mechanism, illustrating how the doors close smoothly and quietly to prevent slamming.

5.3 Storage Capacity

The cabinet offers ample storage with its four tiers. Utilize the space for dishes, pots, dry goods, or other kitchen essentials. Remember to adhere to the weight capacity limits for overall cabinet and individual shelves.



Figure 6: The cabinet doors are open, revealing the spacious interior with four tiers of shelving, suitable for storing various kitchen items like dishes, bottles, and pots.

5.4 Natural Wood Construction

The cabinet is constructed from natural pinewood with a varnished finish, providing both durability and an attractive appearance. The raised door fronts add to its aesthetic appeal.



Figure 7: This image highlights the natural pinewood construction and the design of the raised door fronts, emphasizing the quality of the wood and the varnished surface.

5.5 Product Overview Video

Your browser does not support the video tag.

Video 1: This official video provides a visual overview of the HOMCOM 67-inch Pinewood Kitchen Pantry Storage Cabinet, demonstrating its features and appearance in various settings.

6. Maintenance and Care

6.1 Cleaning

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the varnished pinewood finish.

- Promptly wipe up spills to prevent water damage or staining.

6.2 General Care

- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- Avoid exposing the cabinet to direct sunlight or extreme temperature changes, which can cause wood to warp or fade.
- Keep the cabinet away from excessive moisture.

7. Troubleshooting

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose connections; anti-tipping strap not secured.	Ensure the cabinet is on a level surface. Check and tighten all assembly screws. Secure the anti-tipping strap to the wall.
Doors do not close properly or are misaligned.	Loose hinge screws; cabinet not level; incorrect hinge adjustment.	Check and tighten hinge screws. Ensure the cabinet is level. Adjust hinges as per the assembly manual for proper alignment.
Shelves are not level or fall out.	Shelf pins not fully inserted; incorrect shelf pin placement.	Ensure all four shelf pins are fully inserted into the corresponding holes and are at the same height.
Strong odor from the finish.	New product finish.	Allow the cabinet to air out in a well-ventilated area for several days. The odor should dissipate over time.

8. Specifications

Brand: HOMCOM

Model Name: Storage Cabinet

Model Number: 838-368V00BN

Product Dimensions (Overall): 30.75" W x 12.25" D x 67.25" H

Material: Pine Wood

Finish Type: Varnished

Number of Shelves: 4 (Adjustable)

Overall Weight Capacity: 132 lbs

Each Shelf Weight Capacity: 33 lbs

Item Weight: 63.8 lbs

Installation Type: Freestanding

Assembly Required: Yes

9. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact HOMCOM customer service. If you encounter any issues or have questions regarding your product, please reach out to our support team for assistance.

Manufacturer: Aosom LLC

Contact Information: Please visit the official HOMCOM website or your retailer's support page for the most current

contact details.

© 2023 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZGZNDNN

More documents and user manuals: **https://manuals.plus/**