Snailax 591R

Snailax Vibrating Foot Massager with Heat

MODEL: 591R

1. Important Safety Information

Please read all instructions carefully before using this product. Failure to follow safety warnings and instructions may result in electric shock, fire, or serious injury.

- For adult use only. Keep out of reach of children.
- Consult a healthcare professional before use if you have diabetes, nerve problems, or any other medical condition.
- Do not use the massager in wet environments or near water.
- Unplug the device when not in use and before cleaning.
- Do not operate if the cord or plug is damaged.
- Do not use for more than 15 minutes per cycle, and no more than 3 cycles per day.

2. Package Contents

Verify that all items are included in your package:

- 1x Snailax Vibrating Foot Massager
- 1x Power Adapter
- 1x Remote Control
- 1x User Manual
- 1x Washable Dust Cover



Image Description: A photograph showing the Snailax Vibrating Foot Massager, its retail box, power adapter, and user manual laid out on a white surface. The massager is orange and black with two footpads.

3. Product Overview

The Snailax Vibrating Foot Massager is designed to provide soothing vibration and heat therapy to your feet, calves, and legs. It features multiple massage modes and intensity levels, controlled by either the integrated buttons or a wireless remote.



Image Description: A top-down view of the Snailax Vibrating Foot Massager, which is orange with two black textured footpads. A small remote control is positioned to the right, indicating wireless operation.

Components:

- **Footpads:** Textured surfaces for foot placement.
- **Control Panel:** Integrated buttons for power, mode, intensity, and heat.
- **Remote Control:** Wireless control for all functions.
- **Power Port:** Located on the side or back for connecting the adapter.

4. Setup

1. Place the massager on a flat, stable surface.
2. Ensure the power port is easily accessible.
3. Connect the power adapter to the massager's power port.
4. Plug the power adapter into a suitable electrical outlet.
5. The device is now ready for use.

5. Operating Instructions

The massager can be operated using the integrated control panel or the wireless remote control.



Image Description: A detailed view of the Snailax foot massager's control panel, showing four buttons: Power, Mode, Intensity, and Heat. The wireless remote control, with identical buttons, is held by a hand next to the massager.

Basic Operation:

- **Power On/Off:** Press the **Power Button** ( ) to turn the device on or off.
- **Massage Modes:** Press the **Mode Button** (▣) to cycle through 3 distinct massage modes.
- **Intensity Levels:** Press the **Intensity Button** (▮▮▮) to adjust between 3 customizable vibration intensity levels.
- **Heat Function:** Press the **Heat Button** (∫∫∫) to activate or adjust the 2 optional heat settings.

The standard operating cycle is 15 minutes. It is recommended to use the massager for a maximum of 3 cycles per day.

Usage for Different Body Parts:

The Snailax Vibrating Foot Massager is versatile and can be used for various areas:

- **Feet:** Place both feet on the footpads for vibration and heat therapy.
- **Calves/Legs:** Position the massager to target calf muscles or other leg areas.
- **Waist/Back:** The lightweight design allows for use on the waist or lower back while seated.




Image Description: A collage demonstrating the multi-purpose use of the Snailax massager. It shows individuals using it for their feet, calves, and even placing it behind their back while seated. One image also shows a person standing on the device, indicating its robust design and maximum weight capacity of 198 lbs (90 kg).



Image Description: A woman seated on a sofa, with her feet placed on the Snailax Vibrating Foot Massager. Blue wavy lines emanate from the footpads, visually representing the vibration massage.



Image Description: A close-up of a person's feet resting on the Snailax foot massager. Orange wavy lines and arrows illustrate the heat radiating from the device, with a thermometer icon indicating two heating levels.

6. Maintenance

Cleaning:

The massager includes a detachable and washable dust cover for easy cleaning and maintenance.

- Unplug the massager from the power outlet before cleaning.
- Remove the detachable dust cover.
- The dust cover is machine washable. Follow the care instructions on the label.
- Wipe the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- Ensure the massager is completely dry before reattaching the cover and using it again.



Image Description: A split image showing the benefits of the detachable dust cover. On the left, a hand places the cover into a washing machine. On the right, an illustration depicts the cover preventing dust from accumulating on the massager's surface.

Storage:

Store the massager in a cool, dry place when not in use, away from direct sunlight and moisture.

7. Troubleshooting

If you encounter any issues with your Snailax Vibrating Foot Massager, please refer to the following common solutions:

- **Device not turning on:** Ensure the power adapter is securely plugged into both the massager and a working electrical outlet.
- **No vibration/heat:** Check that the desired function is activated using the control panel or remote. Ensure the device is powered on.
- **Remote control not working:** Verify that the remote control's battery is functional. Ensure there are no obstructions between the remote and the massager.

If problems persist after attempting these solutions, please contact Snailax customer support for assistance.

8. Specifications

Brand	Snailax
Model Number	591R
Product Dimensions	32.5 x 11 x 41.8 cm (12.8 x 4.3 x 16.5 inches)
Product Weight	3.09 kg (6.81 lbs)
Color	Orange
Material	Plastic
Power Source	Corded Electric
Special Features	Heat, Remote Control, Adjustable Vibration Speed
Massager Type	Electric Foot Massager Machine
Specific Uses	Plantar Fasciitis, Myofascial, Neuropathy, Circulation
Country of Origin	China

9. Warranty and Support

The Snailax Vibrating Foot Massager Model 591R comes with a**1-year limited warranty** from the date of purchase. This warranty can be extended to **3 years** upon product registration. Please refer to the warranty card included in your package for detailed terms and conditions.

For technical support, warranty claims, or any inquiries regarding your product, please contact Snailax customer service through their official website or the contact information provided in your warranty documentation.

© 2023 Snailax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question