

LENRUE LENRUE 1059

LENRUE Computer Speakers User Manual

Model: LENRUE 1059 | Brand: LENRUE

INTRODUCTION

Thank you for choosing LENRUE Computer Speakers. These speakers are designed to provide a clear and loud stereo sound experience for your desktop, laptop, iMac, or MacBook. Featuring easy USB/USB-C connectivity, a convenient headphone output jack, and dynamic lighting, these speakers are perfect for enhancing your audio for games, music, movies, and online meetings. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new speakers.



Image: The LENRUE Computer Speakers, showcasing their sleek black design and included USB and 3.5mm audio cables, along with a USB-C to USB adapter.

PRODUCT FEATURES

- **Stereo and Noiseless Audio:** Engineered to deliver clear, loud stereo sound with suppressed static for an enhanced listening experience.
- **Versatile Connectivity:** USB-powered with 3.5mm audio input, compatible with USB and USB-C ports via the included adapter.
- **Integrated Headphone Output Jack:** A convenient 3.5mm jack allows for private listening without disturbing others.
- **Dynamic RGB Lighting:** Features touch-controlled cyclic lights that add an atmospheric visual element to your setup.
- **Easy Volume Control:** A rotary knob on the speaker provides intuitive volume adjustment.
- **Plug and Play:** No drivers required for installation, ensuring quick and easy setup across various operating systems.
- **Wide Compatibility:** Supports Windows (Vista / 7 / 8 / 10), Mac OS, Chrome OS, Linux, and UNIX systems.



Image: An exploded view illustrating the internal components of the LENRUE speaker, highlighting its drivers and design for loud, clear, and stereo sound output.

SETUP GUIDE

Follow these steps to connect your LENRUE Computer Speakers to your device:

1. **Position the Speakers:** Place the left and right speakers on either side of your monitor or laptop. The cable connecting the two speakers is approximately 55 inches long, allowing for flexible placement.
2. **Connect Audio Cable:** Insert the 3.5mm audio jack from the speakers into the audio output port (headphone jack) of your computer, laptop, or monitor.
3. **Connect Power Cable:** Insert the USB-A connector from the speakers into an available USB port on your computer or a USB power adapter (5V, 1A recommended). If your device only has USB-C ports,

use the included USB-C to USB-A adapter.

4. **Power On and Adjust Volume:** Once connected, the speakers will power on. Rotate the volume knob on the front of the right speaker clockwise to increase the volume.
5. **System Settings (if necessary):** Ensure your computer's audio output is set to the connected speakers. This is usually done in your operating system's sound settings.



Image: A close-up view demonstrating the connection of the USB-C to USB adapter with the speaker's USB cable, illustrating how to connect to modern devices like a MacBook Pro.



Image: The LENRUE speakers positioned next to a laptop, with icons representing compatibility with Windows, Mac OS, Chrome OS, Linux, and UNIX, emphasizing their plug-and-play functionality.

OPERATING INSTRUCTIONS

Volume Control

The volume of the speakers can be adjusted using the rotary knob located on the front of the right speaker. Rotate clockwise to increase volume and counter-clockwise to decrease volume. You can also control the volume through your connected device's system settings.

Lighting Control

The speakers feature dynamic RGB lighting. There is an independent touch button to control the lights. Simply touch the designated area on the speaker to toggle the cyclic lights on or off.

Touch Breathing Light



Touch turn on/off



Image: The speakers on a desk setup, illustrating the "Touch Breathing Light" feature, with an icon indicating the touch control for turning the lights on or off.

Headphone Jack Usage

For private listening, plug your headphones into the 3.5mm headphone output jack located on the front of the right speaker. When headphones are plugged in, the speaker audio will automatically mute, and sound will be routed through your headphones. Unplugging the headphones will revert audio back to the speakers.

Headphone Jack



Image: A close-up of the speaker showing the headphone jack, with headphones plugged in, demonstrating the private listening feature.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners or abrasive materials, as they may damage the finish or internal components.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the speakers.
- **Handling:** Handle the speakers with care. Avoid dropping them or subjecting them to strong impacts.
- **Cable Management:** Keep cables organized and free from kinks or excessive bending to prevent damage.

TROUBLESHOOTING

If you encounter any issues with your LENRUE Computer Speakers, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speakers	<ul style="list-style-type: none">Speakers not powered on.Audio cable not fully connected.Incorrect audio output selected on computer.Volume too low.Headphones plugged in.	<ul style="list-style-type: none">Ensure USB power cable is securely connected to a working USB port.Check that the 3.5mm audio jack is fully inserted into your device's audio output.Verify your computer's sound settings are configured to output audio to the speakers.Increase the volume using the rotary knob on the speaker and your computer's volume control.Unplug headphones from the speaker's headphone jack.
Sound is distorted or unclear	<ul style="list-style-type: none">Volume set too high.Audio source quality is low.Loose cable connection.	<ul style="list-style-type: none">Reduce the volume on both the speakers and your device.Try a different audio source to check if the issue persists.Ensure all cables are securely connected.
Lights are not working	<ul style="list-style-type: none">Lights are turned off.Power issue.	<ul style="list-style-type: none">Touch the light control button on the speaker to turn them on.Ensure the speakers are receiving adequate power via the USB connection.

SPECIFICATIONS

Feature	Detail
Model Name	LENRUE 1059
Speaker Type	Surround Sound (2.0 Channel)
Connectivity Technology	USB, USB-C (with adapter), 3.5mm Audio Jack
Audio Output Mode	Stereo
Speaker Maximum Output Power	10 Watts
Power Source	USB (5V, 1A)
Material	Plastic
Colour	Black
Product Dimensions (D x W x H)	9D x 17.5W x 6.8H Centimetres
Item Weight	21.86 Ounces (approx. 619.72 grams)
Compatible Devices	Personal Computer, Desktop, Laptop, Tablet, iMac, MacBook

Feature	Detail
Operating System Compatibility	Windows (Vista / 7 / 8 / 10), Mac OS, Chrome OS, Linux, UNIX

WARRANTY AND SUPPORT

LENRUE products are designed for reliability and performance. For information regarding warranty coverage, technical support, or service inquiries, please refer to the contact information provided with your product packaging or visit the official LENRUE website. Please retain your proof of purchase for warranty claims.