



Manuals.plus /

- › DeLUX /
- › DeLUX GM902Pro Wireless Ergonomic Keyboard User Manual

DeLUX GM902PRO-White

DeLUX GM902Pro Wireless Ergonomic Keyboard User Manual

Model: GM902PRO-White | Brand: DeLUX

INTRODUCTION

The DeLUX GM902Pro is an upgraded ergonomic wireless keyboard designed for natural and comfortable typing. Its curved and split structure promotes a healthy arm angle, reducing wrist strain and shoulder pain. This keyboard offers versatile connectivity options, a long-lasting rechargeable battery, and quiet scissor switches for an enhanced typing experience.



Image: The DeLUX GM902Pro wireless ergonomic keyboard in white, featuring a split design and integrated wrist rest.

PACKAGE CONTENTS

- DeLUX GM902Pro Wireless Ergonomic Keyboard
- 2.4G USB Receiver
- Type-C Charging Cable
- User Manual (this document)

SETUP

1. Charging the Keyboard

Before first use, it is recommended to fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port (located on the side) and to a USB power source. The battery capacity indicator (top-middle of the keyboard) will show charging status.



TYPE WITH THE BACKLIT

simple backlit brightness adjustment by pressing the Light key,
there are 4 brightness levels for adjusting light off-brightness1-brightness2-brightness3


Image: Close-up view of the keyboard showing the Type-C charging port and battery indicator lights.

2. Connecting to Devices

The DeLUX GM902Pro supports connection with up to 3 devices via 2.4G wireless (USB receiver) and Bluetooth 5.0 (BT1 + BT2 channels).

2.1. 2.4G Wireless Connection

1. Locate the 2.4G USB receiver, typically stored in a compartment on the keyboard's underside.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the keyboard using the power switch. The keyboard should automatically connect.



FRONT AND PALM KICKSTAND

Considering seated or standing posture

Image: A small 2.4G USB receiver, used for wireless connection to a computer.

2.2. Bluetooth Connection (BT1 / BT2)

1. Turn on the keyboard.
2. Press the Bluetooth channel button (BT1 or BT2) on the keyboard until the corresponding indicator light blinks, indicating pairing mode.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and search for "DeLUX GM902Pro" (or similar).
4. Select the keyboard to pair. Once connected, the indicator light will become solid.
5. Repeat for a second Bluetooth device using the other BT channel.



ADVANCED QUIET TYPING

With convex and scooped keycap
and scissor switches

Image: The keyboard shown on a desk with icons indicating connectivity to a desktop PC, laptop, and tablet via 2.4G and Bluetooth.

OPERATING THE KEYBOARD

Switching Between Devices

To switch between connected devices, simply press the corresponding connection button (2.4G, BT1, or BT2) on the keyboard. The keyboard will instantly switch to the selected device.

Backlight Adjustment

The keyboard features adjustable backlighting. Press the "Light" key (usually indicated by a lightbulb icon) to cycle through 4 brightness levels: light off, brightness 1, brightness 2, and brightness 3.



TYPING WITH THE LIGHT


simple backlit brightness adjustment by pressing the Light key, there are 4 brightness levels for adjusting (light off-brightness 1-brightness 2-brightness 3)

Image: The keyboard with its white backlight illuminated, demonstrating the visibility of keys in low light conditions.

Ergonomic Design Features

The keyboard's design prioritizes user comfort and natural posture:


- **Curved and Split Structure:** Allows for a natural arm angle, reducing strain.
- **Built-in Pillowed Wrist Rest:** Made with skin-friendly synthetic leather, it supports the palm to maintain a comfortable typing level.
- **Front and Palm Kickstands:** Four adjustable kickstands allow you to customize the keyboard's angle (3°, 5°, 1.5° reverse tilt) to suit seated or standing postures.



SPLIT ERGO STRUCTURE

In natural arm angle for comfortable typing posture

Image: An illustration demonstrating the natural arm and wrist posture achieved with the split ergonomic keyboard, highlighting reduced strain.




DECENT ERGO KEYBOARD SIZE

Balancing the keyboard and mouse space

Image: The underside of the keyboard showing the four adjustable kickstands that allow for different typing angles.

Scissor Switches and Keycaps

The keyboard utilizes low-profile scissor switches for quiet, fast, and responsive typing. The keycaps feature a convex and scooped design for accurate typing orientation, with alpha keys having scooped keycaps and function keys having convex keycaps to help maintain focus.



BT₁ BT₂ 2.4G



USE WITH UP TO 3 DEVICES

2.4G wireless and BT

Image: A close-up view of the keyboard showing the internal scissor switch mechanism beneath removed keycaps, illustrating the low-profile design.

Multimedia Control

By pressing the FN + ESC combo key, you can shift key functions between F1-F12 keys and multimedia shortcuts.

MAINTENANCE

To ensure the longevity and optimal performance of your DeLUX GM902Pro keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface. For deeper cleaning, a slightly damp cloth can be used, ensuring no moisture enters the key switches or internal components. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** While the keyboard has a long battery life, avoid completely draining the battery frequently. Charge it when the low battery indicator appears.
- **Avoid Spills:** Keep liquids away from the keyboard to prevent damage to internal electronics.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding (2.4G)	Low battery; USB receiver not properly connected; Driver issue.	Charge the keyboard. Re-insert the USB receiver. Try a different USB port. Restart your computer.
Keyboard not responding (Bluetooth)	Low battery; Not paired; Out of range; Bluetooth interference.	Charge the keyboard. Ensure keyboard is in pairing mode. Re-pair the keyboard. Move closer to the device. Disable other Bluetooth devices temporarily.
Keys not registering or repeating	Low battery; Debris under keycap; Software issue.	Charge the keyboard. Gently clean around and under the affected key. Restart your computer.
Backlight not working	Backlight turned off; Low battery.	Press the "Light" key to cycle through brightness levels. Charge the keyboard.

SPECIFICATIONS

Product Dimensions: 16.69 x 9.13 x 1.1 inches

Item Weight: 2.07 pounds

Manufacturer: DELUX

Item Model Number: GM902PRO-White

Batteries: 1 Lithium Polymer battery (included)

Compatible Devices: Laptop, PC, Smart TV, Tablet, Smartphone

Connectivity Technology: Wireless, 2.4G USB-C, Bluetooth

Keyboard Description: Ergonomic, Wireless, Backlight

Special Feature: Wireless, Ergonomic, Backlit, Wrist Rest, Rechargeable

Color: White

Number of Keys: 101

Keyboard Backlighting Color Support: Single Color

Style: Modern

WARRANTY AND SUPPORT

The DeLUX GM902Pro keyboard typically comes with a one-year warranty from the date of purchase. For warranty claims, technical support, or any product-related inquiries, please contact DeLUX customer service through their official website or the retailer where the product was purchased.

You can also refer to the official [User Manual \(PDF\)](#) for additional information.