Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EMMA + OLIVER EOH-OBOD-716144

EMMA + OLIVER L-Shaped Computer Corner Glass Desk Instruction Manual

Model: EOH-OBOD-716144

Introduction
Safety Information
Components
Setup & Assembly
Operating Instructions
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your EMMA + OLIVER L-Shaped Computer Corner Glass Desk. Please read this manual thoroughly before assembly and retain it for future reference. Proper assembly and care will ensure the longevity and safe use of your desk.

2. Safety Information

Adhere to the following safety guidelines to prevent injury or damage to the product:

- **Weight Limit:** Do not exceed the maximum weight capacity of 110 lbs (50 kg) on the desk surface.
- **Assembly:** Always assemble the desk according to the provided instructions. Ensure all fasteners are securely tightened before use.
- **Stability:** Ensure the desk is placed on a level surface. The self-leveling floor glides should be adjusted to prevent wobbling.
- **Placement:** Keep the desk away from direct heat sources, open flames, and excessive moisture.
- **Glass Care:** The desk features a tempered glass top. Avoid dropping heavy or sharp objects onto the glass. Do not place extremely hot items directly on the glass without protection.
- **Children:** Keep small parts and assembly tools out of reach of children.

3. Components List

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Two (2) Glass Desk Panels (35.5"W x 23.5"D x 29"H each)
- One (1) Corner Connector Glass Panel (33.25"W x 23.5"D)
- Silver Powder Coated Metal Frame components
- Self-leveling Floor Glides
- Assembly Hardware (screws, bolts, washers, etc.)
- Assembly Tools (if included)




Figure 3.1: Exploded view of the EMMA + OLIVER L-Shaped Computer Corner Glass Desk components, showing the glass panels, metal frame parts, and hardware.

4. Setup & Assembly

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Assemble Frame Sections:** Begin by assembling the individual metal frame sections for the two main desk panels. Attach the crossbars and support wires as indicated in the diagram.
3. **Attach Glass Panels:** Carefully place the tempered glass panels onto the assembled frame sections. Secure them using the provided fasteners. Ensure the glass is seated correctly and evenly.
4. **Connect Corner Section:** Position the two main desk sections and attach the corner connector glass panel. Secure it to both main sections using the designated hardware.
5. **Install Floor Glides:** Screw the self-leveling floor glides into the bottom of each leg. Adjust them as needed to ensure the desk is stable and level on your floor.
6. **Final Check:** Verify that all screws and bolts are tightened. Gently test the desk for stability before placing any items on it.



Figure 4.1: View of the assembled desk frame with glass tops, showing the L-shaped configuration and silver powder-coated metal structure.



Figure 4.2: Close-up details highlighting the 5mm thick tempered glass surface, silver powder-coated metal frame, designer bracing, and self-leveling floor glides.

5. Operating Instructions

Your EMMA + OLIVER L-Shaped Computer Corner Glass Desk is designed for versatile use in home offices, gaming setups, or general workspaces.

- **Placement:** Position the desk in a corner to maximize space, or utilize its L-shape for an open-concept layout.
- **Weight Distribution:** Distribute weight evenly across the desk surface. Avoid concentrating heavy items on one small area or near the edges.
- **Monitor Setup:** The corner connector is designed to accommodate multiple monitors. Ensure monitors are placed securely.
- **Cable Management:** Utilize the open frame design for routing cables neatly to maintain an organized workspace.



Figure 5.1: The EMMA + OLIVER L-Shaped Computer Corner Glass Desk in use, demonstrating its capacity for a computer, camera, and other office items, alongside an office chair.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your desk.

- **Cleaning Glass:** Use a soft, lint-free cloth and a glass cleaner to wipe the tempered glass surface. Avoid abrasive cleaners or scouring pads that can scratch the glass.
- **Cleaning Frame:** Wipe the metal frame with a damp cloth and mild detergent if necessary. Dry immediately to prevent water spots.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if any looseness is detected.
- **Avoid Harsh Chemicals:** Do not use strong chemical cleaners, solvents, or polishes on any part of the desk, as they may damage the finish.

7. Troubleshooting

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Uneven floor surface; loose assembly hardware.	Adjust the self-leveling floor glides until stable. Check and tighten all assembly screws and bolts.
Glass panels do not align correctly.	Incorrect assembly of frame or glass panels.	Disassemble the affected section and re-assemble carefully, ensuring all parts are oriented correctly as per instructions.
Scratches on glass surface.	Abrasive cleaning materials; sharp objects placed on glass.	Use only soft cloths and appropriate glass cleaner. Avoid placing sharp or abrasive items directly on the glass.

8. Specifications

Brand	EMMA + OLIVER
Model Number	EOH-OBOD-716144
Overall Dimensions	83.5"W x 48"D x 29"H
Glass Desk Panels (each)	35.5"W x 23.5"D x 29"H
Corner Connector Panel	33.25"W x 23.5"D
Top Material	5mm Thick Tempered Glass
Base Material	Alloy Steel (Silver Powder Coated)
Color	Black Top / Silver Frame
Weight Capacity	110 lbs (static weight)
Assembly Required	Yes
Item Weight	56 Pounds




Figure 8.1: Dimensional diagram of the EMMA + OLIVER L-Shaped Computer Corner Glass Desk, indicating overall width, depth, and height, as well as individual panel dimensions.

9. Warranty & Support

This EMMA + OLIVER product is covered by a**1-year limited manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, missing parts, or technical support, please contact EMMA + OLIVER customer service. Refer to your purchase documentation for specific contact information or visit the official EMMA + OLIVER website.

Important: Retain your proof of purchase for warranty validation.

© 2025 EMMA + OLIVER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZJVLT9Z

More documents and user manuals: **https://manuals.plus/**