

Aiwa AWPOC10L

Aiwa AWPOC10L DJ Party Speaker User Manual

INTRODUCTION

Thank you for purchasing the Aiwa AWPOC10L DJ Party Speaker. This powerful audio system is designed to deliver an immersive sound experience with its 2500W output, versatile connectivity options, and dynamic LED lighting. Please read this manual carefully before using the product to ensure proper operation and to maximize its features.

IMPORTANT SAFETY INFORMATION

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

PACKAGE CONTENTS

- Aiwa AWPOC10L DJ Party Speaker
- Power Cable
- User Manual (this document)

PRODUCT OVERVIEW

The Aiwa AWPOC10L is a floor-standing DJ Party Speaker featuring dual woofers and tweeters, integrated LED lighting, and a comprehensive control panel.

Front Panel



Image: Front view of the Aiwa AWPOC10L DJ Party Speaker, showcasing its two large woofers with illuminated LED rings and two smaller tweeters at the top. The speaker is black with a textured finish.

Control Panel



Image: Close-up of the top control panel of the Aiwa AWPOC10L speaker, showing various knobs, buttons, and input ports for USB, microphones, and auxiliary connections.

SETUP

Unpacking and Placement

Carefully remove the speaker from its packaging. Place the speaker on a stable, flat surface. Ensure there is adequate ventilation around the unit.



Image: The Aiwa AWPOC10L DJ Party Speaker positioned in a modern room, demonstrating its sleek, tall design and how it fits into a living space.

Power Connection

Connect the power cable to the AC IN port on the rear of the speaker and then plug it into a standard wall outlet.

OPERATING INSTRUCTIONS

Power On/Off

Press the Power button on the control panel to turn the speaker ON or OFF.

Bluetooth Pairing (TWS)

The AWPOC10L features Bluetooth connectivity with True Wireless Stereo (TWS) function, allowing you to connect two AWPOC10L speakers for a stereo sound experience.

1. Turn on both AWPOC10L speakers.
2. Ensure both speakers are in Bluetooth mode.
3. On one speaker, press and hold the TWS button (if available, or follow specific pairing instructions in the quick start guide if not explicitly on the panel). The speaker will indicate it's searching for another TWS device.
4. Once connected, the speakers will form a stereo pair.
5. On your mobile device, search for "AWPOC10L" in your Bluetooth settings and connect.



Image: Two Aiwa AWPOC10L speakers standing side-by-side, illustrating the True Wireless Stereo (TWS) function with their synchronized, colorful LED lights, creating an immersive audio-visual experience.

USB Playback

Insert a USB flash drive into the USB port on the control panel. The speaker will automatically detect and play compatible audio files.

AUX/RCA Input

Connect external audio devices (e.g., smartphone, tablet, TV) using a 3.5mm AUX cable or RCA cables to the respective input ports on the control panel.

Microphone/Karaoke Function

The speaker supports two microphone inputs for karaoke. Connect your microphones to the MIC 1 and MIC 2 ports. Adjust microphone volume and echo effects using the dedicated controls.



Image: A person singing into a microphone, with the Aiwa AWPOC10L speaker visible in the background, demonstrating its karaoke feature in a party setting.

LED Light Control

The integrated LED lights can be controlled via the control panel. Select different lighting modes or turn them off as desired.



Image: A group of people dancing in a dimly lit room, with the Aiwa AWPOC10L speaker prominently displayed in the foreground, its LED lights illuminating the scene and enhancing the party atmosphere.

Equalizer Settings

The speaker features a 10-band equalizer with preset configurations. Use the EQ controls to adjust the sound

profile to your preference for different music genres.

MAINTENANCE

Cleaning

Wipe the speaker's surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

No Power

- Ensure the power cable is securely connected to the speaker and the wall outlet.
- Check if the wall outlet is functioning by plugging in another device.

No Sound

- Check the volume level on the speaker and your connected device.
- Ensure the correct input source (Bluetooth, USB, AUX, RCA) is selected.
- If using Bluetooth, ensure the device is properly paired.

Bluetooth Pairing Issues

- Make sure the speaker is in Bluetooth pairing mode.
- Ensure your device's Bluetooth is enabled and within range (up to 10 meters).
- Forget the device from your phone's Bluetooth list and try pairing again.
- If using TWS, ensure both speakers are in TWS pairing mode before connecting your device.

SPECIFICATIONS

Feature	Detail
Model	AWPOC10L
Output Power	2500W (PMPO)
Speaker Drivers	2 x 10" Woofers, 2 x 3" Tweeters
Connectivity	Bluetooth, USB, RCA, 3.5mm AUX, 2 x MIC
Special Features	True Wireless Stereo (TWS), LED Lights, Karaoke Function, 10-band Equalizer
Power Source	AC Cable
Dimensions (L x W x H)	42.5 x 39.5 x 116 cm
Weight	16 kg

Material	Plastic
Bluetooth Frequency	2402 MHz

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Aiwa website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact Aiwa customer service through their official channels.