

[Manuals.plus](#) /

› [MoNiBloom](#) /

› MoNiBloom Massage Gaming Chair User Manual

MoNiBloom A11-GC-LS-002-GN

MoNiBloom Massage Gaming Chair User Manual

Model: A11-GC-LS-002-GN | Brand: MoNiBloom

INTRODUCTION

Welcome to the user manual for your new MoNiBloom Massage Gaming Chair. This chair is designed to provide ultimate comfort and functionality for gaming, working, or relaxing. It features an integrated massage system, Bluetooth speakers, and adjustable reclining positions to enhance your experience. Please read this manual thoroughly before assembly and use to ensure proper operation and maintenance.



IMPORTANT SAFETY INFORMATION

For your safety and to prevent damage to the product, please adhere to the following guidelines:

- Do not use if your weight exceeds 300 LBS.
- Keep liquids and sharp objects away from electrical components.
- Ensure the chair is on a stable, level surface when reclining or using the footrest.
- Do not stand on the chair.
- Keep children and pets away from moving parts.

PRODUCT FEATURES

Massage Function to Relax Your Body

This gaming chair is equipped with 8 massage spots: 2 on the shoulder, 2 on the lumbar, 2 on the thigh, and 2 on the calf.

It offers 5 massage modes and 2 massage strengths, along with adjustable positions and time settings, to cater to your specific relaxation needs. It serves as an ideal seat for working, studying, and gaming.

MASSAGE FUNCTION

5 massage modes, 2 intensities.



Massge Intensity Control

Five Massage Mode Options

Backrest Position Selection

Lumbar Position Selection

Thigh Position Selection

Leg Position Selection

Massage Time



MASSAGE TIME
PRECISE CONTROL OF
MASSAGE TIME



COMFORTABLE
EFFECTIVE SPINE
PROTECTION

Detailed view of the massage function remote control and the chair's massage zones.

Audio Gaming Chair with Bluetooth Speakers

Built-in dual Bluetooth speakers provide an extraordinary and rich stereo sound experience. Easily connect your mobile phone or other Bluetooth-enabled devices to enjoy immersive audio for games or movies.

POWERFUL SOUND

Bring you an advanced
gaming experience.



Close-up of the 3.5-inch speaker, highlighting the powerful sound feature.

360° STEREO SURROUND




Illustration of a smartphone connected to the chair via Bluetooth, demonstrating the 360-degree stereo surround sound capability.

Adjustable Backrest and Footrest

The gaming recliner chair features an adjustable backrest (95-125 degrees) and a retractable footrest, allowing you to find the most comfortable angle for relaxation or focused activity.

RECLINABLE SEAT BACK



Visual representation of the chair's reclinable seat back, illustrating the adjustment from 95-degree working position to 125-degree resting position.

Humanized Design

Includes a removable headrest for enhanced comfort during long gaming sessions. A convenient side pouch stores controllers or other items, and cup holders on both armrests keep your drinks accessible.

High Quality and Comfortable Material

Covered with environmentally friendly PU leather, the chair is skin-friendly, easy to clean, breathable, and water-proof. Padded with high-density sponge, it offers superior resilience and comfort.

HIGH-DENSITY SPONGE



Close-up image demonstrating the high-density sponge padding for enhanced comfort.

SETUP INSTRUCTIONS

While specific assembly steps are not detailed here, general setup typically involves:

1. **Unpacking:** Carefully remove all components from the packaging and verify against the parts list provided in your product box.
2. **Base Assembly:** Attach the chair base to the main seat frame.
3. **Backrest Attachment:** Secure the backrest to the seat.
4. **Armrest Installation:** Attach the armrests, ensuring they are firmly secured.
5. **Footrest Assembly:** Install the retractable footrest mechanism.
6. **Cushion and Accessories:** Place the headrest cushion and connect any electrical components like the massage remote and power supply.

Refer to the detailed assembly diagram included with your product for precise instructions and component identification.

PRODUCT DIMENSIONS



Product dimensions, useful for planning space during setup.

OPERATING INSTRUCTIONS

Using the Massage Function:

- **Power On/Off:** Connect the chair to a power source. Use the "POWER" button on the wired remote control to turn the massage function on or off.
- **Mode Selection:** Press the "MODE" button to cycle through the 5 available massage modes.
- **Intensity Adjustment:** Use the "STRENGTH" buttons (up/down arrows) to select between the 2 massage intensity levels.
- **Position Selection:** Select specific massage zones (shoulder, lumbar, thigh, calf) using the corresponding buttons on the remote.
- **Timer Setting:** Adjust the massage duration using the "TIME" button.

Connecting Bluetooth Speakers:

- **Activate Bluetooth:** Ensure the chair's Bluetooth function is active (refer to the chair's power controls if applicable).
- **Pairing:** On your mobile device, search for Bluetooth devices. Select "MoNiBloom Chair" (or similar name) from the list to pair.
- **Audio Playback:** Once paired, audio from your device will play through the chair's speakers.

Adjusting Backrest and Footrest:

- **Reclining:** Locate the reclining lever (typically on the side of the chair). Pull the lever and lean back to adjust the backrest angle between 95 and 125 degrees. Release the lever to lock the position.
- **Footrest:** To extend the footrest, pull the designated lever or push forward with your legs. To retract, push the footrest back into its original position.

MAINTENANCE

To ensure the longevity and appearance of your MoNiBloom Massage Gaming Chair, follow these simple maintenance steps:

- **Cleaning:** Wipe the chair with a damp cloth. For tougher stains, use a mild soap solution and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately clean up any spills to prevent staining or damage to the PU leather.
- **Electrical Components:** Keep all electrical components, including the remote and power cords, dry and free from dust.
- **Moving Parts:** Periodically check all bolts and screws to ensure they are tight. Do not over-tighten.

TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Massage function not working.	Power cord not connected; remote control issue; power outlet problem.	Ensure power cord is securely plugged into chair and outlet. Check if outlet is functional. Verify remote control cable is connected.
Bluetooth speakers not connecting.	Bluetooth not enabled on chair/device; device too far; already paired with another device.	Ensure Bluetooth is on for both chair and device. Move device closer. Disconnect from other devices. Try re-pairing.
Chair does not recline smoothly.	Mechanism obstruction; loose connections.	Check for any objects obstructing the reclining mechanism. Ensure all assembly bolts are tightened.
Unstable or wobbly.	Loose assembly bolts; uneven surface.	Check and tighten all assembly bolts. Ensure the chair is placed on a flat, level surface.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Brand: MoNiBloom

Model Name: MoNiBloom A11-GC-LS-002-GN

Color: Green

Product Dimensions: 23"D x 32"W x 43"H

Maximum Weight Recommendation: 300 Pounds

Material: Environmental friendly PU leather, High-density sponge fill

Back Style: Solid Back

Special Features: Adjustable Lumbar, Arm Rest, Cushion Availability, Ergonomic, Swivel, Massage Function, Bluetooth Speakers, Retractable Footrest

Reclining Position Count: 3 or more (95-125 degrees)

Item Weight: 50.7 pounds

UPC: 840256416640

WARRANTY AND SUPPORT

MoNiBloom is committed to providing high-quality products and customer satisfaction. For any questions, concerns, or warranty inquiries regarding your Massage Gaming Chair, please contact MoNiBloom customer support through the retailer's platform or the official MoNiBloom website. Please have your model number (A11-GC-LS-002-GN) and purchase information ready when contacting support.

For more information, visit the [MoNiBloom Store on Amazon](#).

© 2025 MoNiBloom. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

