

[Manuals.plus](#) /

› [Blackview](#) /

› Blackview A53 Smartphone User Manual

Blackview bvdcus-A53Black/Grey/Blue

Blackview A53 Smartphone User Manual

Model: bvdcus-A53Black/Grey/Blue

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Blackview A53 Smartphone. Please read it thoroughly before using the device to ensure proper functionality and to prevent damage.



Figure 1.1: Blackview A53 Smartphone (Grey variant shown)

2. WHAT'S IN THE BOX

Upon opening the package, verify that all items are present:

- Blackview A53 Smartphone
- Power Adapter
- USB Cable

- Phone Case

Your browser does not support the video tag.

Video 2.1: Blackview A53 Smartphone Unboxing and Overview. This video demonstrates the contents of the package and provides a brief overview of the phone's design and features.

3. INITIAL SETUP

3.1 Inserting SIM and SD Cards

The Blackview A53 supports a triple SIM card slot design, allowing for two Nano SIM cards and one Micro SD card simultaneously. Ensure the phone is powered off before inserting or removing cards.

1. Locate the SIM/SD card tray on the side of the device.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your Nano SIM cards and Micro SD card into their respective slots on the tray.
4. Gently push the tray back into the phone until it is flush with the device body.
5. After inserting an SD card, restart your phone for it to be recognized.

A Place for all Your Memories

More space to store your wonderful lifetime




Figure 3.1: Triple SIM Card Slots Design

3.2 Charging the Battery

Before first use, fully charge the device. Connect the USB cable to the phone's charging port and the power adapter, then plug the adapter into a wall outlet. The 5080mAh battery provides extended usage time.

Battery For Your Whole Day

5080mAh long-lasting Battery

Use Time:



6.2 hrs
Game



8 hrs
Movie



9.5 hrs
Web



20 hrs
Call



22 hrs
Music



624 hrs
Standby



Figure 3.2: Charging the Blackview A53 Smartphone

4. OPERATING YOUR SMARTPHONE

4.1 Power On/Off

Press and hold the Power button (located on the right side of the device) until the Blackview logo appears to power on. To power off, press and hold the Power button, then select "Power off" from the options.

4.2 Display and Navigation

The Blackview A53 features a 6.517-inch HD+ Waterdrop Display with 720x1600 resolution and a 60Hz refresh rate. Navigate the interface using touch gestures: tap, swipe, pinch-to-zoom.

Cinematic Viewing Experience

6.517" HD+ Waterdrop Display



Figure 4.1: High-Definition Display

4.3 Android 12 and Doke OS 3.0

Your smartphone runs on Android 12 OS, enhanced with Blackview's Doke OS 3.0. This combination offers an optimized user experience with features like dark mode, chat bubbles, and parental control mode.



Figure 4.2: Android 12 and Doke OS 3.0 Interface

4.4 Camera Functions

The Blackview A53 is equipped with a 12MP rear camera and a 5MP front camera. Open the Camera application to capture photos and videos. Utilize the various modes available for different shooting scenarios.



Figure 4.3: Camera Specifications

4.5 Face ID Unlock

For quick and secure access, set up Face ID unlock in the security settings. This feature allows you to unlock your phone by simply looking at the front camera.

5. MAINTENANCE AND CARE

5.1 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials that could damage the surface.

5.2 Battery Longevity

To maximize battery life, avoid extreme temperatures, do not overcharge, and consider enabling power-saving modes when the battery is low.

5.3 Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to **Settings > System > System update**

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not power on.	Low battery; software crash.	Charge the phone for at least 30 minutes. Press and hold the Power button for 10-15 seconds to force restart.
SD card not recognized.	Card not properly seated; phone not restarted.	Ensure the SD card is correctly inserted. Restart the phone after insertion.
No network signal.	SIM card issue; out of network coverage; incorrect network settings.	Check SIM card insertion. Move to an area with better coverage. Verify network settings in Settings > Network & internet > Mobile network Note: This phone does not work with CDMA carriers like Verizon and Sprint.
Apps are slow or freezing.	Too many apps running; low storage; software glitch.	Close background apps. Clear app cache. Free up storage space. Restart the phone.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	Blackview A53 (bvdcus-A53Black/Grey/Blue)
Operating System	Android 12.0 (with Doke OS 3.0)
Processor	Quad-core MT6761V (2.0GHz)
RAM	7GB (4GB + 3GB Extended RAM)
Internal Storage (ROM)	32GB
Expandable Storage	Micro SD up to 128GB
Display Size	6.517 inches HD+ Waterdrop Display
Resolution	720 x 1600 pixels
Refresh Rate	60Hz
Brightness	500 nits

Feature	Specification
Rear Camera	12MP
Front Camera	5MP
Battery Capacity	5080mAh Lithium Polymer
SIM Card Slots	Triple (2 Nano SIM + 1 Micro SD)
Network Compatibility	4G GSM (T-Mobile, Qlink, Metro PCS, Tello Mobile, Orange Congo DRC/Airtel/Vodacom/Africell, Movistar, Telcel, Tigo, Claro). <i>Does not support CDMA carriers (e.g., Verizon, Sprint).</i>
Navigation	GPS, GLONASS, Galileo, BEIDOU
Dimensions	5.7 x 2.5 x 0.36 inches
Weight	6.9 ounces

8. WARRANTY AND SUPPORT

Blackview offers a lifetime warranty and lifetime customer service for the A53 Smartphone. If you encounter any issues with your product, please contact Blackview customer support for assistance. They are committed to resolving any problems by fixing, replacing, or addressing any product-related concerns. For further support, visit the official Blackview store or contact their customer service channels.

Blackview Store: <https://www.amazon.com/stores/Blackview/page/DA18B8BF-16DB-472E-8F1A-E37ECE5C8DE3>

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question