

JEDELEOS 07252390

JEDELEOS Replacement Belts for Miele S7 and Dynamic U1 Series Vacuums Instruction Manual

Model: 07252390

INTRODUCTION

This instruction manual provides essential information for the installation and maintenance of JEDELEOS replacement belts for Miele S7 and Dynamic U1 Series upright vacuum cleaners. Proper installation and regular replacement ensure optimal performance of your vacuum cleaner.



Image: Two replacement belts and a Miele S7 vacuum. These belts are designed to restore the brush roll function of compatible Miele vacuum models.

COMPATIBILITY

These replacement belts are compatible with the following Miele S7, S7000, and Dynamic U1 Series upright vacuum cleaner models:

- Miele S7210 Twist
- Miele S7260 Cat & Dog
- Miele S7280 Jazz
- Miele S7280 Salsa
- Miele S7580 Pirouette
- Miele S7580 Bolero
- Miele S7580 Tango
- Miele S7580 Swing



Image: Visual representation of compatible Miele S7 series vacuum models. The belts are designed to fit these specific models.

PACKAGE CONTENTS

Each package contains:

- 2 x JEDELEOS Replacement Belts (Part 07252390)



Image: The two replacement belts included in the package.

INSTALLATION INSTRUCTIONS

Replacing the drive belt on your Miele S7 or Dynamic U1 Series vacuum cleaner is a straightforward process. Always ensure the vacuum cleaner is unplugged from the power outlet before beginning any maintenance.

1. **Power Disconnection:** Unplug your Miele vacuum cleaner from the electrical outlet to prevent accidental startup.
2. **Access Brush Roll:** Carefully turn the vacuum cleaner over to access the brush roll area on the underside of the powerhead.
3. **Remove Base Plate:** Depending on your specific model, you may need to remove screws or release clips to detach the base plate covering the brush roll and belt. Refer to your vacuum's original manual for precise instructions on accessing this area.
4. **Remove Old Belt:** Locate the worn or broken belt. Carefully remove it from around the brush roll and motor shaft.
5. **Install New Belt:** Loop the new JEDELEOS replacement belt around the motor shaft first, then stretch it around the brush roll. Ensure the belt is seated correctly in the grooves of both the motor shaft and the brush roll.
6. **Reassemble:** Reattach the base plate, ensuring all screws or clips are securely fastened.
7. **Test:** Plug in the vacuum cleaner and test the brush roll function to confirm proper installation.

Note: If you encounter difficulty, consult your vacuum cleaner's original user manual or seek assistance from a qualified technician.

OPERATION CONSIDERATIONS

Once the new belt is installed, your vacuum's brush roll should operate effectively, providing optimal cleaning performance. Ensure that the brush roll spins freely and without obstruction before and during operation.

MAINTENANCE AND REPLACEMENT SCHEDULE

To maintain the optimal performance of your Miele vacuum cleaner, it is recommended to inspect and replace the drive belt regularly. Over time, belts can stretch, crack, or break, leading to reduced brush roll effectiveness.

- **Inspection:** Periodically check the belt for signs of wear, such as cracks, fraying, or excessive stretching.
- **Replacement Frequency:** It is generally suggested to replace your vacuum cleaner belts every 3 to 9 months, depending on usage frequency and conditions.



Image: Visual reminder to replace the vacuum belt every 3 to 9 months for optimal performance.

TROUBLESHOOTING

If your vacuum cleaner's brush roll is not functioning correctly after belt replacement, consider the following:

- **Brush Roll Not Spinning:**
 - Ensure the belt is correctly seated on both the motor shaft and the brush roll.

- Check for any obstructions (e.g., hair, debris) wrapped around the brush roll or motor shaft.
- Verify that the brush roll itself is not damaged or seized.

• **Unusual Noise or Slipping:**

- A new belt might initially be tight; however, excessive noise or slipping could indicate improper installation or a belt that is not the correct size for your specific model.
- Ensure the base plate is securely reattached and not interfering with the belt's movement.

• **Reduced Suction (Brush Roll Related):**

- A brush roll that is not spinning at full speed due to a loose or incorrectly installed belt can impact cleaning effectiveness. Re-check belt tension and installation.

SPECIFICATIONS

Part Number	07252390
Material	Rubber
Belt Style	Drive Geared Belt
Color	Black
Compatible Devices	Miele S7, S7000, and Dynamic U1 Series Upright Vacuums (S7210, S7260, S7280, S7580)



Image: Detailed view of the replacement belt's geared design, indicating its construction.

WARRANTY AND SUPPORT

For any questions regarding the JEDELEOS replacement belts or for support with installation and troubleshooting, please refer to the seller's contact information on the original purchase platform. Specific warranty details may vary and are typically provided at the point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BZL314L9>

More documents and user manuals: <https://manuals.plus/>