

[Manuals.plus](#) /

› [slochi](#) /

› slochi 6.5-Inch LED Flush Mount Ceiling Light Instruction Manual

slochi slochi-1PACK-001

slochi 6.5-Inch LED Flush Mount Ceiling Light Instruction Manual

Model: slochi-1PACK-001

INTRODUCTION

Thank you for choosing the slochi LED Flush Mount Ceiling Light. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new light fixture. Please read this manual thoroughly before installation and retain it for future reference.

SAFETY INFORMATION

- Always turn off the power at the circuit breaker before beginning installation.
- Consult a qualified electrician if you are unsure about the installation process.
- Do not attempt to modify the fixture in any way.
- Ensure all electrical connections are secure and comply with local codes.
- This fixture is designed for indoor use and is IP44 waterproof, suitable for damp locations like bathrooms.

WHAT'S IN THE BOX

Verify that all components are present before installation:

- slochi LED Flush Mount Ceiling Light Fixture
- Mounting Hardware (screws, expansion tubes)
- Connector
- Instruction Manual

SETUP AND INSTALLATION

The slochi LED Flush Mount Ceiling Light is designed for easy installation, compatible with most junction boxes. No earth wire connection is required due to its insulated PC plastic housing and CE-approved short-circuit prevention.

Installation Steps:

1. **Prepare for Installation:** Turn off power at the circuit breaker. Locate the desired mounting spot on the ceiling.

2. **Mark and Drill Holes:** Use the mounting bracket as a template to mark the positions for drilling. Drill holes and insert the expansion tubes. The installation width is approximately 3.74 inches.
3. **Fix the Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws and expansion tubes.
4. **Connect Wiring:** Connect the household electrical wires to the light fixture's wiring port using the provided connector. Ensure a secure connection. This fixture does not require an earth wire.
5. **Secure the Lamp Body:** Align the light fixture with the mounting bracket and secure it firmly.



Image: Step-by-step guide for installing the ceiling light, showing drilling, bracket attachment, wiring, and securing the fixture.

Product Dimensions:

The light fixture features an ultra-thin design with a 6.5-inch diameter and a thickness of only 0.72 inches, ensuring a seamless fit against the ceiling.



Image: Diagram illustrating the 6.5-inch diameter and 0.72-inch ultra-thin profile of the light fixture, along with examples of compatible junction boxes.

OPERATING INSTRUCTIONS

This slochi LED ceiling light offers adjustable brightness and three color temperature options to suit your preferences.

Adjusting Color Temperature:

The fixture provides three color temperature settings: Warm White (3000K), Natural White (4000K), and Daylight White (6500K).

To select your preferred color temperature, locate the toggle switch on the back of the fixture before final installation or if accessible.



Image: Visual guide showing the three available color temperatures (3000K, 4000K, 6500K) and how to select them using an easy control switch.

Dimming Functionality:

The light is dimmable, allowing brightness adjustment from 10% to 100%. This feature requires a compatible dimmer switch (not included). The minimum dimming brightness is 10% at 3000K warm white, which can function as a night light.



Image: Illustration of smooth dimming from 0% to 100% using a dimmer switch, demonstrating various brightness levels in a kitchen setting.


Compatible Dimmer Models:

For optimal dimming performance, use one of the following compatible dimmer models:

Manufacturer	Model Number
Lutron	MSCL-OP153MH-WH, PD-6WCL-WH, MACL-153M, DVCL-153P, DV-600P, SCL-153PH-WH, MACL-153MR-WH, DVV-603PGH-WH
Leviton	6672, 6631

Note: Absence of a dimmer on this chart does not imply incompatibility. Please reference the dimmer manufacturer's instructions for

installation and further information.



Compatible dimmer Model No.		
6672	6631	
MSCL-OP153MH-WH	PD-6WCL-WH	MACL-153M
DVCL-153P	DV-600P	SCL-153PH-WH
MACL-153MR-WH	DVW-603PGH-WH	

NOTE:Absence of a dimmer on this chart does not imply incompatibility,please reference the dimmers manufacturer's instructions for installation and further information.

Image: Chart listing compatible dimmer switch models from Lutron and Leviton, with a visual representation of a dimmer switch.

No Flicker and Delay:

The built-in light guide plate ensures even illumination without flickering or delay, providing comfortable and soft light that helps avoid eye fatigue.



Image: A living room illuminated by slochi ceiling lights, with a smartphone camera view demonstrating the absence of flicker.

Product Video:

Your browser does not support the video tag.

Video: An official product video demonstrating the features and functionality of the slochi LED Flush Mount Ceiling Light, including brightness adjustment and color temperature options.

MAINTENANCE

The slochi LED Flush Mount Ceiling Light is designed for long-lasting performance with minimal maintenance.

- **Cleaning:** The lamp is fully enclosed with an IP44 waterproof design, preventing shadows or black spots inside. This design keeps it looking new for many years without requiring internal cleaning. For external cleaning, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Durability:** The fixture is moisture-proof, dustproof, and designed to be mosquito repellent, contributing to its longevity and reducing the need for frequent cleaning.



Image: Visual representation of the light's moisture-proof, dustproof, and mosquito-repellent properties, highlighting its sealed design.

TROUBLESHOOTING

If you encounter any issues with your slochi LED Flush Mount Ceiling Light, please refer to the following common troubleshooting steps:

- **Light Not Turning On:**
 - Check if the power is on at the circuit breaker.
 - Ensure all wiring connections are secure.
 - Verify that the wall switch is in the ON position.
- **Flickering or Dimming Issues:**
 - Confirm that you are using a compatible dimmer switch. Refer to the "Compatible Dimmer Models" section.
 - Check the dimmer switch wiring for loose connections.
- **Incorrect Color Temperature:**
 - Ensure the color temperature toggle switch on the fixture is set to your desired setting.

If these steps do not resolve the issue, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	slochi
Model Number	slochi-1PACK-001
Color	White
Material	Plastic
Style	Modern
Light Source	LED
Wattage	12 watts

Feature	Detail
Brightness	1500 lumens
Color Temperature	3000K (Warm White), 4000K (Natural White), 6500K (Daylight White) Selectable
Dimming Range	10%-100% (with compatible dimmer)
Switch Type	Dimmer compatible
Water Resistance Level	IP44 Waterproof
Mounting Type	Ceiling Mount, Flush Mount
Item Dimensions (L x W x H)	6.5"L x 6.5"W x 1.1"H
Service Life	Up to 25,000 hours
Certifications	ETL / CE certified
Recommended Uses	Home lighting, Bedroom, Bathroom, Living room, Closet, Hallway

WARRANTY AND SUPPORT

Slochi is committed to providing high-performance products and attentive customer service. If you have any questions, concerns, or require assistance with your slochi LED Flush Mount Ceiling Light, please do not hesitate to contact our customer service team. Our friendly customer service will provide fast support within 24 hours.

For support, please visit the [slochi Store on Amazon](#) or refer to the contact information provided with your purchase.

© 2026 slochi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question