

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Zerodeko](#) /

› Zerodeko Small Duck Climbing Stair Toy Instruction Manual

## Zerodeko Small Duck Climbing Stair Toy

# Zerodeko Small Duck Climbing Stair Toy

## INSTRUCTION MANUAL

*Model: Small Duck Climbing Stair Toy*

### Introduction

Thank you for purchasing the Zerodeko Small Duck Climbing Stair Toy. This interactive and engaging toy is designed to provide endless fun for toddlers and young children. Featuring adorable small ducks that climb an escalator and slide down a track, accompanied by cheerful music and colorful lights, it helps develop hand-eye coordination and provides sensory stimulation. Please read this manual carefully before assembly and use to ensure safe and optimal operation.

### What's in the Box

Please check the contents of your package to ensure all parts are present:

- 1 x Main Base Unit with Escalator
- 3 x Slide Track Sections (blue)
- 1 x Decorative Top Board (with "Small Duck" sign)
- 9 x Small Duck Figures



Image: All components included in the package, laid out for assembly.

## Setup and Assembly

Follow these steps to assemble your Small Duck Climbing Stair Toy:

1. **Install Batteries:** Locate the battery compartment on the bottom of the main base unit. Open the cover and insert 3 x AA batteries (not included), ensuring correct polarity (+/-). Close the battery cover securely.
2. **Attach the Decorative Top Board:** Insert the decorative top board, featuring the "Small Duck" sign, into the designated slot at the top of the escalator unit on the main base.
3. **Assemble the Slide Tracks:** Connect the three blue slide track sections. There are specific connection points on the main base unit and between the track sections. Ensure they snap firmly into place to form a continuous slide from the top of the escalator down to the starting point for the ducks.
4. **Place Ducks:** Once assembled, place the small duck figures onto the starting ramp at the bottom of the escalator.



Image: The toy fully assembled, ready for operation.

## Operating Instructions

Using your Small Duck Climbing Stair Toy is simple:

1. **Power On:** Locate the ON/OFF switch on the side of the main base unit. Slide the switch to the "ON" position. The escalator will begin to move, and music and lights will activate.
2. **Place Ducks:** Gently place the small duck figures onto the escalator steps at the bottom. The ducks will automatically climb the stairs.
3. **Enjoy the Show:** Once the ducks reach the top, they will slide down the blue tracks, returning to the starting point to repeat the cycle.
4. **Power Off:** When playtime is over, slide the ON/OFF switch to the "OFF" position to conserve battery life.



Image: Detail of the toy in operation, highlighting the escalator and ducks.

## Maintenance

- **Cleaning:** Wipe the toy with a soft, slightly damp cloth. Do not immerse the toy in water or use harsh cleaning agents.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage. Replace all batteries at the same time with new ones of the same type.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight and extreme temperatures.

## Troubleshooting

Problem	Possible Cause	Solution
Ducks are not climbing the escalator.	Batteries are low or incorrectly installed. The ON/OFF switch is in the "OFF" position. Track not assembled correctly.	Check and replace batteries. Ensure the switch is "ON". Verify all track sections are securely connected.

Problem	Possible Cause	Solution
No music or lights.	Batteries are dead or not installed.	Replace batteries with new ones. Ensure correct polarity.
Ducks get stuck on the slide.	Track sections are not aligned properly.	Re-check all track connections to ensure they are flush and smooth.

## Specifications

- **Product Dimensions:** 27.5 x 24.5 x 5.51 inches
- **Item Weight:** 9.9 ounces
- **Power Source:** 3 x AA Batteries (not included)
- **Material:** Durable Plastic
- **Features:** Music, LED Lights, Automatic Escalator






Image: Product dimensions for the assembled toy.

## Safety Information

- **Choking Hazard:** This toy contains small parts (duck figures) and is not suitable for children under 3 years old. Adult supervision is required during play.
- **Battery Safety:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are only to be charged under adult supervision. Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited.
- **General Use:** Do not modify or disassemble the toy. Use only as intended.

## Warranty and Support

Zerodeko stands behind the quality of its products. For any questions, concerns, or support needs regarding your Small Duck Climbing Stair Toy, please contact Zerodeko customer service through the retailer's platform where you purchased the product. Please retain your proof of purchase for any warranty claims.

