

[Manuals.plus](#) /

> [Siljoy](#) /

> Siljoy 20" Ceiling Fan with Lights User Manual

Siljoy CFL-1102

Siljoy 20" Ceiling Fan with Lights User Manual

Model: CFL-1102 | Brand: Siljoy

1. INTRODUCTION

Thank you for purchasing the Siljoy 20" Ceiling Fan with Lights. This modern LED low-profile ceiling fan is designed to provide optimal airflow and adjustable lighting for various rooms, including bedrooms, living rooms, and kitchens. It features 6 wind speeds, dimmable and color temperature adjustable lighting, a reversible DC motor, and convenient control via remote or smart APP. Please read this manual thoroughly before installation and operation to ensure safe and efficient use of your new ceiling fan.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or personal injury, please follow these basic safety precautions:

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes. Consult a qualified electrician if you are unsure.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not bend the fan blades when installing, balancing the blades, or cleaning the fan.
- Do not insert foreign objects between rotating fan blades.
- This appliance is intended for indoor use only.
- Do not operate the fan if any part is damaged. Contact customer support for assistance.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- Siljoy 20" Ceiling Fan with Lights Unit
- Remote Control
- Mounting Hardware
- User Manual (this document)




Figure 3.1: Key components of the Siljoy Ceiling Fan, including the premium white iron suction top, fashion frame design, and modern 5-piece blades.

4. SETUP & INSTALLATION

4.1 Before You Begin

- Ensure you have all necessary tools (screwdriver, wire strippers, ladder, etc.).
- Confirm the ceiling location is suitable for a flush mount fan and can support the fan's weight (8.38 pounds / 3.81 kg).
- Turn off power at the main circuit breaker.

4.2 Mounting the Fan

The Siljoy ceiling fan is designed for flush mount installation. Follow these steps for secure mounting:

1. Attach the mounting bracket to the ceiling outlet box using the provided mounting hardware. Ensure it is securely fastened.
2. Connect the electrical wires from the ceiling to the fan's wiring according to the color-coded instructions (typically black to black, white to white, ground to ground).
3. Carefully lift the fan unit and align it with the mounting bracket. Secure the fan to the bracket using the designated screws.
4. Ensure all connections are tight and secure before restoring power.



Figure 4.1: The Siljoy 20" Ceiling Fan with Lights installed, showcasing its sleek, low-profile design.

5. OPERATING INSTRUCTIONS

5.1 Remote Control & Smart APP Operation

Your Siljoy ceiling fan can be conveniently controlled using the included remote control or via a smart application on your mobile device. Both methods allow you to adjust fan speed, light brightness, and color temperature.



Figure 5.1: Control options for the Siljoy Ceiling Fan, including mobile app, remote, and wall switch compatibility.

5.2 Light Features: Dimmable & Color Temperature Adjustable

The integrated LED light offers versatile illumination:

- **Dimmable:** Adjust the light brightness from 10% to 100% to suit your preference.
- **Color Temperature:** Seamlessly switch between warm light (3000K), warm white light (4500K), and white light (6000K) to create the desired ambiance.
- **Memory Function:** The fan remembers your last light settings when turned off via remote control.



Warm Light

Warm White Light

White Light



3000K

4500K

6000K




Figure 5.2: Adjustable color temperature and dimming capabilities of the integrated LED light.

5.3 Fan Speed Control

Choose from 6 distinct wind speeds to achieve your ideal comfort level:

- **First Gear:** Gentle Wind
- **Second Gear:** Comfortable Wind
- **Third Gear:** Refreshing Wind

- **Fourth Gear:** Cool Wind
- **Fifth Gear:** Strong Wind
- **Sixth Gear:** Super Cool Wind




Figure 5.3: Six adjustable wind speeds for customized comfort.


5.4 Reversible Motor (Summer/Winter Mode)

The DC reversible frequency conversion motor allows you to change the direction of the fan blades for year-round comfort:

- **Summer Mode (Counter-clockwise):** Creates a downward airflow, producing a cooling effect.

- **Winter Mode (Clockwise):** Creates an upward airflow, circulating warm air trapped near the ceiling.

SUMMER & WINTER DUAL-USE



SUMMER MODE



WINTER MODE

Figure 5.4: Summer and Winter dual-use functionality of the fan.

5.5 Sleep Timer

Utilize the 2-hour sleep timer function to automatically turn off the fan, ensuring undisturbed rest and energy saving.

6. CARE AND MAINTENANCE

Regular maintenance will prolong the life and performance of your ceiling fan:

- **Cleaning:** Wipe the fan and light fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- **Dusting:** Regularly dust the blades and light housing to prevent dust buildup, which can affect performance and light output.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.
- **Bulb Replacement:** The LED light source is integrated and not user-replaceable. If the light fails, contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your Siljoy ceiling fan, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power supply; Loose wiring; Remote control battery low.	Check circuit breaker; Ensure all wires are securely connected; Replace remote control battery.
Light does not turn on.	No power supply; Loose wiring; LED module failure.	Check circuit breaker; Ensure all wires are securely connected; Contact customer support for LED module issues.
Fan makes unusual noise.	Loose screws; Unbalanced blades; Motor issue.	Tighten all screws; Ensure blades are properly installed and balanced; Contact customer support.
Remote control not working.	Battery low/dead; Remote not paired; Obstruction.	Replace battery; Refer to pairing instructions in manual (if applicable); Remove obstructions between remote and fan.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Siljoy
Model Number	CFL-1102
Color	White
Material	Iron, Acrylic
Style	Casual
Light Fixture Form	Ceiling
Room Type	Bedroom
Specific Uses For Product	Home
Indoor/Outdoor Usage	Indoor
Power Source	DC
Installation Type	Flush Mount

Feature	Detail
Special Feature	Manual
Control Method	Remote
Light Source Type	LED
Finish Type	Painted
Shade Material	Acrylic
Number of Light Sources	1
Light Color	adjustable white
Included Components	Mounting Hardware
Lighting Method	LED
Item Weight	3.81 Kilograms (8.38 pounds)
Number of Items	1
Bulb Base	GU10
Controller Type	Remote Control
Switch Type	Remote
Unit Count	1.0 Count
Water Resistance Level	Not Water Resistant
Mounting Type	Flush Mount
Shade Color	Transparent
Fixture Type	Non Removable
Assembly Required	Yes
Size	20"
Recommended Uses For Product	indoor
Product Dimensions	21 x 21 x 6.6 inches
Date First Available	March 27, 2023

9. WARRANTY AND CUSTOMER SUPPORT

Siljoy stands behind the quality of its products. For warranty information, technical support, or any inquiries regarding your ceiling fan, please contact Siljoy customer service through the retailer's platform or visit the official Siljoy website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BZNY5LB4>

More documents and user manuals: <https://manuals.plus/>