SIFENE AMR8824

SiFENE Cold Press Juicer Machine User Manual

Model: AMR8824 | Brand: SIFENE

Introduction

Thank you for choosing the SiFENE Cold Press Juicer Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new juicer. Please read all instructions carefully before first use and retain this manual for future reference.



The SiFENE Cold Press Juicer Machine, featuring its main unit and a wide feeding chute.

Safety Precautions

- Always ensure the juicer is properly assembled and all parts are securely locked before operation.
- Do not operate the juicer with wet hands to prevent electric shock.
- Keep hands and utensils out of the feeding chute during operation. Always use the food pusher provided.
- Unplug the juicer from the power outlet before cleaning, disassembling, or when not in use.
- Do not immerse the motor base in water or any other liquid.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure the power supply voltage matches the rating indicated on the juicer.

Setup and Assembly

Proper assembly is crucial for the juicer's functionality and safety. Follow these steps to set up your SiFENE juicer:

1. Place the motor base on a stable, flat surface.
2. Insert the filter basket into the juicing bowl, ensuring it is seated correctly.
3. Place the auger (spiral screw) into the center of the filter basket.
4. Attach the feeding chute assembly onto the juicing bowl, aligning the marks and twisting until it locks into place.
5. Position the pulp and juice containers under their respective spouts.



The dual mouth design allows for easy feeding of various produce.

Video demonstrating the assembly and initial use of the SiFENE Cold Press Juicer Machine.

Operating Instructions

Your SiFENE juicer is designed for efficient cold pressing, preserving nutrients and flavor.

Preparation of Ingredients:

- Wash all fruits and vegetables thoroughly.
- The 83mm wide chute accommodates whole fruits and vegetables, reducing the need for pre-cutting. For very large items or fibrous vegetables, consider cutting them into smaller pieces to prevent clogging.
- Remove hard pits from fruits (e.g., peaches, plums) and large seeds (e.g., mangoes).



The 83mm wide chute simplifies preparation by allowing whole fruits.

Juicing Process:

1. Ensure the juicer is properly assembled and plugged into a suitable power outlet.
2. Press the 'ON/OFF' button to turn on the juicer.
3. Feed ingredients into the wide chute. For optimal juice extraction, feed ingredients slowly and steadily.
4. Use the food pusher to gently guide ingredients down the chute. Do not force ingredients.
5. The juicer operates at a low speed (60 RPM) to minimize heat buildup and oxidation, preserving nutrients.
6. The 7-stage spiral auger and double-layer filter work to maximize juice yield and separate pulp effectively.



Experience high juice yield with minimal waste.

Operation Modes:

- **FWD Mode:** Standard forward operation for juicing. This low-speed mode ensures minimal heat buildup and oxidation.
- **REV Mode:** Reverse function. If ingredients get clogged, press and hold the 'REV' button for a few seconds to reverse the auger and clear the blockage. Release the button to return to standby, then press 'FWD' to resume juicing.



Control panel with Forward (FWD) and Reverse (REV) modes for efficient juicing and anti-clogging.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your juicer.

1. **Disassembly:** After juicing, turn off and unplug the machine. Disassemble the parts in reverse order of assembly.
2. **Washing:** All removable parts are dishwasher safe. Alternatively, they can be easily rinsed under running water and cleaned with warm, soapy water using the provided cleaning brush.
3. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water.
4. **Drying and Storage:** Ensure all parts are completely dry before reassembling or storing the juicer. Store in a clean, dry place.



Easy to assemble and clean, with most parts being dishwasher safe.

Troubleshooting

Problem	Possible Cause	Solution
Juicer does not turn on or beeps continuously.	Improper assembly; safety lock not engaged.	Ensure all parts are correctly assembled and securely locked into place. Refer to the 'Setup and Assembly' section.
Juicer stops during operation or clogs.	Too much produce fed at once; hard ingredients.	Press the 'REV' button to clear the blockage. Feed ingredients slowly and avoid overfilling. Cut harder ingredients into smaller pieces.
Low juice yield or wet pulp.	Ingredients not suitable for juicing; improper feeding.	Ensure ingredients are fresh. Feed slowly and consistently. Some very soft or fibrous ingredients may naturally yield less juice.

Problem	Possible Cause	Solution
Excessive noise or vibration.	Improper assembly; unstable surface.	Check that all parts are securely assembled. Place the juicer on a stable, flat surface.

Specifications

Feature	Detail
Brand	SIFENE
Model Name	AMR-8824
Product Dimensions	8.66"D x 6.3"W x 21.26"H
Maximum Power	250 Watts (400W Peak)
Voltage	120 Volts
Capacity	800 Milliliters
Number of Speeds	3 (FWD, REV, OFF)
Blade Material	Stainless Steel
Dishwasher Safe Parts	Yes (All removable parts)
Special Features	Easy to Clean, Powerful Motor, Safety Lock, 83mm Wide Chute, 7-Stage Spiral Auger, Double-Layer Filter, Low-Speed Cold Press (60 RPM), Quiet Operation (<60dB)

Warranty and Support

SIFENE is committed to customer satisfaction. We stand behind the quality of our product. For any questions, concerns, or assistance with your juicer, please contact our dedicated customer service team. Refer to your purchase documentation for specific warranty terms and contact information.
Additional resources, including a PDF user manual, may be available on the SIFENE official website or through your retailer.

© 2024 SIFENE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question