

Angrox XRT260

Angrox XRT260 Voice Replacement Remote Control User Manual

Model: XRT260

Brand: Angrox

INTRODUCTION

This user manual provides detailed instructions for the Angrox XRT260 Voice Replacement Remote Control, designed for compatible Vizio Smart TVs. This remote offers a seamless replacement experience with voice control capabilities and dedicated shortcut buttons for popular streaming services. Please note that this remote is specifically for Vizio TVs with voice functionality.

Voice Replacement Remote for Vizio TVs

Vizio V-Series / M-Series / P-Series



Only compatible with Vizio TVs with voice function!

Image: The Angrox XRT260 remote shown alongside various Vizio TV models, emphasizing its role as a voice replacement remote for V-Series, M-Series, and P-Series TVs. A warning states it is only compatible with Vizio TVs that have voice function.

PRODUCT OVERVIEW

The Angrox XRT260 remote control is engineered for ease of use and quick access to your favorite content. It features a comprehensive button layout for navigation, volume control, and direct access to streaming applications.

Product Details



Image: A detailed view of the Angrox XRT260 remote control, with callouts pointing to and describing the function of each button, including Input, Power, Menu, App Launcher, SmartCast Home, WatchFree+, Navigation, OK/Pay/Pause, Voice, Closed Caption, Back, Volume Up/Down, and Mute.

Key Features:

- **Voice Functionality:** Enables voice commands for searching and controlling your TV.
- **Shortcut Buttons:** Direct access to Netflix, Disney+, Prime Video, Pluto, iHeart Radio, Tubi, and Watch Free.
- **Ergonomic Design:** Comfortable to hold and use.
- **Dual Technology:** Supports both infrared and Bluetooth technology for reliable operation.

SETUP AND PAIRING INSTRUCTIONS

Before using your new remote, you will need to install batteries and pair it with your Vizio Smart TV. This remote requires 2 AAA batteries (not included).

Requires 2* AAA Batteries

(Batteries are not included)



Image: The rear view of the Angrox XRT260 remote control with the battery cover removed, clearly indicating the slots for two AAA batteries. Text states "Requires 2* AAA Batteries (Batteries are not included)".

Battery Installation:

1. Open the battery compartment cover on the back of the remote.
2. Insert two (2) AAA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

Pairing with Your TV:

For first-time use, it is recommended to unpair any previous defective or missing remotes from your TV to ensure successful pairing of the new remote.

Pairing Instructions



Image: A visual guide demonstrating the pairing process for the Angrox XRT260 remote. A hand is shown pressing both the Microphone and Mute buttons simultaneously, with an arrow indicating the signal being sent to a Vizio TV. Text explains to press and hold these buttons for 5 seconds until the remote's light flashes.

1. Ensure your Vizio TV is powered on.
2. On the Angrox XRT260 remote, press and hold the "Microphone" button and the "Mute" button simultaneously for 5 seconds.
3. Continue holding until the light on the remote begins to flash. This indicates the remote is in pairing mode.
4. Follow any on-screen prompts on your Vizio TV to complete the pairing process.

OPERATING INSTRUCTIONS

Once paired, your Angrox XRT260 remote is ready for use. It provides intuitive control over your Vizio Smart TV.

Using Voice Commands:

The voice function allows for easier interaction with your smart TV, especially for searching content.

Speak and we shall find



"Fast forward"

"Switch to Xbox"

"Show me family movies"

"Only the Pixar ones"

Image: The Angrox XRT260 remote with its microphone button emphasized, positioned next to a Vizio TV displaying a content search interface. Example voice commands such as "Fast forward," "Switch to Xbox," "Show me family movies," and "Only the Pixar ones" are shown, illustrating the voice search capability.

- Press and hold the "Microphone" button.
- Speak your command clearly into the remote.
- Release the "Microphone" button when finished speaking.

Using Shortcut Buttons:

Quickly launch your favorite streaming applications with a single press.

- Press the dedicated button for Netflix, Disney+, Prime Video, Pluto, iHeart Radio, Tubi, or Watch Free to open the respective application directly.

General Navigation:

- Use the directional pad and "OK" button to navigate menus and select items.
- The "Back" button returns to the previous screen or menu.

- Adjust volume using the "Volume Up" (+) and "Volume Down" (-) buttons.
- Press the "Mute" button to silence the TV audio.
- The "Input" button changes the currently displayed input source.
- The "Home" button (SmartCast Home) launches or returns to the SmartCast Home screen.

COMPATIBILITY

This Angrox XRT260 Voice Replacement Remote Control is compatible with the following Vizio Smart TV series that feature voice functionality:

- V-Series
- M-Series
- P-Series

Specific compatible models include, but are not limited to: V655-J04, V655-J09, V705-J03, V755-J04, V435-J01, V505-J01, V505-J09, V555-J01, V585-J01, V706-J03, V756-J03, V756x-J03, V505C-J09, V705-J01, V705x-J03, M55Q7-J01, M58Q7-J01, M65Q7-J01, M70Q7-J03, M75Q7-J03, M43Q6-J04, M50Q6-J01, M55Q6-J01, M65Q6-J09, M70Q6-J03, M75Q6-J03, M50Q7-J01, P65Q9-J01, P75Q9-J01, M55Q7J01, M58Q7J01, M65Q7J01, M70Q7J03, M75Q7J03, M43Q6J04, M50Q6J01, M55Q6J01, M65Q6J09, M70Q6J03, M75Q6J03, M50Q7J01, P65Q9J01, P75Q9J01.

Important Note: This remote will only work with Vizio TVs that have built-in voice functionality. If your Vizio TV does not support voice commands, this remote's voice feature will not function.

TROUBLESHOOTING

If you encounter issues with your Angrox XRT260 remote, please refer to the following common solutions:

- **Remote Not Responding:**
 - Ensure batteries are correctly installed and are not depleted. Replace with new AAA batteries if necessary.
 - Verify line of sight between the remote and the TV's infrared receiver. Obstructions can block the signal.
 - Re-pair the remote with your TV following the "Pairing with Your TV" instructions.
- **Voice Function Not Working:**
 - Confirm that your Vizio TV model supports voice functionality. This remote's voice feature will not work on TVs without this capability.
 - Ensure the remote is properly paired via Bluetooth, as voice commands typically rely on Bluetooth connectivity.
 - Speak clearly and hold the "Microphone" button throughout your command.
- **Limited Range:**
 - The remote supports infrared and Bluetooth. For optimal performance, especially with voice commands, ensure Bluetooth pairing is successful.
 - The effective range is approximately 10-12 meters (33-39 feet). Ensure you are within this range.

SPECIFICATIONS

Feature	Detail
Model	XRT260
Brand	Angrox
Compatible Devices	Vizio Smart TVs (V-Series, M-Series, P-Series with voice function)
Connectivity Technology	Infrared, Bluetooth
Power Source	2 x AAA Batteries (not included)
Color	Black
Special Feature	Ergonomic, Voice Control, Shortcut Buttons
Item Weight	2.89 ounces
Package Dimensions	8.46 x 2.48 x 1.22 inches

MAINTENANCE

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:


- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or if the pairing light does not flash during pairing attempts. Always replace both batteries at the same time.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.
- **Handling:** Avoid dropping the remote or exposing it to excessive force, which can damage internal components.

WARRANTY AND SUPPORT

This product is a replacement remote control. Please note that a user manual and batteries are not included in the package. For product support, please refer to the product listing page where this item was purchased or contact the manufacturer, Angrox, directly through their official channels.

Information regarding specific warranty terms is typically provided by the seller at the point of purchase. Please retain your purchase receipt as proof of purchase for any warranty claims.

Related Documents - XRT260

	<p>VIZIO XRT260 Remote Control - Features and Support</p> <p>Detailed overview of the VIZIO XRT260 remote control, including button functions, mobile app integration via QR code, support contact, model number, FCC ID, and battery information.</p>
---	--

User Manual

<p>Note: When you get the service first time, please remember to do urgent actions. Only Urgent means success for "Panic mode" and all services follow. Then you can Plan a new service successfully, please follow below steps:</p> <ul style="list-style-type: none">- Press on the red menu button below the key to display.- Press on the TV.- Select the service key.- Select the TV display.- System runs, Press OK key, and select done from the "Panic mode".- Press OK key.- Press OK key.- Press OK key.- Select Urgent, Press OK key.- Select Urgent, Press OK key. <p>If you confirm to Urgent, then waiting to see Urgent complete on the TV.</p>	<p>Then follow below Planning new remote actions:</p> <ul style="list-style-type: none">- Press and hold the microphone key continuously about 3 seconds, the TV displays its Plan remote.- Select Plan Remote key, and enter the Planning mode. Then follow the TV display Planning mode. Press and repeat both microphones.- Slide keys about 3-8 seconds, until the remote light flash twice, then the TV displays Planning the system. First screen, please follow above Planning method again, thanks.
---	---

1

2

[User Manual for SHENZHEN YUEHAI ELECTRONIC COMMERCE LIMITED XRT260-V1V2V3 Voice Remote](#)

This user manual provides instructions for pairing and replacing batteries in the SHENZHEN YUEHAI ELECTRONIC COMMERCE LIMITED XRT260-V1V2V3 voice remote. It also includes FCC compliance information.