

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RESHABLE](#) /

› [RESHABLE Salon Station User Manual \(Model B0BZP6GWN3\)](#)

RESHABLE B0BZP6GWN3

RESHABLE Salon Station User Manual

Brand: RESHABLE | Model: B0BZP6GWN3

INTRODUCTION

Thank you for choosing the RESHABLE Salon Station. This manual provides essential information for the safe assembly, operation, and maintenance of your new salon equipment. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

Ensure the salon station is securely mounted to the wall to prevent tip-over. Always follow the assembly instructions provided in the manual. Keep the area around the station clear of obstacles to prevent accidents. Do not place heavy objects on the tabletop or shelves to avoid overloading and potential tip-over. Keep the station away from heat sources to prevent damage to the materials and potential fire hazards. Always unplug the station when not in use.

PRODUCT FEATURES

- **Wall Mount Design:** Offers ample storage and classic elegance, suitable for salon studios, barber shops, tattoo shops, or home use.
- **Sturdy Construction:** Made from premium, eco-friendly particleboard, ensuring long-term use. The smooth surface is waterproof and easy to clean.
- **Large Storage Capacity:** Features two shelves with a glass door for visible and dustproof storage, a lockable drawer, a large bottom cabinet, and two side cabinets.
- **Integrated Tool Holders:** Tabletop includes six built-in heat-resistant tool holders in two sizes, ideal for hairdryers and curling irons. The two side cabinets with tool holders are removable for flexible usage.
- **Easy Assembly:** All parts and hardware are well-packed and pre-labeled for straightforward setup.

COMPONENTS LIST

Before assembly, ensure all components and hardware are present and undamaged. Refer to the included parts diagram for identification.

- Main particleboard panels (various sizes for top, bottom, sides, shelves)
- Glass door panel
- Drawer components (front, back, sides, bottom)
- Drawer slides

- Tool holder inserts
- Hinges for doors
- Door handles
- Lock and keys for drawer
- Assembly hardware (screws, dowels, cam locks, wall mounting brackets)



Figure 1: Detailed view of the salon station's drawer, cabinet, and overall dimensions. This image shows the dimensions of the drawer (9.84" x 11.26" x 2.76"), the upper cabinet (12.8" x 11.14" x 22.99"), and the lower cabinet (11.81" x 14.57" x 22.56"), along with the overall station dimensions (23.03"W x 15.75"D x 66.93"H).

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with certain steps, especially during wall mounting.

1. **Prepare Components:** Unpack all parts and lay them out on a clean, soft surface to prevent scratches. Verify all components against the parts list.
2. **Assemble Base Unit:** Attach the side panels to the bottom panel using the provided hardware (screws and dowels). Ensure all connections are secure.
3. **Install Drawer Slides:** Secure the drawer slides to the inner sides of the main cabinet structure.

4. **Construct Drawer:** Assemble the drawer box using the drawer front, back, side panels, and bottom. Attach the remaining drawer slides to the drawer box. Install the lock mechanism and handle on the drawer front.
5. **Assemble Upper Cabinet:** Attach the side panels to the top and bottom panels of the upper cabinet.
6. **Attach Glass Door:** Install hinges onto the glass door panel and then attach the door to the upper cabinet. Ensure the door opens and closes smoothly.
7. **Assemble Tool Holder Sections:** Connect the individual panels that form the tool holder sections. Insert the heat-resistant rings into the designated holes.
8. **Integrate Sections:** Attach the assembled tool holder sections to the main cabinet structure. Secure the upper cabinet to the top of the main structure.
9. **Wall Mounting:** Identify a suitable wall location. Use appropriate wall anchors and screws to securely mount the salon station to the wall. Ensure it is level and stable.
10. **Final Checks:** Test all drawers and doors for smooth operation. Ensure all connections are tight and the unit is stable.

Your browser does not support the video tag.

Video 1: Detailed assembly instructions for the RESHABLE Salon Station. This video demonstrates each step of the assembly process, from preparing components to final installation, including attaching drawer slides, assembling cabinets, and installing the glass door.



Figure 2: Close-up view of the heat-resistant tool holders integrated into the tabletop, designed for various hair styling tools like hairdryers and curling irons.

OPERATING INSTRUCTIONS

- **Using Tool Holders:** Place hot styling tools such as hairdryers and curling irons into the heat-resistant rings immediately after use for safe storage.
- **Accessing Storage:** Utilize the lockable drawer for securing valuable items. The glass-door cabinet is suitable for displaying and storing frequently used products, while the lower cabinet provides ample space for larger supplies.
- **Adjusting Side Cabinets:** The two side cabinets with tool holders are removable. You can choose to install one or both based on your specific needs and workspace configuration.



Figure 3: The lockable drawer and spacious lower cabinet provide secure and organized storage for various salon essentials.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the particleboard. The waterproof surface helps protect against moisture.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten as necessary to maintain stability.
- **Glass Care:** Clean the glass door with a standard glass cleaner and a lint-free cloth.

Premium Material

Made of durable particle board with water/scratch proof surfaces




Figure 4: The station is constructed from durable, water-resistant, and scratch-proof particleboard for easy maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Station is wobbly after assembly.	Loose connections or improper wall mounting.	Ensure all screws and fasteners are tightened. Verify wall mounting is secure and level.
Drawer does not slide smoothly.	Drawer slides misaligned or debris in tracks.	Check alignment of drawer slides. Clean tracks of any dust or obstructions. Apply a silicone-based lubricant if necessary.
Door does not close properly.	Hinges are misaligned or loose.	Adjust the hinges to ensure proper alignment. Tighten hinge screws.

SPECIFICATIONS

- **Brand:** RESHABLE
- **Model:** B0BZP6GWN3
- **Color:** Black
- **Material:** Engineered Wood, Glass, Iron

- **Product Dimensions:** 15.75"D x 23.03"W x 66.93"H
- **Item Weight:** 44 Pounds
- **Weight Limit:** 22 Pounds (for shelves/drawer)
- **Mounting Type:** Wall Mount
- **Number of Shelves:** 2 (behind glass door)
- **Number of Tool Holders:** 6 (integrated into removable side cabinets)
- **Special Features:** Durable, Waterproof, Lockable Drawer

WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product functionality, please contact RESHABLE customer support. Specific warranty details may vary; please refer to your purchase documentation or contact the seller for more information.