

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ONECAM](#) /

› [ONECAM 18 Gallon Storage Tote Box Instruction Manual](#)

ONECAM 18 Gallon Storage Tote Box

ONECAM 18 Gallon Storage Tote Box Instruction Manual

Model: 18 Gallon Storage Tote Box

1. INTRODUCTION

Thank you for choosing the ONECAM 18 Gallon Storage Tote Box. This manual provides essential information for the proper use, care, and maintenance of your new storage containers. Designed for versatility and durability, these totes are ideal for organizing various household items, from clothing and toys to craft supplies and seasonal decorations. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.



Image 1.1: A single ONECAM 18 Gallon Storage Tote Box with its lid.

2. PRODUCT FEATURES

The ONECAM 18 Gallon Storage Tote Box offers a range of features designed for efficient and reliable storage:

- **Generous Capacity:** Each tote provides an 18-gallon storage volume, suitable for a variety of items.
- **Durable Construction:** Made from robust, BPA-free and phthalate-free plastic for safe and long-lasting use.
- **Secure Snap Lid:** The lid snaps firmly to the base, ensuring contents remain contained and protected from dust and moisture.
- **Stackable Design:** Deep recessed lid allows multiple totes to stack securely, maximizing vertical storage space.
- **Nestable When Empty:** Totes can nest inside each other when not in use, saving space.
- **Integrated Handles:** Contoured end panels with textured, in-molded handles provide a comfortable and secure grip for lifting and carrying.
- **Space-Efficient Shape:** Squared-off design optimizes storage in various spaces.

3. SETUP

The ONECAM 18 Gallon Storage Tote Box requires no assembly. It is ready for immediate use upon unpacking.

1. Remove all packaging materials from the tote and lid.
2. Inspect the tote and lid for any signs of damage from shipping. If damage is found, please contact customer support.
3. Wipe down the interior and exterior with a damp cloth before first use, if desired.

4. OPERATING INSTRUCTIONS

4.1 Filling the Tote

- Place items neatly inside the tote.
- Avoid overfilling the tote beyond its capacity or above the rim, as this may prevent the lid from closing properly and could damage the tote.
- For heavy items, distribute weight evenly to maintain balance.

4.2 Securing the Lid

- Align the lid with the top edge of the tote.
- Press down firmly on all four sides of the lid until you hear and feel it snap securely into place. This ensures contents are protected.



Image 4.1: Demonstrating how to secure the lid by pressing down on the edge.

4.3 Stacking Totes

- The deep recessed surface of the lid is designed for stable stacking.
- Always place heavier totes at the bottom of a stack to maintain stability.
- Do not stack totes too high, especially if they contain heavy items, to prevent tipping.



Image 4.2: Two ONECAM storage totes demonstrating the stackable design.

4.4 Carrying the Tote

- Use the integrated handles on the short sides of the tote for comfortable lifting and carrying.
- If the tote is heavy, use both hands and lift with your legs, not your back, to prevent injury.

5. MAINTENANCE

5.1 Cleaning

- To clean the tote, wipe with a damp cloth.
- For stubborn dirt, a mild soap solution can be used. Rinse thoroughly and dry completely before storing items.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the plastic surface.

5.2 Storage

- Store totes in a cool, dry place away from direct sunlight or extreme temperatures to prevent material degradation.
- When empty, totes can be nested to save space.

6. TROUBLESHOOTING

6.1 Lid Not Closing Properly

- **Check for Obstructions:** Ensure no items are protruding above the rim of the tote, preventing the lid from seating correctly.
- **Align Lid Correctly:** Make sure the lid is aligned squarely with the tote's base before pressing down.

6.2 Tote Damage

- **Cracks or Breaks:** Avoid dropping the tote, especially when full, or applying excessive force. While durable, plastic can crack under extreme impact or stress.
- **Discoloration:** Prolonged exposure to direct sunlight or harsh chemicals may cause discoloration. Store appropriately.

7. SPECIFICATIONS

Specification	Detail
Brand	ONECAM
Model	18 Gallon Storage Tote Box
Capacity	18 Gallons (approx. 68 liters)
Material	Plastic (BPA-free, phthalate-free)
Outside Dimensions (L x W x H)	23 1/8" x 18 1/8" x 14 7/8" (58.7 cm x 46 cm x 37.8 cm)
Interior Bottom Dimensions (L x W x H)	16 3/4" x 13 3/4" x 14 3/8"
Closure Type	Snap
Special Features	Stackable, Nestable, Durable, Lightweight, Portable, Shatterproof
Color	Fuchsia Burst
Quantity	Set of 8



Image 7.1: Detailed dimensions of the ONECAM 18 Gallon Storage Tote Box.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ONECAM 18 Gallon Storage Tote Box, please refer to the retailer's return policy or contact ONECAM customer service directly through their official website or the platform where the product was purchased. Please have your purchase details and product information (ASIN: B0BZPC389N) ready when contacting support.