

[Manuals.plus](#) /

› [VG VOGCREST](#) /

› Rechargeable Facial Hair Remover for Women: 2 in 1 Electric Eyebrow and Facial Hair Remover - Suitable for Middle-aged Women's Eyebrow, Chin, and Cheek Trimming - with Built-in LED Light (White)

VG VOGCREST VG-103

Rechargeable Facial Hair Remover for Women: 2 in 1 Electric Eyebrow and Facial Hair Remover

Model: VG-103 | Brand: VG VOGCREST

PRODUCT OVERVIEW

The VG VOGCREST 2-in-1 Electric Eyebrow and Facial Hair Remover is designed for efficient and gentle hair removal on the face and eyebrows. This compact and portable device features interchangeable heads for versatile grooming, a built-in LED light for precision, and convenient Type-C charging.



Image: The VG VOGCREST 2-in-1 Facial Hair Remover, showing both the facial hair removal head and the eyebrow trimming head, alongside its Type-C charging cable.



2 IN 1 DESIGN




Image: Demonstrates the 2-in-1 design, with one image showing the device used for eyebrow trimming and another for facial hair removal on the chin and cheeks.

SETUP

1. **Initial Charge:** Before first use, fully charge the device using the provided Type-C charging cable. Connect the cable to the device and a suitable USB power source. The built-in LED light may indicate charging status.
2. **Select Head:** Choose the appropriate head for your grooming needs:

- **Facial Hair Removal Head:** For larger areas like cheeks, chin, neck, and around the lip.
- **Eyebrow Trimming Head:** For precise shaping of eyebrows.

3. **Attach Head:** Gently twist or click the desired head onto the device until it is securely in place. Ensure it is properly assembled before use.

LONG LASTING



1 Time Charge = 20 Days Usage



Type C Charging Universal & Fast!



*Tips "Charge on time for a smoother hair removal experience —no pinching, high efficiency!"

Image: Illustrates the Type-C charging port and highlights the device's long-lasting battery life, indicating 20 days of usage on a single charge.

1. **Power On:** Slide the power switch to the "ON" position. The built-in LED light will illuminate to help you see fine hairs.
2. **Hair Removal:**
 - For facial hair, gently press the device against your skin and move it in small, circular motions.
 - For eyebrows, use the precision head and carefully shape the desired area.
 - Move the device slowly and steadily for effective and pain-free hair removal.
3. **Optimal Results:** For a smoother experience, ensure the device is adequately charged. Using a rotating motion can enhance hair removal effectiveness.
4. **Power Off:** Once finished, slide the power switch to the "OFF" position.

EFFORTLESSLY REMOVES FINE HAIR



LED Light



Compact Design



*Tips

1. Use the remover **rotatly** for a better result.
2. **Charge on time** for a smoother hair removal experience —no pinching, high efficiency!

Image: A close-up view of the device in action, highlighting the built-in LED light that illuminates the area for precise removal of fine hairs.

MAINTENANCE

Regular cleaning ensures optimal performance and hygiene of your hair remover.

1. **Cleaning the Head:** After each use, twist off the hair removal head. Use the provided small cleaning brush to remove any trapped hairs from the blades and the interior of the head.

- 2. **Wipe Down:** Wipe the body of the device with a clean, dry cloth. Do not rinse the main body under water.
- 3. **Reassemble:** Once clean and dry, reattach the head securely.
- 4. **Storage:** Store the device in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on.	Low battery or not charged.	Ensure the device is fully charged using the Type-C cable.
Poor hair removal performance.	Blades are clogged with hair or device needs charging.	Clean the hair removal head thoroughly with the brush. Recharge the device if necessary.
Device feels rough on skin or pulls hair.	Insufficient charge or improper usage.	Ensure the device is fully charged. Use gentle, circular motions. Do not press too hard.

SAFETY INFORMATION

- Always keep the device away from water sources.
- Avoid using it on infants or children.
- Be cautious when using the rotating blades to prevent injury.
- Always follow the recommended cleaning and maintenance procedures.
- Do not use the device if the blades are damaged or dull.

SPECIFICATIONS

- **Product Dimensions:** 4 x 0.6 x 1 inches
- **Item Weight:** 3.84 ounces (0.11 Kilograms)
- **Model Number:** VG-103
- **Power Source:** Rechargeable (Type-C)
- **Battery:** 1 CR5 battery required (internal, rechargeable)
- **Color:** White
- **Hair Type Compatibility:** All
- **Manufacturer:** VGVOGCREST

WARRANTY AND SUPPORT

VG VOGCREST offers a hassle-free 60-day return policy and a lifetime guarantee for any product defects. For support or warranty claims, please contact the manufacturer directly through their official channels.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a dietary supplement.

