

[Manuals.plus](#) /

› [Rubbermaid](#) /

› Rubbermaid Mini Resin Outdoor Deck Box & Food Service Utility Scoop User Manual

Rubbermaid Mini Resin Weather Resistant Outdoor Deck Box (16x14x21), Food Service Utility Scoop (64-Ounce)

Rubbermaid Mini Resin Outdoor Deck Box & Food Service Utility Scoop User Manual

Models: Mini Resin Weather Resistant Outdoor Deck Box (16" x 14" x 21"), Commercial Products Food Service Utility Scoop (64-Ounce)

INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of the Rubbermaid Mini Resin Weather Resistant Outdoor Deck Box and the Rubbermaid Commercial Products Food Service Utility Scoop. Please read these instructions carefully before using the products to ensure proper function and longevity.

RUBBERMAID MINI RESIN WEATHER RESISTANT OUTDOOR DECK BOX

Product Description

The Rubbermaid Mini Resin Weather Resistant Outdoor Deck Box is designed for year-round protection of outdoor items. Its compact size makes it suitable for small spaces, offering 2.6 cubic feet of storage. The deck box features double-walled construction for durability and resistance against leaks, dents, rot, and rust. It can also serve as an end table.

Features

- **Dimensions:** 16" W x 14" D x 21" H
- **Capacity:** 2.6 cubic feet
- **Material:** Durable resin with double-walled construction
- **Weather Resistance:** Leak, dent, rot, and rust resistant; resists cracking in cold temperatures.
- **Maintenance:** Maintenance-free, unlike wood storage bins.
- **Versatility:** Can be used for storing grill accessories, small garden tools, gloves, or as an end table.

Setup and Assembly

The Rubbermaid Mini Resin Outdoor Deck Box is designed for easy assembly. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (if included)

with physical product).

2. **Assemble Base:** Secure the base panel.
3. **Attach Side Panels:** Connect the side panels to the base, ensuring they lock securely into place.
4. **Install Lid:** Attach the lid to the assembled body. Ensure hinges are properly aligned and secured.
5. **Final Check:** Confirm all connections are tight and the lid opens and closes smoothly.



Image 1: The Rubbermaid Mini Resin Outdoor Deck Box in its closed state, mocha color.



Image 2: The Rubbermaid Mini Resin Outdoor Deck Box with its lid open, revealing the interior storage space.



Image 3: The Rubbermaid Mini Resin Outdoor Deck Box with its dimensions (16" W x 14" D x 21" H) clearly labeled.

Operating Instructions

To use the deck box, simply lift the lid to access the storage compartment. Place items such as garden tools, cushions, or grill accessories inside. Close the lid firmly to ensure weather protection.

Maintenance

- **Cleaning:** Wipe down with a damp cloth and mild soap as needed. Rinse thoroughly.
- **Inspection:** Periodically check the lid and body for any signs of damage or wear.
- **Storage:** Ensure the lid is properly closed when not in use to protect contents from weather.

Specifications (Deck Box)

Attribute	Detail
-----------	--------

Brand	Rubbermaid
Model	Mini Resin Weather Resistant Outdoor Deck Box
Dimensions (L x W x H)	16" x 14" x 21"
Capacity	2.6 cubic feet
Material	Resin
Color	Mocha
Special Features	Double-walled, Weather Resistant, Leak-proof, Dent-proof, Rot-proof, Rust-proof

RUBBERMAID COMMERCIAL PRODUCTS FOOD SERVICE UTILITY SCOOP

Product Description

The Rubbermaid Commercial Products Food Service Utility Scoop is a durable, 64-ounce scoop designed for various food service applications. Made from clear polycarbonate, it is break-resistant, resists oil and grease, and can withstand high temperatures. Its smooth surface ensures easy cleaning.

Features

- **Capacity:** 64-Ounce
- **Material:** Clear Polycarbonate
- **Durability:** Break-resistant, resists oil and grease.
- **Temperature Resistance:** Holds up to 500°F (260°C).
- **Cleaning:** Smooth surface, commercial dishwasher safe.
- **Handle:** Convenient handle for a steady grip.
- **Origin:** Made in the USA.

Operating Instructions

Use the scoop to transfer ice, ingredients, or other bulk items. Hold the convenient handle for a steady grip and scoop the desired quantity. Ensure the scoop is clean before and after each use, especially when handling food items.



Image 4: The Rubbermaid Commercial Products Food Service Utility Scoop, shown empty.



Image 5: The Rubbermaid Commercial Products Food Service Utility Scoop being used to scoop black-eyed peas.

Maintenance

- **Cleaning:** The scoop is commercial dishwasher safe. For manual cleaning, wash with warm water and mild detergent.
- **Sanitization:** For food service applications, ensure proper sanitization procedures are followed after cleaning.
- **Storage:** Store in a clean, dry place when not in use.

Specifications (Utility Scoop)

Attribute	Detail
Brand	Rubbermaid Commercial Products
Model	Food Service Utility Scoop
Capacity	64-Ounce
Material	Clear Polycarbonate
Color	White
Temperature Range	Up to 500°F (260°C)

TROUBLESHOOTING

This section addresses common issues you might encounter with your Rubbermaid products.

Deck Box Issues

- **Lid not closing properly:**
Ensure no items are obstructing the lid's path. Check hinges for damage or misalignment. Re-assemble if necessary, ensuring all panels are securely connected.
- **Water inside the box:**
Verify the lid is fully closed and sealed. Check for any cracks or damage to the resin material. While weather-resistant, extreme conditions or improper closure can allow moisture in.

Utility Scoop Issues

- **Scoop appears cloudy or stained:**
Ensure thorough cleaning after each use, especially with oily or colored ingredients. Use appropriate commercial dishwasher detergents or hand wash with warm, soapy water. Polycarbonate can sometimes develop minor scratches over time with heavy use.

WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the documentation included with your purchase or visit the official Rubbermaid website. Keep your proof of purchase for warranty claims.

Contact Information:

Website: www.rubbermaid.com

Customer Service: Refer to the website for regional contact details.

© 2023 Rubbermaid. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question