ENUOTEK LB-W001-06

ENUOTEK LB-W001-06 Wall-Mounted LED Reading Light User Manual

Model: LB-W001-06

1. Introduction

Thank you for choosing the ENUOTEK LB-W001-06 Wall-Mounted LED Reading Light. This product is designed to provide versatile and efficient lighting for your reading needs, featuring a flexible gooseneck, adjustable brightness, and a convenient USB charging port. Please read this manual carefully before installation and use to ensure proper operation and safety.

Key Features:

- **Versatile Lighting Options:** 34.5 cm flexible gooseneck and sensitive touch switch for adjustable light direction and 4 brightness levels.
- **Space-Saving Design:** Wall-mounted to save space on nightstands.
- **Modern COB-LED Technology:** 4W power consumption, 240 lumens, 4000K neutral white light.
- **Convenient USB Charging Port:** Integrated 5V 2A USB port for charging mobile phones and other devices.
- **Easy Installation:** Two mounting options (adhesive tape or screws) for quick setup.

2. Safety Instructions

- Ensure the power supply is disconnected before installation or maintenance.
- This product is for indoor use only. Do not expose to moisture or extreme temperatures.
- Do not attempt to disassemble or modify the light. This will void the warranty and may cause damage or injury.
- Keep out of reach of children.
- Use only with the provided power adapter.
- **USB Charging Caution:** While the USB port provides 5V 2A output, avoid charging high-power devices for extended periods without supervision, as this may cause the unit to overheat. If the unit becomes excessively hot, discontinue use of the USB charging function immediately.

3. Package Contents

Verify that all components are present in the package:

- 1 x ENUOTEK Wall-Mounted LED Reading Light
- 1 x Mounting Plate
- 1 x Double-Sided Adhesive Tape
- 2 x Metal Screws
- 2 x Expansion Plugs
- 1 x User Manual

4. Setup and Installation

The ENUOTEK LB-W001-06 offers two installation methods: adhesive mounting or screw mounting.

Method 1: Adhesive Mounting (Recommended for smooth surfaces)

1. Clean the desired wall or headboard surface thoroughly to ensure it is dry and free of dust or grease.
2. Peel off the protective film from one side of the double-sided adhesive tape and apply it firmly to the back of the mounting plate.
3. Peel off the remaining protective film from the adhesive tape.
4. Press the mounting plate firmly onto the cleaned surface for at least 30 seconds.
5. Slide the reading light onto the mounting plate until it clicks securely into place.

Method 2: Screw Mounting (Recommended for uneven or painted surfaces)

1. Choose a suitable location on the wall or headboard.
2. Place the mounting plate against the surface and mark the positions for the two screw holes.
3. Drill two holes at the marked positions. Insert the expansion plugs into the drilled holes.
4. Align the mounting plate with the holes and secure it to the wall using the two metal screws.
5. Slide the reading light onto the mounting plate until it clicks securely into place.

Connect the power adapter to a suitable electrical outlet. The 1.8-meter power cable allows for flexible placement.




Figure 1: Installation methods (screw or adhesive).

5. Operating Instructions

Power On/Off and Brightness Adjustment:

1. **Power On/Off:** Touch the sensitive power button on the base of the lamp to turn the light on or off.
2. **Brightness Levels:** With the light on, repeatedly touch the power button to cycle through the 4 available brightness levels: 15%, 35%, 70%, and 100%. The lamp has a memory function that recalls the last brightness setting used.



Figure 2: Touch control and brightness levels.

Gooseneck Adjustment:

The flexible 34.5 cm gooseneck allows you to direct the light precisely where needed. Gently bend the gooseneck to adjust the angle and position of the light head.



Figure 3: Flexible gooseneck for directional lighting.

Using the USB Charging Port:

The lamp base includes a 5V 2A USB charging port. Connect your mobile phone, tablet, or other USB-powered device to this port for convenient charging. Ensure your device is compatible with 5V 2A charging.



Figure 4: USB 5V 2A charging port.

6. Maintenance

- Before cleaning, ensure the light is unplugged from the power outlet.
- Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- Do not immerse the lamp in water or spray liquids directly onto it.
- Regularly check the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	1. Power adapter not plugged in. 2. Power outlet is not active. 3. Faulty power adapter or cable.	1. Ensure the power adapter is securely plugged into both the lamp and the wall outlet. 2. Test the outlet with another device. 3. Contact customer support for assistance.
Light flickers or is dim.	1. Loose connection. 2. Incorrect brightness setting.	1. Check all connections. 2. Cycle through brightness levels using the touch switch.
USB charging port not working.	1. Device not compatible. 2. Cable issue. 3. Overheating protection activated.	1. Ensure your device is compatible with 5V 2A charging. 2. Try a different USB cable. 3. Unplug the lamp, let it cool down, and then try again. Avoid charging high-power devices for extended periods.
Lamp base becomes hot during USB charging.	High power draw from connected device.	This can occur with certain devices. If the heat is excessive or causes discomfort, discontinue charging the device immediately. Consider using a dedicated wall charger for high-power devices.

8. Specifications

Feature	Specification
Model Number	LB-W001-06
Dimensions (L x W x H)	6 x 2.4 x 50.7 cm (2.4 x 0.9 x 20.0 inches)

Feature	Specification
Weight	388.39 grams (13.7 ounces)
Material	Plastic (Body), Aluminum (Shade)
Color	Black
Light Source Type	LED (COB)
Power Consumption	4 Watts
Luminous Flux	240 Lumens
Color Temperature	4000 Kelvin (Neutral White)
Voltage	230 Volts
Control Method	Touch
USB Output	5V 2A
Power Source	Corded Electric
Mounting Type	Wall Mount
Energy Efficiency Class	G




Figure 5: Product dimensions.

9. Warranty and Support

This ENUOTEK product comes with a**2-year quality warranty** provided by the seller. If you encounter any issues or have questions regarding your product, please contact the seller or ENUOTEK customer support for assistance.

For further support, please refer to the contact information provided at the point of purchase or visit the official ENUOTEK website.

© 2024 ENUOTEK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question