



Manuals.plus /

- › Allewie /
- › Allewie Queen Size Lift Up Storage Bed Instruction Manual

Allewie AK-KBMV0002

Allewie Queen Size Lift Up Storage Bed Instruction Manual

Model: AK-KBMV0002 | Brand: Allewie

1. PRODUCT OVERVIEW

The Allewie Queen Size Lift Up Storage Bed is designed to offer both comfort and practical storage solutions. Featuring a button-tufted headboard with wingback design, this bed frame incorporates a hydraulic lift mechanism, providing ample under-bed storage without the need for a box spring. Its sturdy construction ensures stability and durability.



Image: The Allewie Queen Size Lift Up Storage Bed in a bedroom setting, showcasing its design and functionality.

Key Features:

- **Space-Saving Storage:** Integrated lift-up storage provides significant space for bedding, clothing, and other items.
- **Easy to Use:** Hydraulic gas lift mechanism allows for smooth and effortless access to the storage compartment.
- **Elegant Design:** High wingback, button-tufted headboard adds a sophisticated aesthetic to any bedroom.
- **No Box Spring Needed:** Solid wood slats offer strong support for your mattress directly, eliminating the need for a box spring.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Carefully operate the lift-up storage feature to avoid injury.
- Do not exceed the maximum weight recommendation of 800 pounds.

- Follow assembly instructions carefully to ensure stability and prevent collapse.
- Keep children and pets away from the bed frame during assembly and when operating the lift mechanism.
- Ensure all bolts and screws are securely tightened before use and periodically check for looseness.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. All parts are efficiently packaged in one box.

- Bed Frame components
- Headboard
- Slats
- Assembly Hardware (screws, bolts, washers, Allen wrench)
- Instruction Manual



Image: The disassembled bed frame components, including the headboard, side rails, and wooden slats.

4. SPECIFICATIONS

Attribute	Detail
Size	Queen
Product Dimensions	80.7"L x 60.6"W x 42.1"H
Special Feature	Lift Up Storage
Color	Beige
Finish Type	Upholstered
Compatible Mattress Size	Queen
Assembly Required	Yes
Item Weight	117 pounds
Max Weight Capacity	800 pounds
Underbed Storage Height	10.8 inches

QUEEN
SIZE

L * W * H : 84 * 64 * 42.1 in.

Highest Storage Height (slats to floor): 10.8 in.

Max Capacity: 800 lbs



Image: Detailed dimensions of the Queen size bed frame, including length, width, height, and storage height.

5. SETUP AND ASSEMBLY

Assembly of the Allewie Queen Size Lift Up Storage Bed is required. Please follow the detailed instruction book included in the package. It is recommended to have two people for assembly due to the size and weight of some components.

General Assembly Steps:

1. Unpack all components and verify against the parts list in the instruction manual.
2. Assemble the headboard and footboard sections according to the diagrams.
3. Attach the side rails to the headboard and footboard, ensuring all connections are secure.
4. Install the central support beam and legs.
5. Attach the hydraulic lift mechanism to the frame.
6. Secure the wooden slats to the bed frame. The unique buckle design ensures easy and quick assembly of the slats.
7. Place your mattress directly onto the slats; a box spring is not required.

Note: While the provided tools are sufficient, using your own tools (e.g., a ratchet with appropriate bits) may expedite the assembly process.

Detail Matters



Hand Lifting
Effortless and Convenient



Protective Devices
Stopping and Anti-Falling



Unique Buckles
Easy and Quick Assembly



Image: Details illustrating the hand lifting mechanism, protective devices for safety, and the unique buckles for slat attachment, aiding in assembly.

No relevant assembly videos from the seller were found in the provided product data.

6. OPERATING INSTRUCTIONS

Using the Lift-Up Storage:

The Allewie bed features a hydraulic lift system for easy access to the under-bed storage. This mechanism is designed for smooth and effortless operation.

1. **To Lift:** Stand at the foot or side of the bed. Grasp the frame firmly and lift upwards. The hydraulic pistons will assist in raising the mattress platform smoothly and hold it in the open position.
2. **To Lower:** Gently push the mattress platform downwards. The hydraulic pistons will control the descent, allowing it to close slowly and safely.

Important: Ensure there are no obstructions or body parts in the path of the lifting mechanism when operating. The maximum lifting weight capacity for the mattress and bedding is approximately 110 lbs. The overall maximum weight capacity for the bed (including mattress, occupants, and stored items) is 800 lbs.



Image: The bed with the mattress platform lifted, showcasing the spacious storage area underneath.

MAX LIFTING WEIGHT CAPACITY



**Underbed
Storage Height**

Image: A visual representation indicating the maximum lifting weight capacity of the mattress platform.



Get Underneath Storage Space Used!



4+
Luggage Cases



10+
Storage Boxes



10+
Quilts



20+
Shoes

Image: An example of the under-bed storage space being utilized to store luggage, storage boxes, quilts, and shoes.

7. MAINTENANCE

Proper maintenance will extend the life and appearance of your Allewie bed frame.

- **Cleaning:** The upholstered fabric should be dry cleaned only. For minor spills, gently blot with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Hydraulic Mechanism:** The hydraulic gas lift mechanism is designed for long-term use and generally requires no maintenance. Do not attempt to lubricate or disassemble the pistons.
- **Slats:** Ensure slats are properly seated in their buckles and not damaged. Replace any broken slats immediately to maintain mattress support.

8. TROUBLESHOOTING

This section addresses common issues you might encounter with your Allewie bed frame.

Problem	Possible Cause	Solution
Bed frame is wobbly or squeaks.	Loose hardware connections.	Check and tighten all bolts and screws, especially those connecting the headboard, footboard, and side rails.
Hydraulic lift mechanism is difficult to operate or does not stay up.	Mattress weight exceeds capacity, or mechanism is not properly installed.	Ensure mattress weight is within the 110 lbs lifting capacity. Verify that the hydraulic pistons are correctly attached and oriented as per assembly instructions.
Slats are falling out or not providing adequate support.	Slats not properly buckled or damaged.	Ensure each slat is securely buckled into its designated slot. Inspect for any broken or cracked slats and replace if necessary.
Bed frame appears uneven.	Uneven floor or improper assembly.	Check if the floor is level. Re-check assembly steps to ensure all parts are correctly aligned and tightened.

9. WARRANTY AND SUPPORT

Allewie is committed to providing high-quality products. For any questions, concerns, or assistance with your product, please contact customer support.

Customer Support:

Refer to your purchase documentation or the Allewie official website for the most current customer service contact information.

You can also visit the official Allewie Store on Amazon for more information and products: [Allewie Amazon Store](#)

Protection Plans:

Extended protection plans may be available for your product. Please check the product listing on Amazon or contact customer support for details on available 2-Year or 3-Year Protection Plans.