

[Manuals.plus](#) /

› [Oladance](#) /

› Oladance OWS2 Open Ear Headphones User Manual

## Oladance OLA06

# Oladance OWS2 Open Ear Headphones User Manual

Model: OLA06 | Brand: Oladance

## INTRODUCTION

Welcome to the user manual for your Oladance OWS2 Open Ear Headphones. These innovative headphones are designed to provide a unique audio experience by resting gently on your ear, allowing you to stay aware of your surroundings while enjoying high-fidelity sound. Featuring advanced Bluetooth 5.3, multipoint connection, and extended battery life, the OWS2 offers unparalleled comfort and superior audio performance for various activities.

## PRODUCT OVERVIEW



Figure 1: Oladance OWS2 Open Ear Headphones in Martian Orange, showcasing their unique over-ear design.



Figure 2: A person wearing Oladance OWS2 headphones, demonstrating how they rest on the ear without entering the ear canal.

### Key Features:

- **True Open Ear Design:** Earbuds rest gently and securely on top of your ear, providing comfort and situational awareness.
- **Enhanced Sound Quality:** Dual powerful 16.5mm dynamic drivers deliver rich, consistent audio with deep lows and clear highs.
- **Advanced Connectivity:** Bluetooth 5.3 with multipoint connection allows simultaneous pairing with two devices.
- **Extended Playtime:** Up to 19 hours of continuous playback on a single charge.
- **Environmental Noise Canceling:** Optimized for clear calls in various environments.
- **Smart Touch Control:** Intuitive touch controls for media playback and calls.

## SETUP GUIDE

### 1. Charging the Headphones:

Before first use, fully charge your Oladance OWS2 headphones. Place the earbuds into the provided protective case. Connect the Type-C charging cable to the case and a power source. The indicator lights on the case will show charging status.



Figure 3: OWS2 headphones placed inside their protective charging case.

## 2. Pairing with Your Device:

1. Ensure the headphones are charged and powered on.
2. Open the Bluetooth settings on your mobile phone, tablet, or computer.
3. Search for "Oladance OWS2" in the list of available devices.
4. Select the device name to pair. A voice prompt will confirm successful connection.
5. For multipoint connection, repeat the process with a second device. The headphones will seamlessly switch between connected devices.

## 3. Wearing the Headphones:

The OWS2 features an open-ear design that rests on the outer ear. Gently place each earbud over your ear, ensuring the speaker is positioned near your ear canal for optimal sound. The flexible design provides a secure and comfortable fit for extended wear.



Figure 4: Proper placement of OWS2 headphones for comfortable and secure fit.

---

## OPERATING INSTRUCTIONS

### 1. Smart Touch Controls:

The OWS2 headphones feature intuitive touch controls on the outer surface of each earbud. Specific gestures control various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Volume Up/Down:** Swipe up or down on the touch sensitive area of the earbud.



Figure 5: Demonstrating the touch control functionality on the OWS2 earbud.

### 2. Audio Performance:

Experience immersive sound with the OWS2's advanced audio technology. The 16.5mm dynamic drivers and bio-diaphragm technology ensure a rich and balanced sound profile across all volumes. The directional playing feature minimizes sound leakage, providing a private listening experience while maintaining awareness of your surroundings.

### 3. Call Functionality:

The Environmental Noise Canceling (ENC) technology ensures clear voice pickup during calls, reducing background noise for both you and the person on the other end. This makes the OWS2 ideal for calls in busy environments.

Your browser does not support the video tag.

Video 1: Detailed Introduction of Oladance Wearable Stereo. This video provides a comprehensive overview of the OWS2's features and design.

---

## MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to wipe the earbuds and charging case. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in their protective case to prevent damage and keep them charged.
- **Water Resistance:** The OWS2 headphones are water resistant. However, they are not waterproof. Avoid prolonged exposure to water or submersion. Dry thoroughly if exposed to moisture.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.

## TROUBLESHOOTING

| Problem                              | Possible Cause                                                    | Solution                                                                                                                               |
|--------------------------------------|-------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Headphones do not power on.          | Low battery.                                                      | Charge the headphones fully using the provided case and cable.                                                                         |
| Cannot pair with device.             | Bluetooth is off; headphones not in pairing mode; device too far. | Ensure Bluetooth is enabled on your device. Place headphones in pairing mode (usually by opening the case). Keep devices within range. |
| No sound or low volume.              | Volume too low; improper placement; connection issue.             | Increase volume on both headphones and connected device. Adjust earbud placement. Re-pair the headphones.                              |
| Sound quality is poor.               | Interference; improper fit.                                       | Move away from sources of interference. Adjust earbud placement for optimal sound projection.                                          |
| Microphone not working during calls. | Microphone blocked; software issue.                               | Ensure microphone ports are clear. Restart the headphones and your device.                                                             |

## SPECIFICATIONS

| Feature                 | Detail                   |
|-------------------------|--------------------------|
| Model Name              | OLA06                    |
| Connectivity Technology | Wireless (Bluetooth 5.3) |
| Ear Placement           | Open Ear                 |

| Feature                | Detail                               |
|------------------------|--------------------------------------|
| Audio Driver Size      | 16.5 Millimeters                     |
| Battery Life           | Up to 19 Hours (per charge)          |
| Charging Time          | 2 Hours                              |
| Material               | Medical-grade Liquid Silicone Rubber |
| Water Resistance Level | Water Resistant                      |
| Control Method         | Touch                                |
| Item Weight            | 0.26 Kilograms (9.2 ounces)          |
| Product Dimensions     | 2.28 x 1.57 x 0.79 inches            |

### WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Oladance website or contact their customer service. You can also find additional resources and user guides through the following links:

- [Instructions for Use \(IFU\) \(PDF\)](#)
- [User Guide \(PDF\)](#)

Oladance products typically come with a standard manufacturer’s warranty covering defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**