

Andis 74150

Andis 74150 GTX-EXO Professional Cord/Cordless Lithium-ion Electric Beard & Hair Trimmer

Model: 74150 | Brand: Andis

INTRODUCTION

The Andis GTX-EXO Trimmer is a professional-grade cord/cordless lithium-ion electric beard and hair trimmer designed for precision and versatility. It features advanced blade technology and a powerful motor for consistent performance, allowing for detailed outlining, shaving, and fading.

IMPORTANT SAFETY INFORMATION

Standard safety warnings for electric trimmers apply, including potential skin irritation, eye injury, electrical safety, and avoiding use near water sources. Always read the full user manual before operation to ensure safe and proper use.

KEY FEATURES

- **GTX-Z Carbon-Steel Blades:** Retooled for closer cuts and can be zero-gapped without modification, providing cutting-edge precision.
- **Enhanced Visibility:** Intuitive design provides crystal clear visibility for outlining, shaving, and fading, improving accuracy.
- **Cordless Design:** Powered by a lithium-ion battery, offering over 100 minutes of consistent power for unrestricted movement.
- **Constant Speed Technology:** Delivers 7,200 strokes per minute (spm) for smooth cutting through all hair types, preventing snagging.




Image: The Andis GTX-EXO Trimmer in black, resting on its charging stand, highlighting its sleek design and cordless capability.

SETUP GUIDE

1. **Unboxing:** Carefully remove all components from the packaging. Verify all items are present: trimmer, charging stand, power adapter, and any included accessories.
2. **Initial Charge:** Before first use, fully charge the trimmer. Connect the power adapter to the charging stand, then place the trimmer onto the stand. The indicator light will show charging status.
3. **Blade Inspection:** Ensure the GTX-Z blades are clean and properly aligned. The trimmer comes pre-set for a tight cut.

Your browser does not support the video tag.

Video: An unboxing and initial setup demonstration of the Andis GTX-EXO Trimmer, showing how to remove it from the box, connect the charging stand, and place the trimmer for charging.

OPERATION

1. **Power On/Off:** Use the power switch located on the front of the trimmer to turn it on or off. The indicator light will illuminate when powered on.
2. **Trimming Techniques:** The intuitive design allows for extreme visibility, making it ideal for precise outlining, detailed work, and close dry shaving. Use light, even pressure.
3. **Cordless Operation:** Enjoy over 100 minutes of cordless runtime. The trimmer can also be used while charging if needed.

Your browser does not support the video tag.

Video: A professional barber demonstrates the features and power of the Andis GTX-EXO Trimmer, highlighting its cordless operation and precision.




Image: The Andis GTX-EXO Trimmer being used to precisely trim a beard, showcasing its ergonomic design and visibility.

CARE AND MAINTENANCE

CARE AND MAINTENANCE

Regular cleaning and lubrication are essential for optimal performance and longevity of your Andis GTX-EXO Trimmer.

- 1. **Cleaning Blades:** After each use, brush hair clippings from the blades. You may use a damp cloth to wipe the housing.
- 2. **Lubrication:** Apply a few drops of clipper oil (included) to the blades before and after each use. This reduces friction, prevents rust, and maintains cutting efficiency.
- 3. **Storage:** Store the trimmer in its charging stand or a safe, dry place when not in use.



Image: A close-up of the Andis GTX-EXO Trimmer's exposed blade, illustrating its design for easy cleaning and maintenance.

TROUBLESHOOTING COMMON ISSUES

Problem	Possible Cause	Solution
Trimmer not cutting effectively / pulling hair	Dull or dirty blades, insufficient lubrication, hair buildup.	Clean and oil blades. If problem persists, consider blade replacement or professional sharpening.
Trimmer not turning on	Battery not charged, power switch off.	Ensure trimmer is fully charged. Check power switch position.
Blades getting hot	Lack of lubrication, prolonged use.	Apply clipper oil. Allow trimmer to cool down between uses.

Your browser does not support the video tag.

Video: A customer demonstrates the trimmer's cutting performance, noting issues with multiple passes required, which could indicate a need for blade maintenance or adjustment.

PRODUCT SPECIFICATIONS

- **Model Number:** 74150
- **Product Dimensions:** 10.79 x 5.28 x 4.53 inches
- **Item Weight:** 2 Pounds
- **Power Source:** Lithium-ion battery (1 required)
- **Blade Material:** Carbon-Steel (GTX-Z)
- **Motor Speed:** 7,200 spm (strokes per minute)
- **Color:** Black
- **Country of Origin:** USA

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user manual provided with your product or visit the [Andis Store](#).

A PDF version of the user manual is available for download:[User Manual \(PDF\)](#).

Protection plans are available for extended coverage:

- 2-Year Protection Plan: \$16.99
- 3-Year Protection Plan: \$23.99
- Complete Protect: \$16.99/month (covers all eligible past and future purchases)

© 2024 Andis Company. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is my Andis 74150 GTX-EXO trimmer not charging or turning on after I replaced the battery?

Based on the Andis 74150 GTX-EXO manual and standard safety guidelines, here are the steps to troubleshoot your power and charging issues after a battery replacement:Check Internal Connections: The manual explicitly states, "Do not...

[Read full answer](#)