

Manuals.plus /

› WANAI /

› WANAI 3.5 Cu.Ft Chest Freezer Instruction Manual (Model BCBD-63)

## WANAI BCBD-63

# WANAI 3.5 Cu.Ft Chest Freezer Instruction Manual (Model BCBD-63)

Comprehensive guide for your WANAI Chest Freezer.

## 1. INTRODUCTION

Thank you for choosing the WANAI 3.5 Cu.Ft Chest Freezer, Model BCBD-63. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.





Figure 1: WANAI 3.5 Cu.Ft Chest Freezer (Model BCBD-63) with lid open.

The WANAI 3.5 Cu.Ft Chest Freezer is designed for compact spaces, offering ample storage for frozen goods. Its features include an adjustable thermostat, a removable storage basket, and energy-efficient operation.

## 2. IMPORTANT SAFETY INFORMATION

- Ensure the freezer is placed on a stable, level surface.
- Allow adequate ventilation around the appliance. Do not block air vents.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the freezer before cleaning or performing any maintenance.
- Keep children away from the freezer, especially when the lid is open.

### 3. SETUP AND INSTALLATION

#### 3.1 Unpacking

Carefully remove the freezer from its packaging. Inspect the appliance for any damage that may have occurred during shipping. If damage is found, contact your retailer immediately.

Your browser does not support the video tag.

Video 1: Unboxing and initial setup of the WANAI 3.5 Cu.Ft Chest Freezer.

#### 3.2 Placement

Place the freezer on a firm, level floor in a dry, well-ventilated area. Avoid direct sunlight or heat sources. Ensure there is at least 4 inches (10 cm) of space around the sides and back of the freezer for proper air circulation.



Figure 2: Dimensions of the WANAI 3.5 Cu.Ft Chest Freezer.

#### 3.3 Initial Power-On

After placing the freezer, allow it to stand upright for at least 24 hours before plugging it in. This allows the

refrigerant and oils in the compressor to settle, preventing potential damage. Once settled, plug the freezer into a dedicated grounded electrical outlet.

Your browser does not support the video tag.

Video 2: Overview of the WANAI Chest Freezer, including initial setup considerations.

## 4. OPERATING INSTRUCTIONS

### 4.1 Temperature Control

The freezer features an adjustable 7-grade temperature control dial located on the front lower right side. Rotate the dial to select your desired temperature setting:

- **Levels 1-2:** Ideal for keeping items cool, such as beverages or fresh produce (approx. 32°F to 50°F).
- **Levels 3-7:** For freezing and deep freezing items (approx. 32°F to -11.2°F). Higher numbers indicate colder temperatures.



**7 TEMP ADJUSTMENT**

**RANGES FROM -11.2°F~50°F**

The graphic features a blue background with a white snowflake pattern. On the left, a blue-bordered box contains two images: the top one shows fresh seafood including salmon, lobster, and fish, and the bottom one shows various cuts of raw meat. To the right of this box is a black, teardrop-shaped temperature control dial with a white ring and numbers 1 through 7. Below the dial is a glowing green power button. A large blue snowflake icon is positioned in the bottom right corner of the graphic.

Figure 3: Temperature control dial with 7 settings.

## 4.2 Using the Removable Basket

The freezer includes a removable wire basket for convenient storage of smaller items. This helps organize contents and provides easy access to frequently used items without having to dig through the main compartment.



Figure 4: Removable storage basket for organizing freezer contents.

Your browser does not support the video tag.

Video 3: Demonstration of freezer usage, including the removable basket.

## 5. MAINTENANCE

### 5.1 Defrosting

This is a manual defrost freezer. Defrost the freezer when the frost layer on the interior walls reaches about 0.2 inches (5 mm) thick. To defrost:

1. Unplug the freezer from the power outlet.
2. Remove all food items and place them in another freezer or cooler.
3. Open the drain plug located at the bottom of the freezer to allow water to escape. Place a shallow pan or towel underneath to collect the water.
4. Leave the lid open to speed up the defrosting process.
5. Once defrosted, clean and dry the interior thoroughly before plugging it back in and returning food items.

## 5.2 Cleaning

Regularly clean the interior and exterior of the freezer with a mild detergent and warm water. Avoid abrasive cleaners or sharp objects that could damage the surfaces.

## 6. TROUBLESHOOTING

| Problem                         | Possible Cause   | Solution   |
|---------------------------------|--|--|
| Freezer does not operate.       | Not plugged in; circuit breaker tripped; power outage.                                     | Check power connection; reset circuit breaker; check household power.                                    |
| Temperature is not cold enough. | Temperature control set too warm; excessive door opening; large amount of warm food added. | Adjust temperature control to a colder setting; minimize door openings; allow time for new food to cool. |
| Excessive noise.                | Freezer is not level; contact with wall/other objects.                                     | Adjust leveling legs; move freezer away from obstructions.   |

## 7. SPECIFICATIONS

**Brand:** WANAI

**Model:** BCBD-63

**Capacity:** 3.5 Cu.Ft

**Color:** Black

**Dimensions (D x W x H):** 20.7" x 16.22" x 29.52"

**Item Weight:** 38 pounds

**Voltage:** 110 Volts

**Wattage:** 70 watts

**Door Hinges:** Top

**Door Material Type:** Stainless Steel

**Shelves:** 1 (removable basket)

**Certification:** ETL

**Included Components:** Basket

U.S. Government

Federal law prohibits removal of this label before consumer purchase.

# ENERGYGUIDE

Compact Chest Freezer  
• Manual Defrost

Brand: WANAI  
Models: BD-63  
Capacity: 3.5 CU.FT



**Compare ONLY to other labels with yellow numbers.**  
Labels with yellow numbers are based on the same test procedures.

**Estimated Yearly Energy Cost**

**\$30**



**190 kWh**

**Estimated Yearly Electricity Use**

- † Your cost will depend on your utility rates and use.
- † Cost range based only on models of similar capacity with Manual Defrost.
- † Estimated energy cost based on a national average electricity cost of 12 cents per kWh.

[ftc.gov/energy](http://ftc.gov/energy)

Figure 5: EnergyGuide label for WANAI 3.5 Cu.Ft Chest Freezer.

## 8. WARRANTY AND SUPPORT

WANAI offers reliable customer service. For any product-related questions or post-sales issues, please contact our 24-hour online customer service. We are committed to providing a satisfactory solution.

Please refer to your purchase documentation for specific warranty details and contact information.