Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soundcore

Soundcore by Anker Liberty 4 NC Wireless Earbuds

Instruction Manual

1. Setup

1.1. Unboxing

Upon opening the package, ensure all components are present:

- Liberty 4 NC Earbuds
- Charging Case (extends battery life to 50 hours)
- XS/S/M/L Ear Tips (M pre-installed)
- USB-C Charging Cable



Image: The Soundcore Liberty 4 NC earbuds in their open charging case, showcasing the sleek design and included accessories.

1.2. Charging

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the case and a power source. A 10-minute charge provides 4 hours of music playback.



Image: An illustration demonstrating the earbuds being charged within their case, highlighting the battery life and quick charge capabilities.

1.3. Pairing

The Liberty 4 NC earbuds enable quick and effortless Bluetooth pairing with Android devices. They support Bluetooth 5.3 for stable connections and multi-point connectivity.

1. Open the charging case.
2. The earbuds will automatically enter Bluetooth pairing mode.
3. On your device, search for "Soundcore Liberty 4 NC" in the Bluetooth settings and select to connect.

1.4. App Installation

For full customization and optimal performance, download the Soundcore app. The app allows you to sculpt your sound profile using HearID 2.0, adjust the EQ with 22 presets, and manage various settings.

2. Operating Instructions

2.1. Noise Cancellation

The Liberty 4 NC earbuds feature Adaptive ANC 2.0, which makes real-time calculations and adjusts to your ear canals and external environment to reduce noise by up to 98.5%.



Image: A visual representation of the earbud's internal components and how they achieve 98.5% noise reduction.



Image: A person wearing the earbuds on a train, illustrating the adaptive noise cancelling feature for peaceful travel.

You can control your soundscape with 5 levels of noise cancelling, 2 transparency modes, and 4 modes specifically designed for plane, train, bus, and taxi travel. Adjust these settings via the Soundcore app.

Your browser does not support the video tag.

Video: An official product video from AnkerDirect showcasing the noise cancelling capabilities of the Soundcore Liberty 4 NC earbuds.

2.2. Sound Quality & Customization

Equipped with 11mm custom-tuned drivers, the earbuds deliver crisp and detailed Hi-Res wireless audio. LDAC technology transfers 3 times more data than regular Bluetooth, enhancing your listening experience.



Image: An illustration highlighting the 11mm custom drivers and Hi-Res Audio Wireless with LDAC support for superior sound.

Use the HearID 2.0 feature in the Soundcore app to create a personalized sound profile tailored to your hearing. You can also manually adjust the equalizer or select from 22 preset sound profiles.

2.3. Call Features

The earbuds feature 6 beamforming microphones and an AI algorithm that amplifies your voice and reduces background noise, ensuring clear calls even in noisy environments.



Image: A person using the earbuds for a call, demonstrating the effectiveness of the 6-mic AI clear call technology.

2.4. Controls

The earbuds utilize touch controls for various functions. The charging case also features a 3-in-1 smart button for opening the case, entering Bluetooth pairing mode, or resetting your earbuds.
Specific touch control functions can be customized via the Soundcore app.

2.5. Battery Life

Enjoy extended listening times with the Liberty 4 NC:

- **Normal Mode:** Up to 10 hours of playback on a single charge, and up to 50 hours with the charging case.
- **ANC On:** Up to 8 hours of playback on a single charge, and up to 40 hours with the charging case.

3. Maintenance

3.1. Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. For ear tips, remove them and clean with mild soap and water, then dry thoroughly before reattaching.

3.2. Water Resistance

The Liberty 4 NC wireless noise cancelling earbuds are IPX4 water-resistant. This rating means they are protected against splashing water from any direction. They are suitable for use during light rain or workouts but should not be submerged in water.



Image: The earbuds shown with water splashes, indicating their IPX4 water-resistant design.

3.3. Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged. Store the case in a cool, dry place away from extreme temperatures.

4. Troubleshooting

If you encounter issues with your Soundcore Liberty 4 NC earbuds, try the following steps:

- **No Sound:** Ensure earbuds are charged, connected to your device, and volume is up.
- **Connection Issues:** Reset the earbuds by placing them in the case and pressing the smart button. Re-pair with your device. Ensure Bluetooth is enabled on your device.
- **Charging Problems:** Check the USB-C cable and power adapter. Ensure the charging contacts on the earbuds and case are clean.
- **Noise Cancellation Not Working:** Ensure ANC is enabled in the Soundcore app and try different modes. Ensure ear tips provide a good seal.

For more detailed troubleshooting, refer to the officialTroubleshooting Guide (PDF) or the User Manual (PDF).

5. Specifications

Feature	Detail
Model Name	Liberty 4 NC
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth 5.3
Audio Driver Type	Dynamic Driver (11mm)
Frequency Range	20-20KHZ
Battery Life (Earbuds)	10 Hours (Normal Mode), 8 Hours (ANC On)
Battery Life (with Case)	50 Hours (Normal Mode), 40 Hours (ANC On)
Charging Time	10 minutes for 4 hours playback
Water Resistance Level	IPX4
Control Method	Touch
Item Weight	0.67 ounces (19 Grams)
Product Dimensions	4.25 x 4.25 x 2.17 inches
Material	PC+ABS

Included Components	Charging case

6. Warranty and Support

For warranty information and customer support, please visit the official Soundcore website or refer to the documentation included with your product. You can also find additional resources, including the full user manual and troubleshooting guide, via the links provided in the Troubleshooting section.
The product was first available on June 20, 2023.

© 2024 Soundcore. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZV4QFP8

More documents and user manuals: **https://manuals.plus/**