Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ibergrif M16303

Ibergrif M16303 Wall-Mounted Kitchen Faucet Instruction Manual

Model: M16303
Brand: Ibergrif

Introduction

Thank you for choosing the Ibergrif M16303 Wall-Mounted Kitchen Faucet. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new faucet. Please read these instructions carefully before installation and retain them for future reference.

Product Overview

The Ibergrif M16303 is a wall-mounted kitchen faucet constructed from high-quality 304 stainless steel with a brushed finish, designed for durability and resistance to corrosion and scratches. It features a single lever for easy control of water flow and temperature, and a ceramic disc cartridge for reliable, drip-free performance.



Figure 1: Ibergrif M16303 Wall-Mounted Kitchen Faucet.

Setup and Installation

This faucet is designed for wall-mounted installation. Ensure you have all necessary tools and materials before beginning. Professional installation is recommended if you are unfamiliar with plumbing work.

Included Components

Verify that all components are present in the packaging:

- Faucet body with spout and handle
- Mounting hardware (e.g., eccentric S-unions, escutcheons, gaskets)
- Instruction manual



Figure 2: All installation materials are included for convenience.

Installation Steps (General)

1. **Prepare the Wall:** Ensure the water supply lines are shut off. Mark the desired mounting points for the faucet on the wall, ensuring they are level and at the correct distance for your plumbing connections.
2. **Install S-Unions:** Apply plumber's tape to the threaded ends of the eccentric S-unions. Screw the S-unions into the wall water supply outlets. Adjust them until the distance between their centers matches the faucet's inlet spacing (typically 150mm) and they are level.
3. **Attach Escutcheons:** Place the decorative escutcheons over the S-unions, flush against the wall.
4. **Mount the Faucet Body:** Place gaskets onto the faucet's inlet nuts. Connect the faucet body to the S-unions, tightening the nuts securely with a wrench. Avoid overtightening.
5. **Test for Leaks:** Slowly turn on the main water supply and check all connections for leaks.



Figure 3: Product dimensions for installation planning. The faucet has a spout reach of 300mm and a height of 268mm from the wall connection.

Operating Instructions

The Ibergrif M16303 faucet is designed for simple and intuitive operation.

Water Flow and Temperature Control

- **Turn On/Off:** Lift the single lever handle to turn on the water flow. Push it down to turn off.
- **Adjust Temperature:** Move the lever to the left for hot water and to the right for cold water. The ceramic cartridge ensures smooth and precise temperature adjustment.
- **Adjust Flow:** The height to which the lever is lifted controls the water flow rate.



Figure 4: The single lever controls both hot and cold water, indicated by red and blue arrows.

Spout Rotation

The faucet spout can rotate 360 degrees, providing flexibility and convenience for various sink tasks.



Figure 5: The faucet spout offers 360-degree rotation for enhanced usability.

Water-Saving Aerator

The integrated high-quality aerator provides a smooth, splash-free water flow and helps conserve water by up to 30%.



Figure 6: The faucet features a NEOPERL water-saving aerator for efficient water usage.

Maintenance

Regular maintenance will ensure the longevity and optimal performance of your Ibergrif M16303 faucet.

Cleaning the Faucet

- Clean the brushed stainless steel finish regularly with a soft cloth and mild soap or a non-abrasive cleaner.
- Avoid using abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.

Aerator Maintenance

If water flow decreases or becomes irregular, the aerator may be clogged with debris.

1. Unscrew the aerator from the tip of the spout.
2. Rinse the aerator screen under running water to remove any particles. For stubborn deposits, soak in a vinegar

solution.

3. Reassemble the aerator and screw it back onto the spout.



Figure 7: Close-up view of the aerator and connection points, highlighting areas for maintenance.

Ceramic Cartridge

The faucet is equipped with a durable ceramic disc cartridge, designed to prevent leaks and drips for a long operational life. If a leak occurs from the handle area, the cartridge may need inspection or replacement. Contact customer support for assistance.

Troubleshooting

This section addresses common issues you might encounter with your faucet.

- **Low Water Flow:** Check if the aerator is clogged (refer to Maintenance section). Ensure water supply valves are fully open.
- **Leaks from Spout:** This is typically caused by a worn aerator gasket or a faulty cartridge. Clean or replace the

aerator gasket first. If the issue persists, the ceramic cartridge may need replacement.

- **Leaks from Handle Base:** This usually indicates a problem with the ceramic cartridge. Contact customer support for guidance on replacement.
- **Water Temperature Issues:** Ensure both hot and cold water supply lines are connected correctly and fully open.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact Ibergrif customer support.

Specifications

Feature	Specification
Model Number	M16303
Brand	Ibergrif
Material	304 Stainless Steel (Faucet Body), Brass (Handle Material)
Finish	Brushed
Installation Method	Wall-Mounted (Monotrou)
Product Dimensions (L x W x H)	30 x 20 x 26.8 cm (11.8 x 7.9 x 10.5 inches)
Item Weight	1.17 kilograms (2.58 lbs)
Number of Handles	1 (Lever Style)
Handle Placement	Right
Special Feature	Rotary (360° Swivel Spout)
Included Components	Installation hardware
Cartridge Type	Ceramic Disc

Warranty and Support

For warranty information, technical support, or to order replacement parts, please contact Ibergrif customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: Ibergrif Griferias S.L

Contact Information: Refer to the Ibergrif official website or your purchase documentation for the most current support contact details.

Important Safety Information

- Always shut off the main water supply before attempting any installation, maintenance, or repair.
- Wear appropriate personal protective equipment (e.g., safety glasses, gloves) during installation.
- If you are unsure about any part of the installation or repair process, consult a qualified plumber.
- Do not use excessive force when tightening connections to avoid damaging the faucet or plumbing.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZV5L8BQ

More documents and user manuals: **https://manuals.plus/**