

[Manuals.plus](#) /

> [XELAR](#) /

> XELAR Wireless Headset LC-B41 User Manual

## XELAR LC-B41

# XELAR Wireless Headset LC-B41 User Manual

Model: LC-B41

Brand: XELAR

## INTRODUCTION

---

Welcome to the user manual for your XELAR LC-B41 Wireless Headset. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your device. Please read this manual carefully before using the headset to ensure optimal performance and longevity.

## PACKAGE CONTENTS

---

Please verify that all items listed below are present in your package.



Image: The XELAR LC-B41 headset, charging cables, ear tips, and ear hooks are displayed alongside the product box and user manual.

- XELAR LC-B41 Wireless Headset
- USB Charging Cable
- Ear Tips (various sizes)
- Ear Hooks (various sizes)
- User Manual

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your XELAR LC-B41 Wireless Headset.



Image: A close-up view of the XELAR LC-B41 Wireless Headset, highlighting its sleek design, power switch, and LED indicator light.

The headset features a power switch (ON/OFF), a multi-function button, volume controls, a charging port, and an LED indicator. The ergonomic design ensures a comfortable fit for extended use.

## SETUP

---

### Charging the Headset

Before first use, fully charge the headset.

1. Connect the small end of the USB charging cable to the charging port on the headset.

2. Connect the large end of the USB charging cable to a USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator will show red during charging and turn blue or off when fully charged.
4. Charging time is approximately 2.5 hours.

## Pairing with a Device

The XELAR LC-B41 uses Bluetooth 5.0 for stable and fast connections.

1. Ensure the headset is fully charged and turned off.
2. Press and hold the Multi-function Button until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "XELAR LC-B41" from the list.
5. Once connected, the LED indicator will flash blue slowly or turn off, and you will hear a confirmation tone.

The infographic features a central image of the XELAR LC-B41 headset. Surrounding it are six circular icons, each with a number in a blue circle and a label in a white rounded rectangle below it. The icons represent: 01 Laptop (laptop screen), 02 Computer (desktop monitor), 03 iOS en Android (Android robot and Apple logo), 04 iPad (iPad tablet), 05 Smart Phone (smartphone), and 06 Smartwatch (smartwatch). At the top left, the text 'Comfortabele pasvorm' is in a white rounded rectangle. Below it, the large white text 'IS GESCHIKT VOOR' is followed by 'COMPATIBELE APPARATEN: iPhone, Android telefoon, PC, ipad, en andere bluetooth apparaten'.

Image: The XELAR LC-B41 headset is shown centrally, surrounded by icons representing compatible devices such as laptops, computers, iOS/Android phones, iPads, smartphones, and smartwatches.

The headset is compatible with a wide range of Bluetooth-enabled devices, including smartphones, tablets, laptops, and smartwatches.

## OPERATING INSTRUCTIONS

---

### Power On/Off

To Power On: Slide the power switch to the "ON" position. The LED indicator will flash blue.

To Power Off: Slide the power switch to the "OFF" position. The LED indicator will turn off.

### Call Management

Answer Call: Press the Multi-function Button once.

End Call: Press the Multi-function Button once during a call.

Reject Call: Press and hold the Multi-function Button for 2 seconds.

Redial Last Number: Double-press the Multi-function Button.

### Volume Control

Increase Volume: Press the Volume Up (+) button.

Decrease Volume: Press the Volume Down (-) button.

### Music Playback

Play/Pause: Press the Multi-function Button once.

Next Track: Press and hold the Volume Up (+) button for 2 seconds.

Previous Track: Press and hold the Volume Down (-) button for 2 seconds.

### Connecting to Two Devices Simultaneously

The XELAR LC-B41 headset supports connecting to two Bluetooth devices at the same time, allowing seamless switching between calls from different phones (e.g., work and personal).

# 2 APPARATEN TEGELIJK VERBINDEN MET 1 HEADSET

Sluit uw headset aan op uw zakelijke en privételefoon om alle oproepen eenvoudig te beantwoorden met 1 headset.



Image: The XELAR LC-B41 headset is depicted as a central hub, with arrows indicating stable connections to two separate smartphones, demonstrating its dual-device connectivity feature.

1. Pair the headset with the first device as described in the "Pairing with a Device" section.
2. Turn off the Bluetooth function on the first device.
3. Put the headset back into pairing mode (red and blue flashing LED).
4. Pair the headset with the second device.
5. Once the second device is connected, re-enable Bluetooth on the first device. The headset should automatically connect to both devices.

## MAINTENANCE

### Cleaning

Regularly clean your headset to ensure hygiene and optimal performance.

- Use a soft, dry, lint-free cloth to wipe the surface of the headset.
- For ear tips, remove them from the headset and gently wipe with a damp cloth. Ensure they are completely dry before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

## Storage

- Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing the headset in dusty or dirty environments.
- If storing for an extended period, charge the headset at least once every three months to preserve battery life.

## TROUBLESHOOTING

---

Problem	Solution
Headset does not turn on	Ensure the headset is charged. Connect it to a power source and try again.
Cannot pair with device	Ensure the headset is in pairing mode (red and blue flashing LED). Turn off and on Bluetooth on your device. Move the headset closer to your device.
No sound or low volume	Check the volume levels on both the headset and your connected device. Ensure the headset is properly connected.
Intermittent connection	Ensure there are no obstacles between the headset and your device. Move away from sources of strong electromagnetic interference.

## SPECIFICATIONS

---

Sterke verbinding

# BLUETOOTH V5.0 SNELLE KOPPELING

Door de geavanceerde bluetooth 5.0 technologie beschikt de headset over een stabiele verbinding



## Specificaties



CVC 8.0  
Ruisonderdrukking



Batterij  
Indicator



Bluetooth  
5.0



Ingebouwde  
Microfoon

Image: A diagram illustrating key specifications of the XELAR LC-B41 headset, including CVC 8.0 Noise Cancellation, Battery Indicator, Bluetooth 5.0, and Built-in Microphone.

- **Model:** LC-B41
- **Bluetooth Version:** 5.0
- **Wireless Range:** Up to 15 meters
- **Talk Time:** Up to 24 hours
- **Standby Time:** Up to 60 days
- **Charging Time:** Approximately 2.5 hours
- **Battery Capacity:** 200mAh polymer battery
- **Noise Cancellation:** CVC 8.0
- **Microphone:** Built-in, Noise Cancelling
- **Material:** Plastic, Silicone
- **Special Features:** Sweat-resistant, Strong Battery
- **Compatibility:** Desktops, Laptops, Mobile phones, Tablets

## WARRANTY AND SUPPORT

XELAR products are designed for durability and performance. For warranty information and technical support, please refer to the contact details provided on the product packaging or visit the official XELAR website.

For common issues, please refer to the Troubleshooting section of this manual.

© 2023 XELAR. All rights reserved.