

Panasonic ES-LV9W-S

Panasonic ES-LV9W-S LAMDASH PRO 5-Blade Electric Shaver Instruction Manual

Model: ES-LV9W-S

1. INTRODUCTION

Thank you for purchasing the Panasonic ES-LV9W-S LAMDASH PRO 5-Blade Electric Shaver. This advanced grooming device is engineered for a close, comfortable shave, featuring a powerful linear motor, a flexible 5D head, and an automatic cleaning and charging system. This manual provides essential information for the safe and effective use, maintenance, and care of your shaver.

2. IMPORTANT SAFETY INFORMATION

Always read all instructions and warnings before using this product to ensure safe operation.

- Do not use the shaver while it is connected to the charging cable.
- This shaver is designed for wet/dry use. It can be used in the shower or with shaving cream, but ensure it is not charging when used with water.
- Before initial use or if you have sensitive skin, perform a patch test on a small, inconspicuous area of your skin.
- Keep the shaver and its accessories out of reach of children.
- Do not disassemble, repair, or modify the shaver yourself. Contact authorized service personnel for any repairs.
- Use only the provided charger and accessories.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Panasonic ES-LV9W-S LAMDASH PRO 5-Blade Electric Shaver

- Automatic Cleaning and Charging Station
- AC Adapter/Charger
- Semi-Hard Case
- Cleaning Brush
- Protective Cap
- Instruction Manual

4. SETUP

4.1 Initial Charging

Before first use, fully charge the shaver. This typically takes about 1 hour for a full charge, providing approximately 14 days of use (based on 3 minutes of shaving per day).

1. Connect the AC adapter to the automatic cleaning and charging station.
2. Place the shaver into the cleaning and charging station. Ensure it is seated correctly.
3. Plug the AC adapter into a power outlet (100-240V compatible).
4. The display on the shaver and/or station will indicate charging status.

4.2 Attaching/Detaching the Shaver Head

The shaver head is designed for easy attachment and detachment for cleaning or replacement.

- To detach: Press the release buttons on either side of the shaver head and gently pull the head upwards.
- To attach: Align the shaver head with the body and push down until it clicks securely into place.

5. OPERATING YOUR SHAVER

5.1 Basic Shaving

The Panasonic ES-LV9W-S features a 5-blade system and a high-speed linear motor (approx. 14,000 strokes/min, resulting in 70,000 cutting actions/min) for efficient shaving.

- Press the power button to turn on the shaver.
- Hold the shaver at a right angle (90 degrees) to your skin.
- Gently stretch your skin with your free hand and move the shaver slowly against the grain of your beard.
- The flexible 5D head adapts to facial contours, ensuring close contact with the skin.
- The LAMDASH AI technology detects beard thickness approximately 233 times per second and adjusts power for optimal shaving without excessive skin burden.



濃いヒゲも早く、深く、
やさしく剃りきる。

LAMDASH PRO

ラムダッシュPRO 5枚刃

○写真はイメージです。

Image: Proper grip and handling of the shaver.

密着 5 Dヘッド

アゴ下の複雑な凹凸にもぴったり
密着して、肌にやさしく剃りあげる。




○写真はイメージです。

Image: The 5D head flexes to follow facial contours for a smooth shave.

ラムダッシュAI+※

常に最適なパワーで肌へ余分な負担をかけずに、やさしく早剃り。



※ヒゲの濃さや、シェーバーヘッド内部のヒゲクズによって、センサーが反応(駆動音の変化)しない場合がありますが、異常ではありません。

○写真のモデルはES-LS9CX-Kです。

○写真・イラストはイメージです。

Image: LAMDASH AI detects beard density and adjusts motor power.

5.2 Wet/Dry Shaving

This shaver is designed for both wet and dry shaving, offering flexibility for your grooming routine.

- **Dry Shaving:** Use on dry skin for a quick and convenient shave.
- **Wet Shaving:** Apply shaving foam or gel to your face and then shave. The shaver is waterproof and can be used in the shower.

お風呂でも剃れる

充電式

入浴時にシェービングができる。



○イラストはイメージです。

Image: The shaver is suitable for wet shaving, including use in the bath.

5.3 Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for precise grooming of sideburns, mustaches, and detailing.

- Slide the trimmer switch upwards to engage the pop-up trimmer.
- Use the trimmer to shape and define your beard lines or trim longer hairs before shaving.
- Slide the switch back down to retract the trimmer when finished.

6. MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your shaver.

6.1 Automatic Cleaning and Drying

The included automatic cleaning and charging station provides a convenient way to clean, dry, and charge your shaver.

- After shaving, rinse the shaver head under running water to remove most hair clippings.
- Place the shaver into the cleaning and charging station.

- Select the desired cleaning cycle (e.g., clean, dry). The station uses a cleaning solution and heat to sterilize (99% or more) and dry the shaver.

全自動洗淨充電器システム



※
**99%以上
除菌**

ヒーターとファンで
加熱乾燥

○写真のモデルはES-LS9CX-Kです。



コンパクトで
場所をとらない！

17.5 cm

9.5 cm 9.4 cm

※【試験依頼先】(一財)日本食品分析センター【試験方法】洗淨充電器にて専用洗淨剤を使用し、洗淨・乾燥した刃部の除菌率を測定
【試験結果】99 % 以上除菌【試験成績書発行】2017年4月26日【試験成績書発行番号】第17036945001-0101号 ○写真はイメージです。

Image: The automatic cleaning and charging station ensures hygienic maintenance.

6.2 Manual Cleaning

For quick cleaning or when the cleaning station is not available:

1. Turn off the shaver and detach the outer foil frame.
2. Brush away any loose hair clippings from the inner blades and outer foil using the provided cleaning brush.
3. Rinse the outer foil frame and inner blades thoroughly under running water.
4. Shake off excess water and allow the parts to air dry completely before reattaching.

6.3 Blade and Foil Replacement

For optimal shaving performance, it is recommended to replace the outer foil and inner blades periodically. Refer to the product packaging or Panasonic's official website for recommended replacement intervals and compatible replacement parts for model ES-LV9W-S.

7. TROUBLESHOOTING

If you encounter any issues with your shaver, refer to the following common solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Poor shaving performance.	Blades/foil are dull or clogged.	Clean the shaver thoroughly. Replace blades/foil if worn.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure gentle pressure and shave against the grain. Consider wet shaving with foam/gel.
Shaver stops during use.	Battery is low.	Recharge the shaver.

If the problem persists, please contact Panasonic customer support.

8. SPECIFICATIONS

- **Model Number:** ES-LV9W-S
- **Blade System:** 5-Blade Linear Motor
- **Motor Speed:** Approximately 14,000 strokes/min
- **Cutting Actions:** Approximately 70,000 cutting actions/min
- **AI Sensor:** LAMDASH AI (233 detections/sec)
- **Head Type:** 5D Multi-Flex Head
- **Usage:** Wet/Dry (Waterproof)
- **Power Source:** Battery Powered (Rechargeable)
- **Battery Life:** Approximately 14 days (based on 3 minutes/day)
- **Included Components:** Shaver, Automatic Cleaning Charger, Semi-Hard Case
- **Product Dimensions:** 5.9 x 7.2 x 16.7 cm
- **Item Weight:** 210 g
- **Blade Material:** Stainless Steel
- **Color:** Silver

9. WARRANTY AND SUPPORT

For detailed warranty information, product registration, and customer support, please refer to the warranty card included with your product or visit the official Panasonic website. Keep your purchase receipt as proof of purchase for warranty claims.

Panasonic Official Website: www.panasonic.com

Panasonic Store: [Visit the Panasonic Store on Amazon](#)