

[Manuals.plus](#) /

> [SUOERNUO](#) /

> SUOERNUO Laundry Sorter Basket 2 Bag Laundry Hamper Cart Instruction Manual

SUOERNUO 9002

SUOERNUO Laundry Sorter Basket Instruction Manual

Model: 9002

PRODUCT OVERVIEW

The SUOERNUO Laundry Sorter Basket is a versatile and efficient solution for organizing your laundry. This 2-bag hamper cart features rolling lockable wheels and removable bags, designed for convenient clothes storage and sorting. Its robust metal frame and non-woven fabric bags ensure durability and ease of use in various household settings.



Image: The SUOERNUO 2-Bag Laundry Sorter Basket, showcasing its black metal frame and two black removable laundry bags. The cart is equipped with rolling wheels for easy mobility.

KEY FEATURES

- **Large Capacity:** The 2-section laundry sorter measures 21.96"L x 15.75"W x 32.67"H. Each laundry bag has dimensions of 9.44"L x 12.6"W x 20.28"H, offering ample space for clothes.
- **Easy Classification:** Divided into two sections, this sorter simplifies separating light, dark, or colored clothes.
- **4 Rolling Wheels:** Equipped with heavy-duty wheels for smooth movement. Two wheels are lockable to ensure stability when stationary.
- **Multifunctional Design:** Ideal for household and hotel use, capable of holding dirty clothes, toys, or other scattered items to maintain tidiness.

- **Removable Bags:** The laundry bags are designed with practical handles for easy removal and transport to the laundry room.
- **Durable Construction:** Features a thickened metal pipe frame and non-woven fabric bags, ensuring strength, durability, and ease of cleaning.



Image: Detailed view highlighting the removable handles for the bags, the durable non-woven fabric material, and the swivel caster wheels with their locking mechanism.

SETUP AND ASSEMBLY

Assembly of the SUOERNUO Laundry Sorter Basket is designed to be straightforward. Please follow the included instruction manual for detailed steps. All necessary components are provided for a complete setup.

1. Unpack all components and verify against the parts list in the instruction manual.
2. Assemble the metal frame according to the diagrams. Ensure all connections are secure.
3. Attach the four swivel caster wheels to the base of the frame. Ensure two of the wheels are the lockable type and are installed correctly.

4. Insert the removable non-woven fabric bags into their designated sections within the frame. The bags have handles that hook onto the frame for stability.
5. Once assembled, test the stability of the frame and the functionality of the wheels and locks.



Image: An illustration demonstrating the ease of removing the laundry bags using their integrated handles, facilitating transport from bedroom to laundry room.

OPERATING INSTRUCTIONS

Using your laundry sorter is simple and designed to streamline your laundry routine.

- **Sorting Laundry:** Utilize the two separate compartments to pre-sort your laundry. Common sorting methods include separating lights from darks, or delicates from regular items.
- **Mobility:** To move the cart, unlock the two lockable wheels by pushing the lever up. Gently push or pull the cart to your desired location.
- **Stability:** To keep the cart stationary, push the lever down on the two lockable wheels to engage the brake.
- **Removing Bags:** When a bag is full or ready for washing, simply lift it by its handles from the frame. The bags are designed for easy removal and re-insertion.



Image: The laundry sorter in a bedroom setting, illustrating its convenient placement for daily clothes organization.



Image: The laundry sorter being used to store toys, highlighting its multifunctional capability beyond just laundry.

MAINTENANCE

Proper maintenance will extend the life of your laundry sorter.

- **Cleaning the Bags:** The non-woven fabric bags can be cleaned if they become dirty. They are removable and can be wiped down with a damp cloth or hand-washed with mild detergent. Allow to air dry completely before re-inserting into the frame.
- **Cleaning the Frame:** Wipe the metal frame with a soft, damp cloth as needed to remove dust or spills. Avoid abrasive cleaners that could damage the finish.
- **Wheel Maintenance:** Periodically check the wheels for any lint or debris that might hinder smooth rolling. Clean as necessary.



METAL NON-WOVEN FABRIC

THICKENED METAL PIPE, STRONG
AND NOT EASY TO BREAK
SMOOTH AND DURABLE, EASY TO CLEAN.

Image: A detailed view of the thickened metal pipes and non-woven fabric, highlighting their robust and easy-to-clean properties.

TROUBLESHOOTING

If you encounter any issues with your laundry sorter, please refer to the following common solutions:

- **Cart not rolling smoothly:** Check the wheels for any accumulated lint, hair, or debris. Clean the wheels thoroughly. Ensure the lockable wheels are in the unlocked position.
- **Cart is unstable:** Ensure all frame connections are securely tightened. Verify that the lockable wheels are engaged when you want the cart to remain stationary.
- **Bags not fitting correctly:** Ensure the bags are inserted into the correct sections and their handles are properly hooked onto the frame.

If problems persist, please contact customer support for assistance.

SPECIFICATIONS

Product Dimensions	21.96"L x 15.75"W x 32.67"H
Bag Dimensions (each)	9.44"L x 12.6"W x 20.28"H
Capacity	65 Liters
Material	Metal (Frame), Non-woven Fabric (Bags)
Color	Black
Model Number	9002
Special Features	Wheeled, Lockable Wheels, Removable Bags, 2 Compartments
Item Weight	6.25 pounds

-PRODUCT DIMENSION-



Image: A visual representation of the product dimensions, including height, length, and width in inches and centimeters.

WARRANTY AND SUPPORT

For any warranty claims, product support, or inquiries regarding your SUOERNUO Laundry Sorter Basket, please refer to the contact information provided with your purchase documentation or visit the official SUOERNUO store on Amazon.

SUOERNUO Store: [Visit SUOERNUO Store](#)

