

[Manuals.plus](#) /

› [Bedsure](#) /

› Bedsure GentleSoft Electric Blanket King Size Instruction Manual

Bedsure BS-500B-S

Bedsure GentleSoft Electric Blanket King Size Instruction Manual

Model: BS-500B-S

INTRODUCTION

Thank you for choosing the Bedsure GentleSoft Electric Blanket. This manual provides essential information for the safe and efficient use, maintenance, and care of your new electric blanket. Please read all instructions carefully before use and retain this manual for future reference.

IMPORTANT SAFEGUARDS

To reduce the risk of burns, electric shock, fire, or injury, please observe the following:

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if the blanket is wet.
- Do not use with a damaged cord or plug. If damaged, contact customer support.
- Do not use with pins or other metallic objects.
- Do not use folded, bunched, or tucked in. Ensure the blanket lies flat.
- Do not dry clean this product. Dry cleaning solvents may damage the insulation of the heating element.
- Always unplug the blanket from the electrical outlet when not in use.
- Keep the control unit away from drafts or open windows to prevent it from getting wet.
- This blanket is designed for household use only.

PACKAGE CONTENTS

- 1 Bedsure GentleSoft Electric Blanket (King Size, 90" x 100")
- 2 Dual Controllers

SETUP INSTRUCTIONS

1. **Unpack the Blanket:** Carefully remove the electric blanket and controllers from the packaging. Unfold the blanket completely.
2. **Position the Blanket:** Lay the electric blanket flat on your bed, ensuring it is evenly spread without any folds, creases, or bunching. The connectors for the controllers should be positioned at the foot of the bed.
3. **Connect the Controllers:** Locate the two connection ports at the foot of the blanket. Firmly plug each controller's cord into its respective port until it clicks securely into place. Ensure the connection is snug.
4. **Plug into Power:** Plug the power cords from both controllers into a standard 120V AC, 60Hz electrical outlet. Avoid using extension cords or power strips.



Image: The Bedsure GentleSoft Electric Blanket, folded, with its two controllers resting on top. This illustrates the blanket's texture and the appearance of the control units.



Image: The electric blanket fully spread out on a bed, showing the placement of the two controllers near the foot of the bed, ready for use.

OPERATING INSTRUCTIONS

Your Bedsure GentleSoft Electric Blanket features dual controls, allowing independent temperature and time settings for each side of the King size blanket.

Controller Functions:

- **Power Button:** Press to turn the blanket ON or OFF.
- **TEMP +/- Buttons:** Adjusts the heat level from 1 (Lo) to 10 (Hi).
- **TIME +/- Buttons:** Sets the operating time from 1 to 10 hours.
- **PREHEAT Button:** Activates a rapid heating function to quickly warm the blanket.

DUAL CONTROLLERS



**10 Time
Settings**



**10 Heating
Levels**



**Preheat
Function**

Image: A detailed view of the two individual controllers for the electric blanket. Each controller features a digital display, power button, temperature adjustment buttons, time adjustment buttons, and a preheat function button.

Using the Blanket:

1. **Turn On:** Press the Power button on your desired controller. The display will illuminate, typically defaulting to a low heat setting and an 8-hour timer.
2. **Adjust Heat:** Use the TEMP +/- buttons to select your preferred heat level (1-10). Level 1 is the lowest, and Level 10 is the highest.
3. **Set Timer:** Use the TIME +/- buttons to set the desired operating duration (1-10 hours). The blanket features an automatic 8-hour shut-off for safety, which is the default setting.
4. **Preheat Function:** For faster warming, press the PREHEAT button. This will quickly bring the blanket to a high temperature. Once sufficiently warm, you can adjust to your desired regular heat setting.
5. **Dual Control:** Each controller operates its respective side of the King size blanket independently. This allows two users to customize their warmth settings simultaneously.
6. **Turn Off:** Press the Power button again to turn off the blanket. Always unplug the blanket from the wall outlet when

not in use for extended periods.



Image: A couple sleeping in bed, each covered by a portion of the Bedsure electric blanket, illustrating the convenience of dual control for individual comfort.

MAINTENANCE AND CARE

Proper care ensures the longevity and performance of your electric blanket.

Washing Instructions:

- **Disconnect:** Always unplug the blanket from the wall outlet and detach both controllers from the blanket before washing. Ensure all cords are completely disconnected.
- **Pre-soak (Optional):** For best results, pre-soak the blanket for 15 minutes in mild soap and lukewarm water.
- **Machine Wash:** Machine wash on a gentle or delicate cycle in cold water (maximum 86°F / 30°C). Do not bleach. The unique dyeing technique helps prevent fading.
- **Rinse:** Rinse on a normal cycle.
- **Spin Dry:** Spin dry on a slow speed to remove excess water.

Drying Instructions:

- **Line Dry:** Drape the blanket over a clothesline or shower rod. Do not use clothespins on the heating wires.
- **Tumble Dry:** If using a dryer, tumble dry on a low heat setting for a maximum of 5 minutes. Remove while still damp and air dry completely. Do not iron.
- **Ensure Complete Dryness:** Ensure the blanket is completely dry before reconnecting the controllers and plugging it back in.

Storage:

When not in use, store the blanket loosely folded or rolled in a cool, dry place. Avoid placing heavy objects on top of the blanket, as this can damage the internal wiring.

TROUBLESHOOTING

If you encounter issues with your electric blanket, please refer to the following common solutions:

Problem	Possible Cause	Solution
Blanket not heating or controller not turning on.	Loose connection, power outage, or internal safety shut-off.	Ensure controllers are firmly plugged into the blanket and the wall outlet. Check if the outlet is functional. Unplug for 5 minutes, then plug back in to reset.
Blanket not warm enough on low settings.	Low heat setting selected.	Increase the heat level using the TEMP + button. For initial warmth, use the PREHEAT function. Note that electric blankets provide a gentle warmth, not intense heat.
Controller display is too bright.	No auto-dim feature on the controller.	Turn the controller upside down or cover the display to block the light if it is disruptive.
Timer setting resets or doesn't behave as expected after preheating.	Controller defaults to 8 hours and accounts for prior run time.	If you preheat and then want a specific shorter timer, turn the blanket OFF and then ON again after preheating. This resets the timer to 8 hours, allowing you to set your desired duration from that point.
Blanket feels too hot or overheats.	High heat setting, or safety feature activated.	Reduce the heat setting. The blanket has an automatic 8-hour shut-off and overheat protection. If it feels excessively hot, turn it off immediately and unplug it.



OVERHEAT PROTECTION

Automatically turns off by default after 8 hours.

Image: An illustration highlighting the overheat protection feature, which automatically shuts off the blanket after 8 hours of continuous operation for enhanced safety.


PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	BS-500B-S
Size	King (90"L x 100"W)
Color	Navy
Material	100% Polyester (240 GSM Flannel top, 200 GSM Sherpa bottom)
Heat Settings	10 Levels

Feature	Detail
Time Settings	10 Settings (1-10 hours)
Auto Shut-Off	8 Hours (default)
Controllers	2 (Dual Control)
Power Input	120V AC, 60Hz (Dual 110W controllers)
Special Features	Preheat Function, Overheat Protection, ETL & FCC Certified, Machine Washable
Item Weight	9.61 pounds




Image: A cross-section diagram illustrating the construction of the blanket, featuring a 240 GSM flannel top layer, PTC/NTC heating wires, and a 200 GSM sherpa bottom layer.



ELONGATED INSULATED HEATING WIRES

Bedsure



Others






Image: This graphic compares Bedsure's elongated insulated heating wires, designed for improved safety and reliability, with standard heating wires. It also includes a graph showing the temperature rise over time.

SIZING REFERENCE-KING



PLEASE NOTE

The color of this product may appear slightly different on various monitors, but we believe it will exceed your expectations upon unboxing.

TIPS

For use with the included controller ONLY. Please do not use any other controller for this blanket. Please make sure that the MODEL NUMBER on the blanket's care label matches the MODEL NUMBER on the back of the controller.



Image: A sizing reference chart displaying the dimensions of Twin, Queen, and King size electric blankets, including the 90x100 inch King size model.

WARRANTY AND SUPPORT

Bedsure is committed to providing quality products. For any questions, concerns, or support needs regarding your Bedsure GentleSoft Electric Blanket, please contact Bedsure customer service. While specific warranty details are not provided in this manual, Bedsure typically offers support for product defects and operational issues. You can find more information and contact details by visiting the official Bedsure Store online.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BZY62ZD3>

More documents and user manuals: <https://manuals.plus/>