

[Manuals.plus](#) /

› [MIATONE](#) /

› MIATONE LONDON Wireless Bluetooth Earbuds User Manual

MIATONE LONDON

MIATONE LONDON Wireless Bluetooth Earbuds User Manual

Model: LONDON | ASIN: B0BZYGYMK

1. INTRODUCTION

Thank you for choosing MIATONE LONDON Wireless Bluetooth Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

2. PACKAGE CONTENTS

Please check the package for the following items:

- MIATONE LONDON Wireless Bluetooth Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Cushions (various sizes)
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your MIATONE LONDON earbuds and charging case.



Image: MIATONE LONDON Wireless Bluetooth Earbuds securely placed within their charging case, displaying the brand logo on the front.

ONE STEP PAIRING

STEP 1: UPON TAKING EARBUDS OUT, THEY WILL AUTOMATICALLY POWER ON.
STEP 2: OPEN THE BLUETOOTH SETTINGS ON YOUR PHONE AND SELECT <MIATONE LONDON>.



Image: The MIATONE LONDON earbuds removed from their charging case, showcasing their individual design and form factor.

4. SETUP

4.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

- Place the earbuds into the charging case.
- Connect the USB-C charging cable to the charging port on the case and to a power source (e.g., computer USB port, wall adapter).
- The indicator light on the charging case will show charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.




Image: The MIATONE LONDON earbuds in their charging case, connected via a USB-C cable, illustrating the charging process and indicating battery life.

4.2. Pairing with a Bluetooth Device

The earbuds feature one-step pairing for convenience.

1. **Step 1:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Step 2:** On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. **Step 3:** Select "MIATONE LONDON" from the list of found devices to connect.
4. Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.



Image: A smartphone screen displaying Bluetooth settings with "Miatone London" selected as a connected device, alongside the open earbud charging case.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off. Alternatively, disconnect Bluetooth and the earbuds will power off after 5 minutes of inactivity, or press and hold the touch control area on both earbuds for 5 seconds.

5.2. Wearing the Earbuds

For optimal sound quality and comfort, choose the correct ear cushion size and insert the earbuds gently

into your ear canal. Adjust them until they feel secure and comfortable.




Image: A person smiling and wearing the MIATONE LONDON earbuds, demonstrating a secure and comfortable fit during activity.

5.3. Touch Controls

The MIATONE LONDON earbuds feature intuitive touch controls on each earbud. The functions are as follows:



Image: A diagram illustrating the touch control functions for both the left (L) and right (R) MIATONE LONDON earbuds, detailing single tap, double tap, triple tap, and long press actions for media playback, call management, and voice assistant activation.

- **Play/Pause:** Tap once (L or R earbud).
- **Answer Call:** Tap once (L or R earbud).
- **End Call:** Tap twice (L or R earbud).
- **Reject Call:** Press and hold for 2 seconds (L or R earbud).
- **Volume Down:** Tap twice (L earbud).
- **Volume Up:** Tap twice (R earbud).
- **Previous Track:** Press and hold for 2 seconds (L earbud).
- **Next Track:** Press and hold for 2 seconds (R earbud).
- **Activate Voice Assistant (Siri/Google Assistant/Bixby):** Tap three times (L or R earbud).

6. MAINTENANCE

6.1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the earbud mesh and charging contacts using a dry cotton swab or a small, soft brush.

6.2. Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.

6.3. Water Resistance (IPX7)

The MIATONE LONDON earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for workouts and outdoor activities where they might be exposed to sweat or light rain. However, they are not designed for swimming or prolonged submersion.

- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.
- The charging case is **not** waterproof.



Image: A person wearing MIATONE LONDON earbuds while being splashed with water, demonstrating the earbuds' sweat and water-resistant capabilities.

7. TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing	• Ensure earbuds are charged. • Make sure Bluetooth is enabled on your device. • Forget "MIATONE LONDON" in your device's Bluetooth settings and re-pair. • Place earbuds back in the case, close the lid, wait 5 seconds, then open to re-enter pairing mode.
No sound or low volume	• Check device volume and earbud volume. • Ensure earbuds are properly connected to your device. • Clean any debris from the earbud mesh.
Earbuds not charging	• Ensure the charging cable is securely connected. • Check the charging port and contacts for any obstructions. • Try a different USB-C cable or power source.

Problem	Solution
One earbud has no sound	• Place both earbuds back into the charging case, close the lid, then open it again. • Try re-pairing the earbuds with your device.

8. SPECIFICATIONS

Detailed technical specifications for the MIATONE LONDON Wireless Bluetooth Earbuds:

- **Model Name:** LONDON
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Version:** 5.3
- **Form Factor:** In Ear
- **Control Method:** Touch
- **Waterproof Rating:** IPX7
- **Playtime (Single Charge):** Up to 9 hours
- **Total Playtime (with Charging Case):** Up to 50 hours
- **Special Features:** Bluetooth 5.3, IPX7 Waterproof, Microphone Included
- **Material:** Composite
- **Item Weight:** Approximately 0.028 ounces (per earbud)
- **Manufacturer:** MIATONE



Image: A detailed diagram highlighting the internal Bluetooth 5.3 chip within a MIATONE LONDON earbud, emphasizing features like stable connection, lower power consumption, longer transmission range, and lower latency.




Image: An exploded view diagram of the MIATONE LONDON earbud's internal components, focusing on the titanium diaphragm dynamic driver and acoustic technology for immersive stereo sound.



Image: A person engaged in a video call while wearing MIATONE LONDON earbuds, illustrating the clear call quality provided by the integrated microphone and sound enhancement technology.

9. WARRANTY AND SUPPORT

MIATONE products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the MIATONE official website or your purchase platform. Please have your product model (LONDON) and ASIN (B0BZYGYMK) ready when contacting support.