

DONGFXK S2-grey 30" W x 72" H

DONGFXK Motorized Blinds User Manual

Model: S2-grey 30" W x 72" H

[Introduction](#) [What's Included](#) [Installation](#) [Operation](#) [Battery Replacement](#) [Care & Maintenance](#) [Safety](#) [Specifications](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing DONGFXK Motorized Blinds. This manual provides detailed instructions for the installation, operation, and maintenance of your new blackout roller shades. Please read this manual thoroughly before use to ensure proper function and longevity of your product.

These smart roller shades feature a no-drill, cordless design for easy installation and are controlled via remote. They are designed to provide 100% blackout, effective UV protection, and noise reduction, making them suitable for various rooms including bedrooms, living rooms, bathrooms, and offices.

2. WHAT'S INCLUDED

Upon unboxing, please verify that all components are present:

- Motorized Roller Shade (S2-grey, 30" W x 72" H)
- Single-channel Remote Control
- Mounting Hardware (brackets, screws, silicone pads)
- Hex Key (for safety lock)
- 6 AA Batteries (pre-installed or included separately)
- User Manual

Smart Blinds



6 AA batteries (included)



Noise<40db



Use for 4-6 months

Remote Control

1-channel remote (included)
15-channel remote (optional)



Voice Control

hub(optional)



App Control

hub(optional)




Image: All components of the DONGFXK Motorized Blinds, including the roller shade, remote control, and installation instructions.



Image: A close-up view of the roller shade and the included remote control.

3. INSTALLATION

3.1. Measuring Your Window

Accurate measurements are crucial for proper fit and function. Refer to the diagrams below for inside and outside mount measurements.

NO DRILL BLINDS

1. Place the end with the no-drill device to the left side of the window frame

2. If there is a gap between the top raila and the window frame, use a silicone pad to stick to the right side of the top rail and then push the right side of the smart blind

3. After installation, please do not forget to fasten non-drill device.

ACCESSORY




Image: Detailed diagrams illustrating how to measure window width and height for both inside and outside mount installations.



Image: Another diagram detailing measurement for inside and outside mounts, including window depth considerations.

3.2. No-Drill Installation (Inside Mount)

The DONGFXK motorized roller shades feature a no-drill design, ideal for quick installation without damaging walls. This method is primarily for inside mounts.

1. Place the end of the blind with the no-drill device against the left side of the window frame.
2. If there is a gap between the top rail and the window frame, use a silicone pad to secure it to the right side of the top rail. Then, push the right side of the smart blind into place.
3. After installation, fasten the non-drill device using the provided hex key to ensure the blind is securely in place.




Image: Step-by-step visual guide for no-drill installation, showing placement, securing with a silicone pad, and tightening the safety lock.

3.3. Video Installation Guide

For a visual demonstration of the installation process, please watch the official video below:

Your browser does not support the video tag.

Video: Official installation guide for DONGFXK No Drill Motorized Blinds with Remote Control. This video demonstrates the quick and easy

setup process.

4. OPERATION

4.1. Remote Control

Your smart blinds come with a single-channel remote control for basic up/down operation. An optional 15-channel remote (not included) can control multiple blinds simultaneously.



Image: Overview of smart control options including remote, voice, and app control.

HOW TO MEASURE

Adjustable height range of shades. 72" high shades are suitable for windows of 0-72"



Image: Illustration of single-channel remote controlling one blind and an optional 15-channel remote controlling multiple blinds.

4.2. Smart Control (Optional Hub Required)

To enable app control and voice commands via smart devices (e.g., smartphone, smart speaker), an optional hub (not included) is required. Connect the hub to your smart home system to integrate the blinds.



Image: Demonstrates the use of an optional hub for smart control via app or voice commands with devices like Alexa.

4.3. Operation Demonstration Video

See the motorized blinds in action, demonstrating their quiet operation and blackout capabilities:

Your browser does not support the video tag.

Video: Animation demonstrating the quiet operation and blackout function of the motorized blinds in a living room setting.

5. BATTERY REPLACEMENT

The blinds are powered by 6 AA batteries (included). Batteries typically last 4-6 months. The top-mounted battery compartment allows for easy, hassle-free replacement.

1. Roll up the blinds completely and lay them flat on a stable surface.
2. Slide the protruding board aside to reveal the battery compartment.
3. Pull out the battery box and replace the 6 AA dry batteries.

4. Install the battery box back into the valance, ensuring it clicks into place.




Image: Step-by-step guide for replacing the 6 AA batteries in the motorized blinds.

6. CARE AND MAINTENANCE

To maintain the appearance and functionality of your DONGFXK Motorized Blinds:

- **Spot Clean Only:** For cleaning, use a soft, damp cloth to gently spot clean any soiled areas. Do not immerse the blinds in water or use harsh chemical cleaners.
- Regularly check the battery compartment and replace batteries as needed (approximately every 4-6 months).
- Ensure the blinds operate smoothly and are free from obstructions.

7. SAFETY INFORMATION

Your DONGFXK Motorized Blinds are designed with safety in mind:

- **Cordless Design:** The cordless operation ensures safety for children and pets by eliminating hazardous cords.
- **Anti-Tangle Mechanism:** Designed to prevent tangling during operation.
- Always ensure the safety lock is tightened after installation.
- Keep the remote control out of reach of small children to prevent unintended operation.



Image: Safety features of the motorized blinds, emphasizing their cordless, anti-tangle, and child/pet-safe design.

8. SPECIFICATIONS

Feature	Detail
Brand	DONGFXK
Model Number	e01abcf6-1809-427e-83a5-9f85d2f2ee19
Product Dimensions	72"L x 30"W
Size	30" W x 72" H
Color	S2-grey
Material	Polyester

Feature	Detail
Opacity	Blackout
Operation Mode	Automatic
Special Feature	Motorized
Control Type	Remote
Mounting Type	Inside Mount, Outside Mount
Batteries	6 AA batteries required (included)
Item Weight	3.99 pounds (1.81 Kilograms)
Product Care Instructions	Spot Clean Only
Recommended Uses	Indoor (Bedroom, Living Room, Bathroom, Office, Children's Room, Study Room)

9. TROUBLESHOOTING

If you encounter issues with your motorized blinds, please refer to the following common solutions:

- **Blinds not responding to remote:**
 - Check if the remote control batteries need replacement.
 - Ensure the remote is within range and pointed towards the blind's receiver.
 - Verify that the blind's batteries are correctly installed and charged.
- **Blinds not moving smoothly:**
 - Check for any obstructions in the window frame or along the blind's path.
 - Ensure the blind is properly installed and level.
- **Difficulty setting upper/lower limits:**
 - Refer to the detailed programming instructions in the included user manual for remote limit setting.
- **Noise during operation:**
 - A silent wave motor is designed for quiet operation (Noise < 40dB). If excessive noise occurs, check for obstructions or loose components.

If problems persist, please contact customer support for assistance.

10. WARRANTY AND SUPPORT

DONGFXK is committed to providing quality products and excellent customer service.

- **Warranty:** Your DONGFXK automatic blinds come with a 2-year warranty.
- **Repair & Replacement Policy:** A 60-day repair and replacement policy is included.
- **Custom Service:** We offer custom selection based on different window sizes.
- **Contact Support:** For any questions, issues, or custom service requests, please contact DONGFXK customer support. Refer to the contact information provided in your product packaging or on the official DONGFXK website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question