

[Manuals.plus](#) /

> [Aiwa](#) /

> Aiwa AWSBH1 Soundbar User Manual

Aiwa AWSBH1

Aiwa AWSBH1 Soundbar User Manual

Model: AWSBH1

INTRODUCTION

The Aiwa AWSBH1 Soundbar is an exceptional option designed to enhance your home audio experience. This soundbar combines power, versatile connectivity, and an elegant design to deliver high-quality sound for your favorite movies, series, and music. This manual provides detailed instructions for setting up, operating, and maintaining your Aiwa AWSBH1 Soundbar.



Image: Front view of the Aiwa AWSBH1 Soundbar, showcasing its sleek, black design.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in the package:

- 1 x Aiwa AWSBH1 Soundbar
- 1 x User Manual
- Power Cable
- Remote Control
- Audio Cables (e.g., AUX cable)

BARRA DE SONIDO SOUND BAR



AWSBH1

aiwa

Image: The Aiwa AWSBH1 Soundbar as it appears in its packaging, highlighting the product name.

SETUP GUIDE

1. Placement

Place the soundbar on a stable, flat surface directly in front of your television or display. Ensure there are no obstructions in front of the speakers for optimal sound delivery. The soundbar is designed for tabletop mounting.

2. Connections

Connect the soundbar to your power source using the provided power cable. The soundbar supports multiple input options:

- **USB Input:** For playing audio files directly from a USB drive.
- **AUX Input:** For connecting devices via a 3.5mm audio cable.
- **Optical Input:** For high-quality digital audio connection from your TV or other devices.
- **Coaxial Input:** Another digital audio input option.
- **HDMI (ARC) Input:** For simplified audio connection and control with compatible TVs.

Refer to the back panel of the soundbar for port locations.



Image: Rear view of the Aiwa AWSBH1 Soundbar, detailing the various input ports available for connection.

Your browser does not support the video tag.

Video: A demonstration of unboxing and connecting the Aiwa AWSBH1 Soundbar to a television, showcasing the ease of setup and various connection options.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the power button on the soundbar or remote control to turn the unit on or off. An indicator light will confirm the power status.

2. Input Selection

Use the "Input" or "Source" button on the remote control or soundbar to cycle through available input modes (Bluetooth, USB, AUX, Optical, Coaxial, HDMI ARC).

3. Bluetooth Connection

To connect via Bluetooth:

1. Switch the soundbar to Bluetooth mode.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "AWSBH1" in your device's Bluetooth settings and select it to pair.
4. Once paired, you can stream audio wirelessly to the soundbar. The Bluetooth range is approximately 18 meters.



Image: The Aiwa AWSBH1 Soundbar demonstrating its wireless Bluetooth connectivity with a smartphone.

4. USB Playback

Insert a USB drive containing MP3 or WAV audio files into the USB port. The soundbar will automatically switch to USB mode and begin playback. Use the remote control to navigate tracks.

5. Sound Equalizer

The soundbar features a built-in sound equalizer with preset modes to optimize audio for different content types (e.g., Movie, Music, News). Use the EQ button on the remote control to cycle through these modes.



Sonido nítido y claro con graves profundos

Image: The Aiwa AWSBH1 Soundbar positioned beneath a television, emphasizing its ability to deliver crisp and clear sound with deep bass.



Image: The Aiwa AWSBH1 Soundbar integrated into a home entertainment setup, highlighting its 40W power, 2.0 channel configuration, and versatile connectivity options including MP3, AUX, and USB.

MAINTENANCE

To ensure the longevity and optimal performance of your soundbar, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the soundbar's ventilation openings are not blocked to prevent overheating.
- **Storage:** If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your Aiwa AWSBH1 Soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power	Power cable not connected; Power outlet not working.	Ensure power cable is securely connected. Try a different power outlet.
No Sound	Incorrect input selected; Volume too low; Audio cable loose/damaged.	Select the correct input source. Increase volume. Check audio cable connections.

Problem	Possible Cause	Solution
Bluetooth Disconnection	Device out of range; Interference.	Move device closer to the soundbar. Avoid placing soundbar near other wireless devices. Re-pair the device.
USB Playback Issues	Unsupported file format; USB drive corrupted.	Ensure files are MP3 or WAV. Try a different USB drive or reformat the current one.

If the issue persists after trying these solutions, please contact Aiwa customer support.

SPECIFICATIONS

Feature	Detail
Brand	Aiwa
Model Name	AWSBH1
RMS Power	40W
PMPO Power	120W
Speaker Configuration	2.0 Channel with 4 speakers
Connectivity	Bluetooth, USB, AUX, Optical, Coaxial, HDMI (ARC)
Bluetooth Range	Up to 18m
Supported Audio Formats	MP3, WAV
Special Features	Sound Equalizer
Power Source	Wired Electric
Dimensions (H x D x W)	6 cm x 6.50 cm x 94 cm (Unit) / 15 x 13 x 104 cm (Product)
Weight	3 kg
Mounting Type	Tabletop Mount

WARRANTY AND SUPPORT

Your Aiwa AWSBH1 Soundbar comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Aiwa customer service through their official website or the contact information provided in your product documentation.

Keep your purchase receipt as proof of purchase for warranty purposes.

