

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

**FINGERTIME FINGERTIME-P1**

# FINGERTIME Bluetooth Headphones Over-Ear Instruction Manual

Model: FINGERTIME-P1

Brand: FINGERTIME

## INTRODUCTION

---

Thank you for choosing FINGERTIME Bluetooth Headphones. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new headphones, ensuring you get the best audio experience. These over-ear headphones offer high-fidelity audio, low-latency game mode, and extended playtime, designed for comfort and versatility.



*FINGERTIME Bluetooth Over-Ear Headphones in black, showcasing their sleek design.*

## **PACKAGE CONTENTS**

---

Please check the package for the following items:

- Foldable Deep Bass Headphone
- 3.5mm backup audio cable
- USB charging cable
- User Manual (this document)

## **PRODUCT OVERVIEW**

---

Familiarize yourself with the various parts and controls of your FINGERTIME headphones.



*Detailed view of the headphone controls and ports.*

1. Power Button: ON/OFF, Music Mode/Game Mode switch
2. Volume Up Button: Short press for increasing volume, long press for next song
3. Volume Down Button: Short press for reducing volume, long press for previous song
4. Multi-function Button: Short press for Play/Pause, Answer Calls/Hang off calls; Long press for Reject Calls
5. 3.5mm Audio Interface
6. Type-C Charging Interface
7. LED Indicator
8. Dust Cover



## **BRUSHED CD TEXTURE METAL SHEET**

Unique design & Distinctiveness

*Brushed CD Texture Metal Sheet for unique design.*

**ULTRA-SOFT  
PROTEIN LEATHER  
EARCUPS**



*Ultra-Soft Protein Leather Earcups for comfort.*



## 40MM DRIVERS

### High-Resolution Audio

*40mm Acoustic Stereo Drivers for HiFi Audio.*

## SETUP

---

### 1. Charging the Headphones

Before first use, fully charge your headphones. A full charge provides up to 60 hours of playtime.

- Connect the included USB charging cable to the Type-C Charging Interface (6) on the headphones and to a USB power source (e.g., computer USB port, wall adapter).
- The LED Indicator (7) will show charging status. It typically turns off or changes color when fully charged.
- **Quick Charge Feature:** A 10-minute charge can provide up to 2 hours of listening time.

## 500mAh Super Large Battery Capacity

Up to 55 hours working time  
Fast Charging Technology  
charge 10 minutes=Up to 2 hours of listening time



 UP TO 55hrs  
Quick charging  
 10 minutes =  2 hrs

*The headphones feature a 500mAh battery for extended playtime and fast charging capabilities.*

## 2. Bluetooth Pairing

Pair your headphones with your Bluetooth-enabled device (smartphone, tablet, laptop, desktop).

- **Power On:** Long press the Power Button (1) until the LED Indicator (7) flashes, indicating pairing mode.
- **Activate Bluetooth:** On your device, go to Bluetooth settings and turn on Bluetooth.
- **Select Device:** Look for "FINGERTIME-P1" or a similar name in the list of available devices and select it to connect.
- **Confirmation:** The LED Indicator (7) will stop flashing and remain solid (or turn off, depending on model) once successfully paired.

## BLUETOOTH 5.3 & LOW LATENCY MODE



*Equipped with advanced Bluetooth 5.3 technology for stable and fast connections.*

**Multi-Device Connection:** These headphones can be paired with two devices simultaneously, allowing seamless switching between them.

# UNIVERSAL COMPATIBILITY: ANDROID & IOS



*Universal compatibility with Android and iOS devices.*

### 3. Wired Connection (3.5mm Audio Cable)

For devices without Bluetooth or when the battery is low, use the included 3.5mm audio cable.

- Plug one end of the 3.5mm audio cable into the 3.5mm Audio Interface (5) on the headphones.
- Plug the other end into the audio jack of your device.
- The headphones will automatically switch to wired mode. Note that some headphone functions (like volume control on the headphones) may be disabled in wired mode, and you will control volume directly from your device.

## OPERATING INSTRUCTIONS

---

### Power On/Off


- **Power On:** Long press the Power Button (1) for approximately 3 seconds. The LED indicator will light up.
- **Power Off:** Long press the Power Button (1) for approximately 3 seconds. The LED indicator will turn off.

## Music Playback

- **Play/Pause:** Short press the Multi-function Button (4).
- **Volume Up:** Short press the Volume Up Button (2).
- **Volume Down:** Short press the Volume Down Button (3).
- **Next Song:** Long press the Volume Up Button (2).
- **Previous Song:** Long press the Volume Down Button (3).

## Call Management

- **Answer/End Call:** Short press the Multi-function Button (4) when a call comes in or during a call.
- **Reject Call:** Long press the Multi-function Button (4) when a call comes in.
- **Voice Assistant:** (If supported by device) Double-press the Multi-function Button (4).




*ENC Call Noise Reduction ensures clear communication.*

## Game Mode (Low Latency)

Activate Game Mode for ultra-low latency audio, ideal for gaming and video content where audio-visual synchronization is critical.

- **Switch Mode:** Short press the Power Button (1) to toggle between Music Mode and Game Mode.
- In Game Mode, the headphones achieve a low latency of 40ms, significantly reducing audio delay.



## GAME MODE

40ms ultra-low delay audio & video synchronization

*Game Mode provides 40ms ultra-low delay for improved audio and video synchronization.*

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents. For earcups, gently wipe with a damp cloth and allow to air dry completely before use.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The headphones are foldable for easy storage and portability.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not used for extended periods.

- **Avoid Water:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.



*The foldable design makes the headphones a perfect travel partner.*

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully using the provided USB cable.
Cannot pair with device.	Bluetooth is off on device; headphones not in pairing mode; too far from device.	Ensure Bluetooth is enabled on your device. Long press the Power Button (1) to enter pairing mode. Move headphones closer to the device (within 10 meters).
No sound or low volume.	Volume too low on headphones or device; incorrect audio output selected; headphones not connected.	Increase volume on both headphones and your device. Check if headphones are properly connected via Bluetooth or 3.5mm cable. Ensure the correct audio output is selected on your device.
Audio cuts in and out.	Interference; device too far; low battery.	Move closer to your device. Avoid strong electromagnetic interference. Charge the headphones.
Microphone not working.	Incorrect input device selected on computer/device.	Check your device's audio settings and ensure the headphones are selected as the input device.

## SPECIFICATIONS

**Model Name:** P1 (FINGERTIME-P1)

**Connectivity Technology:** Wireless (Bluetooth), Wired (3.5mm)

**Wireless Communication Technology:** Bluetooth 5.3

**Bluetooth Range:** 10 Meters

**Ear Placement:** Over Ear

**Audio Driver Type:** Dynamic Driver

**Driver Size:** 40mm

**Frequency Range:** 20Hz - 20,000Hz

**Impedance:** 32 Ohm

**Battery Life:** Up to 60 Hours (Playtime)

**Charging Interface:** Type-C

**Noise Control:** Sound Isolation, ENC Call Noise Reduction

**Special Features:** Adjustable Headband, Foldable, Microphone Included, Low Latency Game Mode

**Material:** Plastic (Headphones), Protein Leather (Earcups)

**Item Weight:** 13.4 ounces (0.38 Kilograms)

**Compatible Devices:** Bluetooth-enabled devices (Smartphones, Tablets, Laptops, Desktops)

## WARRANTY AND SUPPORT

FINGERTIME provides lifetime worry-free user support for your headphones. If you have any questions or encounter any issues with your product, please do not hesitate to contact us. We are committed to replying within 24 hours to assist you. For support, please refer to the contact information provided in your product packaging or visit the official FINGERTIME website.



© 2025 FINGERTIME. All rights reserved.

## Related Documents

	<p><a href="#">Fingertime ANCO1 Fashion Bluetooth Headset User Manual</a></p> <p>User manual for the Fingertime ANCO1 Fashion Bluetooth Headset, detailing product parameters, button operations, modes, and FCC statements.</p>
	<p><a href="#">Fingertime Removal Service Terms and Conditions for Electrical Appliances</a></p> <p>Official terms and conditions for Fingertime's free removal service of used regulated electrical appliances (REE) in Hong Kong, as per the Producer Eco-Responsibility Ordinance. Includes details on service timing, location, and customer responsibilities.</p>