

[Manuals.plus](#) /

› [Heybly](#) /

› Heybly HLR006B1 Folding Luggage Rack with Laundry Bag Instruction Manual

Heybly HLR006B1

Heybly HLR006B1 Folding Luggage Rack with Laundry Bag Instruction Manual

Model: HLR006B1

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or product damage.

- Do not exceed the maximum static weight capacity of 100 lb (45.5 kg).
- Ensure all parts are securely fastened before use.
- Keep children and pets away from the product during assembly.
- Use on a flat, stable surface to prevent tipping.
- Avoid placing hot items directly on the fabric components.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1 x Heybly Luggage Rack (HLR006B1)
- 1 x Laundry Bag/Storage Compartment
- Assembly Hardware (pre-installed or integrated)
- 1 x Instruction Manual



Image: The Heybly HLR006B1 Folding Luggage Rack, fully assembled, showcasing its black steel frame and fabric storage compartments.

3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Heybly Luggage Rack. No additional tools are required beyond what is provided.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Refer to the package contents list to ensure all items are present.
2. **Extend Frame:** Gently pull the sides of the X-shaped steel frame apart until it is fully extended and stable. Ensure the legs are oriented correctly for the rack to stand upright. The frame is designed to unfold easily.
3. **Attach Top Straps:** The strong nylon straps are typically pre-attached to the top bars of the frame. Ensure they are taut and securely fastened, forming the surface for luggage placement. If detached, re-attach them using the integrated fasteners.
4. **Install Storage Compartment:** Attach the fabric storage compartment (laundry bag) to the lower section of the frame. Use the provided Velcro fasteners to secure it firmly to the support rods. Ensure the compartments are correctly aligned and fully extended.
5. **Verify Stability:** Once assembled, gently shake the rack to ensure all connections are secure and the unit is stable on a flat surface.



Image: A close-up view of the X-shaped steel frame, highlighting its structural design for stability.



Image: A detailed view of the fabric storage compartment, showing its two sections and how it attaches to the frame with Velcro.

4. OPERATING INSTRUCTIONS

4.1 Using the Luggage Rack

Place your suitcase or travel bag on the top straps of the rack. The elevated position allows for easier access to your belongings without bending or placing luggage on furniture. Ensure the weight is evenly distributed and does not exceed the maximum capacity.



Image: A silver suitcase resting on the top straps of the luggage rack, demonstrating its primary use.

4.2 Utilizing the Storage Compartment

The integrated fabric compartment offers two sections:

- **Laundry Bag Section:** Use the larger section for storing dirty clothes, keeping them separate from clean items.
- **Shelf Section:** The smaller, shelved section can be used for shoes, toiletries, or other small items.



Image: The luggage rack with its fabric storage compartments, one side holding folded clothes and the other a laundry bag.

4.3 Folding for Storage

To fold the luggage rack for compact storage:

1. Remove any items from the top and the storage compartment.
2. Unfasten the Velcro tabs securing the fabric storage compartment to the lower frame.
3. Gently push the sides of the X-frame inward until the rack folds flat.
4. Re-fasten the Velcro tabs if desired to keep the fabric compartment neatly folded with the frame.

The racks are very lightweight and fold up for easy, compact storage



Image: A side-by-side comparison showing the luggage rack in its open, ready-to-use state and its compact, folded state for storage.

5. MAINTENANCE

- **Cleaning the Frame:** Wipe the steel frame with a damp cloth and mild detergent. Dry thoroughly to prevent rust.
- **Cleaning the Fabric:** The fabric storage compartment can be spot cleaned with a damp cloth and mild soap. Allow to air dry completely. Do not machine wash or tumble dry.
- **Regular Inspection:** Periodically check all connections and fasteners to ensure they remain tight and secure.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack is unstable or wobbly.	Loose connections; uneven surface.	Ensure all frame connections are secure. Move the rack to a flat, level surface.
Fabric compartment sags.	Overloaded; Velcro straps not securely fastened.	Do not exceed the weight capacity of the compartment. Re-fasten Velcro straps firmly.

Problem	Possible Cause	Solution
Difficulty folding the rack.	Items still in compartment; frame obstruction.	Remove all items. Ensure no fabric or other objects are obstructing the folding mechanism.

7. SPECIFICATIONS

Feature	Detail
Model Number	HLR006B1
Color	Black
Material	Alloy Steel Tubes, Nylon Straps
Overall Size (Unfolded)	23.62" L x 14.57" W x 24.21" H (Approx. 60 cm L x 37 cm W x 61.5 cm H)
Folded Size	23.63" L x 2.56" W x 28.35" H (Approx. 60 cm L x 6.5 cm W x 72 cm H)
Item Weight	7.73 lbs (3.5 kg)
Max. Static Weight Capacity	100 lbs (45.5 kg)
Special Feature	Foldable design, Integrated Laundry Bag/Storage
Assembly Required	Yes




Image: Technical drawing illustrating the key dimensions of the Heybly HLR006B1 luggage rack in both its open and folded configurations.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Heybly website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question