

## HOTBEST A

# HOTBEST Large Bean Bag Chair Sofa Cover (No Filler) - Model A

Instruction Manual

## 1. INTRODUCTION

---

This manual provides instructions for the assembly, use, and care of your HOTBEST Large Bean Bag Chair Sofa Cover, Model A. This product is designed to be filled with your choice of soft materials, such as foam particles, stuffed animals, blankets, or old clothes, to create a comfortable seating solution. Please read these instructions carefully before use.




Image 1.1: The HOTBEST Large Bean Bag Chair Sofa Cover in Grey.

## 2. PARTS LIST

---

The HOTBEST Large Bean Bag Chair Sofa Cover package includes the following:

- 1 x Bean Bag Cover (Grey, 3.3 x 3.9 ft)
- Note: Filler material is NOT included and must be purchased separately.



This product does not contain fillers, can be filled with soft things in DIY, easy to disassemble and wash sofa and decoration

Image 2.1: The bean bag cover features a durable zipper and a convenient carrying handle.

### 3. SETUP INSTRUCTIONS

Follow these steps to properly fill your bean bag chair cover:

1. **Unpack the Cover:** Carefully remove the bean bag cover from its packaging.
2. **Locate the Zipper:** Find the zipper located on the bottom or side of the cover.
3. **Open the Zipper:** Unzip the cover completely to reveal the inner lining and opening for filler.
4. **Prepare Filler:** Have your chosen filler material (e.g., foam particles, stuffed animals, blankets) ready.
5. **Insert Filler:** Begin carefully pouring or placing the filler material into the bean bag cover. If using foam particles, it is recommended to use a separate "change bag" or liner to contain the particles and prevent spills during filling.
6. **Distribute Evenly:** Gently shake and adjust the cover to distribute the filler evenly, ensuring a comfortable and supportive shape.
7. **Close the Zipper:** Once filled to your desired firmness, securely close the zipper.




Image 3.1: Visual guide for filling the bean bag cover. Steps include opening the package, unzipping the cover, inserting filler particles (with a change bag), and completing the filling process.

For a visual demonstration of the cover's features and zipper mechanism, please watch the following video:

Your browser does not support the video tag.

Video 3.1: This video demonstrates the features of the bean bag cover, including the zipper and handle, and how to access the interior for filling.

## 4. OPERATING INSTRUCTIONS

Once filled, your bean bag chair cover is ready for use. The ergonomic design supports your body for comfortable seating.

- **Seating:** Sit comfortably on the bean bag, allowing the filler to conform to your body shape.
- **Repositioning:** Use the integrated handle to easily move the bean bag to different locations within your home or garden.
- **Storage:** The large capacity allows for storing various items like stuffed animals, blankets, or old clothes, helping to keep your space tidy.

**Ergonomic design, perfectly supporting your body and comfortable to seat.**



Image 4.1: The bean bag cover, once filled, provides ergonomic support for comfortable seating.

consejos: usar ropa de cama, cojines y ropa



También puede poner las partículas de espuma según lo necesite



Image 4.2: The bean bag cover can also serve as a storage solution for items like stuffed animals.

## 5. MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your bean bag cover, please follow these care instructions:

- **Washing:** The cover is machine washable. Remove all filler before washing. Use cold water on a gentle cycle.
- **Drying:** Tumble dry on low heat or air dry. Avoid high heat to prevent shrinking or damage to the fabric.
- **Stain Removal:** For minor stains, spot clean with a mild detergent and damp cloth.
- **Zipper Care:** Ensure the zipper is fully closed before washing. Avoid pulling the zipper aggressively.



Image 5.1: The soft and durable fabric of the bean bag cover is designed for easy maintenance.

## 6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	HOTBEST
Model Number	A
Material	Cloth
Color	Grey
Size (XL)	100 x 120 cm (approximately 3.3 x 3.9 ft)
Closure Type	Zipper
Special Feature	Durability, Machine Washable, Integrated Handle
Item Weight	Approximately 16 ounces (cover only)

Product Dimensions

Approximately 3.3 x 3.3 x 79.2 inches (unfilled, as per product data)



Size	L	H
S	70CM	80CM
M	80CM	90CM
XL	100CM	120CM

Image 6.1: Size chart indicating dimensions for different bean bag cover sizes.

## 7. TROUBLESHOOTING

- **Difficulty Filling:** Ensure the zipper is fully open. For fine fillers like foam particles, consider using a funnel or a separate liner bag to minimize mess.
- **Bean Bag Feels Flat:** Add more filler material to achieve desired firmness and shape.
- **Zipper Issues:** If the zipper is stiff, apply a small amount of zipper lubricant or rub a pencil lead along the teeth. Avoid forcing the zipper.
- **Cover Wrinkled:** Lightly steam or iron on a low setting, or allow the cover to naturally smooth out with use.

## 8. WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the retailer's policy where the product was purchased or contact HOTBEST customer service directly. Contact details can typically be found on the product packaging or the official HOTBEST website.