Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HMHAMA S5 T6 T7

HMHAMA Replacement Tires for Roborock S5, T6, T7, Mijia 1S Vacuum Cleaner

Instruction Manual

Introduction

This manual provides instructions for the installation and maintenance of HMHAMA replacement tires designed for Roborock S5, T6, T7, and Mijia 1S robotic vacuum cleaners. These tires are engineered to restore optimal traction and performance to your vacuum's drive wheels, ensuring efficient cleaning and extended device lifespan.

Setup and Installation

Replacing the vacuum cleaner tires is a straightforward process. Follow these steps to ensure correct installation:

1. **Step 1: Remove the Wheel.** Carefully detach the wheel assembly from your robotic vacuum cleaner. This may require unscrewing a few fasteners.
2. **Step 2: Remove the Used Tire.** Once the wheel is removed, gently cut and peel off the old, worn rubber tire from the wheel hub. Ensure all remnants of the old tire are removed.
3. **Step 3: Place the New Tire.** Stretch the new HMHAMA replacement tire over the wheel hub. Ensure it is seated firmly and evenly around the entire circumference of the wheel. The non-slip tread should face outwards.
4. **Step 4: Reassemble the Wheel.** Reattach the wheel assembly to your robotic vacuum cleaner, securing any fasteners that were removed in Step 1. Ensure the wheel spins freely and is properly aligned.



Visual guide demonstrating the four steps for tire replacement: removing the wheel, detaching the old tire, fitting the new tire, and reattaching the wheel.



The replacement tire features a textured surface for enhanced grip, with a width of 15mm.

Operating Considerations

Once the new tires are installed, your robotic vacuum cleaner should operate with improved traction and mobility. The natural rubber material provides a non-slip, wear-resistant surface, preventing the wheels from skidding on various floor types and contributing to more efficient cleaning performance.

Maintenance

To ensure the longevity and optimal performance of your replacement tires, consider the following maintenance tips:

- **Regular Inspection:** Periodically check the tires for any signs of wear, cuts, or embedded debris.
- **Cleaning:** If dirt or hair accumulates on the tire surface, gently clean it with a damp cloth to maintain optimal grip.
- **Storage:** If storing the vacuum for an extended period, ensure the tires are clean and dry.

Troubleshooting

If your robotic vacuum cleaner experiences issues after tire replacement, consider these common troubleshooting steps:

- **Vacuum Slipping or Poor Movement:**
  - Ensure the new tires are fully seated and not loose on the wheel hub.
  - Check for any debris (e.g., hair, lint) caught between the tire and the wheel mechanism.
  - Verify that the wheel assembly is correctly reattached and not obstructed.
- **Uneven Movement:**
  - Confirm that both replacement tires are installed correctly and are of the same type.
  - Inspect the wheel axles for any damage or bending.

Specifications

Brand	HMHAMA
Model Compatibility	Roborock S5, T6, T7, Mijia 1S
Material	Rubber
Color	Black
Item Dimensions (L x W x H)	3 x 3 x 2 inches
Item Weight	0.02 Kilograms (approx. 0.704 ounces)
Number of Pieces	2 (1 pair)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C14CX3SW

More documents and user manuals: **https://manuals.plus/**