

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SPYRA](#) /

› [SPYRA SpyraThree™ Electric Water Blaster User Manual](#)

SPYRA SpyraThree™ (Model 4260747380131)

SPYRA SpyraThree™ Electric Water Blaster User Manual

Model: SpyraThree™ (Model 4260747380131)

INTRODUCTION

Welcome to the world of next-level water battles with your new SPYRA SpyraThree™ Electric Water Blaster. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure maximum fun and performance.

Safety Information

This product is recommended for ages **14 years and up**. Always use the water blaster responsibly and avoid aiming at eyes or face. Do not modify the device.

WHAT'S IN THE BOX

Your SPYRA SpyraThree™ package includes the following items:

- One (1) SpyraThree™ Electric Water Blaster
- One (1) Charging Cable
- Integrated Battery (pre-installed)



The SPYRA SpyraThree™ Electric Water Blaster, ready for action.

SETUP

Battery Charging

The SpyraThree™ comes with an integrated Lithium Ion battery. Before first use, fully charge the blaster using the provided USB-C charging cable. The tactical display will show the charging progress.

SPYRATHREE™

RED

2200
shots per
charge

Quick
auto-
reload

Textured
handle for
grip

Tactical
digital
display

USB-C FAST CHARGING

The SpyraThree™ features USB-C fast charging for quick power-ups.

For a visual guide on charging and initial setup, please refer to the official SPYRA Brand Video:

Official SPYRA Brand Video demonstrating product features and usage.

Initial Water Fill

To fill the blaster, submerge the nozzle into a water source. The automatic reload system will quickly fill the tank. Ensure the nozzle is submerged up to the indicated line to prevent leakage during filling.

OPERATING INSTRUCTIONS

Game Modes

The SpyraThree™ offers three distinct game modes, selectable via a switch on the blaster:

- **League Mode:** Delivers a single, powerful shot for superior range and impact.
- **Burst Mode:** Fires a 3-round super fast burst for rapid-fire action.
- **Open Mode:** Allows you to pull the trigger and fire continuously as desired.



SPYRA™

TRIPLE IT. 3X GAME MODES, 3X THE POWER

LEAGUE <i>Single powershot for superior range and impact</i>	BURST <i>3 round super fast burst fire</i>	OPEN <i>Pull the trigger however you like</i>
--	--	---

Select your preferred game mode for different tactical advantages.

Automatic Reload

The SpyraThree™ features a fully automated reload system. Simply submerge the nozzle into a water source, and the blaster will automatically refill and re-pressurize its tank in under 10 seconds. This ensures minimal downtime during intense water battles.

SPYRA™



FULLY AUTOMATED RELOAD

*Auto-refill your entire tank in
under 10 seconds by dipping it
into water*



*SpyraBase is
sold separately.*

Quickly refill your blaster by submerging the nozzle into water.

Tactical Display

Stay informed with the integrated LED tactical display. This display provides real-time information on your current tank volume (water supply) and battery status (energy level), ensuring you are always prepared for the next shot.

SPYRA™

97%

TACTICAL DISPLAY

*Digital display shows
tank volume and battery
life at all times.*



The digital display keeps you updated on your blaster's status.

MAINTENANCE

Draining Excess Water

After use, it is recommended to drain any excess water from the blaster's housing. The blaster is designed with an outlet for this purpose, ensuring proper drying and longevity of the internal components.



Locate the outlet to drain any remaining water after use.

Cleaning and Storage

After each use, wipe down the exterior of the blaster with a clean, damp cloth. Ensure the blaster is completely dry before storing it in a cool, dry place away from direct sunlight. Do not submerge the entire blaster in water for cleaning.

TROUBLESHOOTING

E1 Error Message

If your SpyraThree™ displays an