

- [Manuals.plus](#) /
- › [Squishmallows](#) /
 - › Squishmallows Pokémon Snorlax Plush Toy (25 cm) Instruction Manual - Model SQPK00010

Squishmallows SQPK00010

Squishmallows Pokémon Snorlax Plush Toy (25 cm) Instruction Manual

Model: SQPK00010

INTRODUCTION

This manual provides essential information for the care and enjoyment of your Squishmallows Pokémon Snorlax Plush Toy. Designed for comfort and companionship, this ultra-soft stuffed animal is a delightful addition to any collection.



Image 1: Front view of the Squishmallows Pokémon Snorlax plush toy, showcasing its soft texture and characteristic sleepy expression.

SAFETY INFORMATION

Warning: Not suitable for children under 3 years.

Always supervise young children during play. Inspect the plush toy regularly for any damage or loose parts that could pose a choking hazard. Keep away from open flames and heat sources.

SETUP

Your Squishmallows Pokémon Snorlax Plush Toy is ready for use directly out of its packaging. No assembly or batteries are required.

1. Carefully remove the plush toy from its packaging.
2. Remove all tags and plastic attachments before giving to a child.
3. Gently fluff the plush toy to restore its original shape if it was compressed during shipping.

OPERATING INSTRUCTIONS

The Squishmallows Pokémon Snorlax Plush Toy is designed for cuddling, display, and imaginative play. It is suitable for all ages 3 and up.

- **Cuddling:** Enjoy the ultra-soft texture for comfort and relaxation.
- **Display:** Place the plush toy on a bed, shelf, or desk as a decorative item.
- **Play:** Integrate Snorlax into imaginative play scenarios.

MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your Squishmallows Pokémon Snorlax Plush Toy, follow these care instructions:

- **Spot Cleaning:** For minor spills or stains, use a damp cloth with mild soap. Gently blot the affected area. Do not rub vigorously.
- **Hand Washing:** For a more thorough clean, hand wash with cold water and a gentle detergent. Rinse thoroughly.
- **Drying:** Air dry only. Do not use a machine dryer, as high heat can damage the plush material and filling. Lay flat on a clean towel or hang in a well-ventilated area away from direct sunlight.
- **Do Not Bleach:** Avoid using bleach or harsh chemicals.
- **Do Not Iron:** Ironing can damage the fabric.



Image 2: Side profile of the Squishmallows Pokémon Snorlax plush toy, illustrating its rounded shape and soft contours.

TROUBLESHOOTING

If you encounter any issues with your plush toy, refer to the following common concerns and solutions:

Problem	Solution
Plush toy appears flattened or misshapen.	Gently fluff and reshape the plush toy by hand. The ultra-soft filling should regain its form.
Small stain or dirt mark.	Refer to the "Maintenance and Care" section for spot cleaning instructions.
Loose threads or minor seam issues.	Carefully trim any loose threads with scissors. If a seam is significantly open, contact customer support.

SPECIFICATIONS

- **Product Name:** Squishmallows Pokémon Snorlax Plush Toy
- **Model Number:** SQPK00010
- **Brand:** Squishmallows
- **Manufacturer:** Jazwares
- **Size:** Approximately 25 cm (10 inches)
- **Weight:** 7.4 ounces (approximately 210 grams)
- **Material:** Ultra-soft plush fabric and filling
- **Recommended Age:** 3 years and up
- **Batteries Required:** No



Image 3: Front view of the Squishmallows Pokémon Snorlax plush toy, clearly indicating its 10-inch (25 cm) height for scale.

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. For warranty inquiries, please contact the manufacturer, Jazwares, or the retailer where the product was purchased.

SUPPORT AND CONTACT

For further assistance, questions, or to report any issues, please contact Squishmallows customer support or visit their official brand store.

Squishmallows Official Store: [Visit the Squishmallows Store](#)

© 2025 Squishmallows. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C17PWMT5>

More documents and user manuals: <https://manuals.plus/>