

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ABSEN](#) /

› [ABSEN K2.9D Plus 500\\*750 Channel Pack User Manual](#)

## ABSEN K2.9D Plus 500\*750 Channel Pack

# ABSEN K2.9D Plus 500\*750 Channel Pack User Manual

Model: K2.9D Plus 500\*750

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your ABSEN K2.9D Plus 500\*750 Channel Pack. Please read this manual thoroughly before installation and operation, and keep it for future reference. The K2.9D Plus is a high-performance LED display panel designed for professional applications, offering superior visual quality and reliability.

## SAFETY INFORMATION

Always observe the following safety precautions to prevent damage to the product or injury to personnel:

- Ensure proper grounding for all electrical connections.
- Do not expose the display to moisture or extreme temperatures.
- Avoid direct eye exposure to the LED light source.
- Only qualified personnel should perform installation and maintenance.
- Disconnect power before cleaning or servicing.

## PACKAGE CONTENTS

Verify that all components are present upon unpacking:


- ABSEN K2.9D Plus 500\*750 LED Display Panel
- Power Cable
- Signal Cable (e.g., Ethernet/HDMI)
- User Manual (this document)
- Mounting Accessories (if included with specific package)

## SETUP

Follow these steps for proper installation and initial setup:

## 1. Physical Installation:

Carefully unpack the LED display panel. Identify the mounting points on the panel and the corresponding structure. Securely attach the panel using appropriate mounting hardware. For multi-panel installations, ensure precise alignment and secure locking mechanisms between panels.



*Image: A single ABSEN K2.9D Plus 500\*750 LED display panel, shown vertically, highlighting its slim profile and mounting brackets on the side. This panel is designed for modular assembly into larger LED walls.*

## 2. Power Connection:

Connect the provided power cable to the power input port on the LED panel. Ensure the power source meets the specified voltage requirements. For multiple panels, connect them in a daisy-chain configuration if supported, or use a dedicated power distribution unit.

## 3. Signal Connection:

Connect the signal cable (e.g., Ethernet, HDMI, DVI, or SDI, depending on your system) from your video processor or sending card to the signal input port on the first LED panel. For multi-panel setups, daisy-chain the signal to subsequent panels using the output port of the preceding panel.

## OPERATING

---

Basic operational guidelines for your LED display:

### 1. Powering On/Off:

After all connections are secure, power on your video processor first, then apply power to the LED display panels. To power off, reverse the sequence: power off the LED panels, then the video processor.

### 2. Input Source Selection:

Use your video processor's controls or software to select the desired input source (e.g., PC, media player, camera). Ensure the resolution and refresh rate settings match the requirements of the K2.9D Plus panels for optimal display.

### 3. Brightness Adjustment:

Brightness can typically be adjusted via the video processor or dedicated control software. Adjust to suit ambient lighting conditions and desired visual impact.

## MAINTENANCE

---

Regular maintenance ensures the longevity and performance of your display:

- **Cleaning:**

Gently wipe the screen surface with a soft, lint-free cloth. For stubborn marks, use a specialized LED screen cleaning solution applied to the cloth, not directly to the screen. Do not use abrasive cleaners or solvents.

- **Inspection:**

Periodically inspect cables for wear or damage. Check connections to ensure they are secure. Verify that all cooling fans (if present) are free from obstructions and functioning correctly.

- **Storage:**

When not in use, store panels in their original packaging or protective cases in a dry, temperature-controlled environment, away from direct sunlight and dust.

## TROUBLESHOOTING

---

Common issues and their potential solutions:

Problem	Possible Cause	Solution
No display/Black screen	No power; Loose signal cable; Incorrect input source.	Check power connections; Reconnect signal cable securely; Select correct input source on video processor.
Partial display/Missing sections	Loose signal daisy-chain connection; Faulty panel.	Check signal connections between panels; Contact support if a panel is suspected faulty.
Flickering/Unstable image	Poor signal quality; Incorrect refresh rate.	Ensure high-quality signal cables; Adjust refresh rate settings on video processor to match panel specifications.

If the problem persists after attempting these solutions, please contact ABSEN customer support.

## SPECIFICATIONS

---

Key technical specifications for the ABSEN K2.9D Plus 500\*750 Channel Pack:

- **Brand:** ABSEN
- **Model:** K2.9D Plus 500\*750 Channel Pack

- **Color:** Black
- **ASIN:** B0C18YBCH5
- **Manufacturer:** ABSEN
- **Date First Available:** March 29, 2023
- *Note: Specific pixel pitch, resolution, brightness, and power consumption details are typically found in a detailed product datasheet. Please refer to official ABSEN documentation for comprehensive technical specifications.*

## WARRANTY AND SUPPORT

ABSEN products are designed for reliability and performance. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official ABSEN website.

For technical assistance, troubleshooting beyond this manual, or spare parts inquiries, please contact ABSEN customer support. Have your product model and serial number ready when contacting support.

*Contact Information:* Please visit [www.absen.com/support](http://www.absen.com/support) for the latest support resources and contact details.

© 2023 ABSEN. All rights reserved.

Information in this manual is subject to change without notice.

## Related Documents - K2.9D Plus 500\*750 Channel Pack

 <p>Absenicon X-Series Ultrawide Screen User Manual</p>	<p><a href="#">Absenicon X-Series Ultrawide Screen User Manual</a></p> <p>Comprehensive user manual for the Absenicon X-Series Ultrawide LED display screens, covering product specifications, installation, maintenance, and troubleshooting for models X151, X178, and X205.</p>
 <p>Full spectrum radiator VITAE 350 / 500 / 750 / 1300 ECO 350 / 500 / 750</p> <p>INSTRUCTIONS FOR INSTALLATION AND USE English</p>	<p><a href="#">Sentiotec VITAE and ECO Full Spectrum Infrared Radiators: Installation and User Manual</a></p> <p>Comprehensive installation and user manual for Sentiotec VITAE and ECO series full spectrum infrared radiators. Covers product features, safety guidelines, installation procedures, technical specifications, and maintenance for optimal use in sauna and wellness environments.</p>
 <p>HERSCHEL Inspire Wall &amp; Ceiling-mounted Infrared Heaters INSTALLATION &amp; OPERATING INSTRUCTIONS</p> <p>ELECTRICAL EQUIPMENT IMPORTANT SAFETY TO PURCHASER</p>	<p><a href="#">HERSCHEL Inspire Infrared Heaters: Installation and Operating Instructions</a></p> <p>Comprehensive installation, operating, safety, and warranty guide for HERSCHEL Inspire Wall &amp; Ceiling-mounted Infrared Heaters. Learn about positioning, electrical safety, maintenance, and compliance.</p>

	<p><a href="#"><u>Absenicon X Series X108 User Manual: High-End LED Display Guide</u></a></p> <p>Comprehensive user manual for the Absenicon X Series X108 LED display. Learn about its advanced Micro LED technology, integrated design, interactive features, installation, and maintenance for professional meeting rooms and lecture halls.</p>
	<p><a href="#"><u>A.O. Smith Gas-Fired Power Burner Copper Boilers Installation, Operation, and Maintenance Manual</u></a></p> <p>This manual provides comprehensive installation, operation, and maintenance instructions for A.O. Smith Gas-Fired Power Burner Copper Boilers, models LB/LW-500, 750, and 1000. It covers safety precautions, technical specifications, wiring diagrams, troubleshooting, and warranty information.</p>
	<p><a href="#"><u>WAGO I/O SYSTEM 750 750-464: 2/4 AI RTD Configurable Analog Input Module Manual</u></a></p> <p>Comprehensive manual for the WAGO I/O SYSTEM 750 750-464 2/4 AI RTD configurable module. Covers technical specifications, device description, process image, commissioning, diagnostics, and hazardous environment usage.</p>

## Documents - ABSEN – K2.9D Plus 500\*750 Channel Pack

**Absen K2.9D PLUS 500\*750 Channel Pack**

**Group** Manufacturer **Manufacturer item no.** Absen 11829DP0000000175

**Description** Absen K2.9D PLUS 500\*750 Channel Pack, K2.9D PLUS 500\*750 Channel Pack

**Extended details**

Type	Technical specifications
	Flatscreen Accessory

© 2022 Truedata BV. | Holmeveerdstraat 67 | 1094BH Amsterdam | +31 20 222 2742 | service@truedata.nl

### [\[pdf\] Datasheet Accessories](#)

Datenblatt Absen K2.9D PLUS 500\*750 Channel Pack IT Supplies Group Flatscreen Accessories

Manufacturer item no 11829DP0000000175 Description 9D 718145 datasheet 617471 itsupplies nl ashx file |||

Absen K2.9D PLUS 500\*750 Channel Pack Group Manufacturer Manufacturer item no. Flatscreen Accessories Absen 11829DP0000000175 Description Absen K2.9D PLUS 500\*750 Channel Pack, K2.9D PLUS 500\*750 Channel Pack Extended details Type Technical specifications Flatscreen Accessory 2022 Truedata B.V...

lang: **score:38** filesize: 60.26 K page\_count: 1 document date: 2023-01-12