

[Manuals.plus](#) /

› [Quechua](#) /

› QUECHUA TEPEE Multifunctional Camp Kitchen Unit Instruction Manual

Quechua 4073894

QUECHUA TEPEE Multifunctional Camp Kitchen Unit

Instruction Manual

1. PRODUCT OVERVIEW

The QUECHUA TEPEE Multifunctional Camp Kitchen Unit is an innovative and meticulously designed solution to simplify cooking in outdoor environments. It offers a comprehensive setup for meal preparation, featuring a spacious work area, integrated sink, ample storage, and convenient hanging options.



Figure 1.1: Fully assembled QUECHUA TEPEE Camp Kitchen Unit, showcasing its hexagonal design and integrated storage.




Figure 1.2: Overhead view of the kitchen unit, highlighting the central support structure and the surrounding hexagonal work surfaces.

2. PRODUCT FEATURES

- **Spacious Work Area:** Provides ample surface for food preparation and cooking.
- **Integrated Sink:** A dedicated area for washing, designed for convenience.
- **Ample Storage:** Multiple compartments and bags for organizing kitchen essentials.
- **Height-Adjustable Legs:** Three legs with rotating bases allow for stable setup on uneven terrain.
- **Portable Design:** Compactly foldable for easy transport and storage, complete with a storage bag, reinforced handle, and shoulder strap.
- **Rain Cover:** Included rain cover allows the unit to be left outdoors in various weather conditions.



Figure 2.1: View of the underside, illustrating the integrated storage bags and the rolled-up rain cover.



Figure 2.2: Side profile showing the convenient external storage bags attached to the unit's frame.

3. SETUP INSTRUCTIONS

The QUECHUA TEPEE kitchen unit is designed for quick and straightforward setup from its folded state.

1. **Unpack the Unit:** Remove all components from the storage bag.
2. **Extend the Legs:** Unfold and extend the three main support legs. Adjust their height as needed to ensure the unit is level on uneven ground. The rotating bases on the feet help with stability.



Figure 3.1: Detailed view of the adjustable leg mechanism, allowing for height customization.

3. **Assemble the Frame:** Connect the hexagonal work surfaces to the central support structure. Ensure all locking mechanisms are securely engaged.



Figure 3.2: Components laid out for assembly, showing the central support and hexagonal table sections.




Figure 3.3: Detail of the secure latching mechanism that connects the table segments.

4. **Insert the Sink:** Place the sink component into its designated slot in the work surface.
5. **Attach Storage Bags:** Secure the fabric storage bags to the designated hooks or loops around the unit.
6. **Prepare Hanging Accessories:** Attach the high hanging hook to the central pole for items like lanterns or water bags.



Figure 3.4: Detailed view of the sturdy hook located at the top of the central support pole.

4. OPERATING INSTRUCTIONS

The QUECHUA TEPEE kitchen unit is designed for versatile use in various outdoor cooking scenarios.

- **Cooking Surface:** Utilize the large hexagonal surface for placing portable stoves, cutting boards, and other cooking equipment.
- **Sink Usage:** Fill the integrated sink with water for washing dishes or hands. A hanging water bag can be used to supply water to the sink.




Figure 4.1: The kitchen unit with a water bag suspended from the central pole, demonstrating the sink functionality.

- **Storage:** Use the attached storage bags for utensils, ingredients, and other camping kitchen items.
- **Bin Stand:** The unit includes a bin stand for waste disposal, helping to keep your campsite clean.



Figure 4.2: The kitchen unit in use by a family, demonstrating its practical application for outdoor cooking.



Figure 4.3: A user preparing food on the kitchen unit, illuminated by a hanging light, showcasing its utility during evening hours.

5. MAINTENANCE

- **Cleaning:** After each use, wipe down all surfaces with a damp cloth. For stubborn stains, use mild soap and water. Rinse thoroughly.
- **Drying:** Ensure all components, especially fabric parts and the sink, are completely dry before folding and storing to prevent mold and mildew.

- **Storage:** Store the unit in its provided storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Rain Cover:** If the unit is left outdoors, ensure the rain cover is properly deployed to protect it from elements.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit is unstable/wobbly.	Uneven ground; legs not fully extended or locked.	Adjust the height of individual legs using the rotating bases until stable. Ensure all leg locks are engaged.
Difficulty folding/unfolding.	Components misaligned; debris in joints.	Ensure all latches are disengaged. Check for any obstructions in the folding mechanisms. Refer to assembly steps in reverse.
Water leakage from sink.	Sink not properly seated; drain plug loose.	Ensure the sink is firmly pressed into its slot. Check and tighten the drain plug.

7. SPECIFICATIONS

Attribute	Detail
Model Number	4073894
Brand	Quechua
Product Dimensions (LxWxH)	60 x 120 x 70 cm (23.6 x 47.2 x 27.6 inches)
Folded Size	113 x 52 x 14 cm (44.5 x 20.5 x 5.5 inches)
Item Weight	14.6 kg (32.2 lbs)
Material	Stainless Steel
Color	Blue
Features	Portable, Height Adjustable Legs, Integrated Sink, Storage, Rain Cover

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Quechua website or contact your retailer. Keep your proof of purchase for any warranty claims.

For more information about Quechua products, visit: [Decathlon Quechua Official Website](#)

