

## NOLYTH 726133312635

# NOLYTH External USB-C CD/DVD Drive User Manual

Model: 726133312635

## 1. INTRODUCTION

---

This manual provides instructions for the proper setup, operation, and maintenance of your NOLYTH External USB-C CD/DVD Drive. Please read this manual thoroughly before using the device to ensure optimal performance and longevity. Keep this manual for future reference.

## 2. PRODUCT OVERVIEW

---

### Key Features

- **Slot-in Design with USB 3.0 Adapter:** Connects via a single USB Type-C data cable. Includes a free USB 3.0 adapter for compatibility with various USB port types.
- **Plug and Play:** Automatic detection on Mac and Windows systems without complex settings.
- **High-Speed Read/Write:** Max 8X DVD+/-R write speed, 8X DVD read speed, 24X CD-R write speed, and 24X CD read speed.
- **Wide Compatibility:** Supports Windows 11/10/8.1/7/Vista/XP/98/SE/ME/2000, Linux, and all versions of Mac OS. Compatible with Apple laptops, Mac, MacBook Air/Pro, iMac, Mac mini, and various PC desktops.
- **Stylish and Durable Design:** Constructed from full aluminum alloy, matching the aesthetic of Mac devices.
- **Slim and Portable:** Compact size (139x139x17mm) and lightweight for easy transport.
- **Multifunctional:** Capable of playing music, watching DVD movies, burning/ripping CDs & DVDs, backing up data, burning files, and installing software/systems/games.

## What's in the Box

- 1 x NOLYTH USB-C External CD/DVD Drive
- 1 x USB 3.0 Adapter
- 1 x User Manual

## Product Views

### USB-C SuperDrive



A top-down view of the silver USB-C SuperDrive connected to a MacBook Pro. The drive is connected to the USB-C port on the laptop. A CD is partially inserted into the drive. A red circle highlights the USB-C connector, and another red circle highlights the connection point on the laptop.

### USB SuperDrive



A top-down view of the silver USB SuperDrive connected to a Lenovo laptop. The drive is connected to the USB 3.0 port on the laptop. A CD is partially inserted into the drive. A red circle highlights the USB 3.0 adapter, and another red circle highlights the connection point on the laptop.

**Plug and Play, High Speed CD/DVD Reading and Writing**

<b>Supported Models:</b>	Mac, MacBook Pro, MacBook Air, iMac, Mac mini, Mac Pro, HP, Lenovo...
<b>Multi-System Compatible:</b>	MacOS, Windows 11/10/8/7..., Linux
<b>Supported Formats:</b>	CD-ROM/DVD-ROM/DVD±R DL/DVD±RW/CD-RW/DVD±R/CD-R
<b>Read Speed:</b>	DVD 8X; CD 24X
<b>Write Speed:</b>	CD-R 24X; CD-RW 16X; DVD-RW 6X; DVD+RW 8X; DVD±R DL 6X; DVD±R 8X
<b>Comes with a Free USB 3.0 Adapter</b>	


Figure 2.1: Top-down view of the NOLYTH External CD/DVD Drive.



Figure 2.2: Close-up of the slot-loading mechanism and the aluminum alloy construction.

## Multi-function External CD Drive

Enjoy your life more easily



Install software



Copy Files



Burn CD/DVD



Data Backup



Watch Movie



Play Games

Figure 2.3: Physical dimensions of the drive (5.43 x 5.43 x 0.63 inches).

### 3. SETUP INSTRUCTIONS

The NOLYTH External CD/DVD Drive is designed for plug-and-play functionality. Follow these steps to connect and begin using your drive:

1. **Connect the Drive:** Locate an available USB-C port on your computer. Plug the attached USB-C cable from the NOLYTH drive directly into this port.
2. **Using the USB 3.0 Adapter (if needed):** If your computer only has standard USB-A ports, attach the provided USB 3.0 adapter to the USB-C cable, then plug the adapter into a USB-A port on your computer.
3. **System Recognition:** Your computer should automatically detect the drive. No additional drivers are typically required.

# Widely Compatible



Figure 3.1: Connecting the drive directly via USB-C to a laptop.




### Data Transfer Interface

USB Type-C data cable and with the free USB 3.0 adapter to connect to various computers with USB-C and USB ports for more stable reading and writing.

### Slot-loading Optical Drive

Slot-loading only, no eject button. Eliminates the hassle of manually opening and closing the tray - just right-click on the computer to eject the disc.



### Made from Aluminium Alloy, Edge Fillet Design

Perfect matches the grey-coloured material of Mac, MacBook Pro/Air and iMac, comfortable sleek stylish appearance and sturdy construction.

### All-in-one Finished DVD Drive

Built-in USB Type-C cable, no need for a separate power adapter. And don't worry about lost CD drive cables.




Figure 3.2: Connecting the drive using the USB 3.0 adapter to a laptop.

## Setup Demonstration Video

Your browser does not support the video tag.

Video 3.1: This video demonstrates the connection process of the NOLYTH External DVD Drive to both Mac and Windows laptops, showing how to insert and play a disc.

## 4. OPERATING INSTRUCTIONS

### Inserting and Ejecting Discs

The NOLYTH drive features a slot-loading mechanism. There is no physical eject button on the drive itself.

1. **Inserting a Disc:** Gently push the disc into the slot with the label side facing up. The drive will automatically pull the disc in.
2. **Ejecting a Disc:** To eject a disc, right-click on the drive icon in your computer's file explorer (Windows) or drag the disc icon to the Trash/Eject icon (Mac). The disc will then be ejected automatically.



Figure 4.1: Visual guide for inserting a disc, dragging files for burning, and automatic ejection after use.

## Supported Disc Formats and Speeds

The drive supports a variety of CD and DVD formats with the following maximum speeds:

- **Read Speed:** CD 24X, DVD 8X
- **Write Speed:** CD-R 24X, CD-RW 16X, DVD-R 8X, DVD+R 8X, DVD-RW 6X, DVD+RW 8X, DVD-R DL 6X, DVD+R DL 6X

Supported formats include CD-ROM, CD±R/RW, DVD-ROM, DVD-RAM, DVD±R/RW, VCD, and SVCD.




Figure 4.2: Overview of maximum read and write speeds for different CD and DVD formats.

## DVD Region Code Information

DVDs are often region-coded. The drive's region code must match the disc's region code for playback. The drive allows for a limited number of region code changes (typically 4 times). Once the limit is reached, the region code becomes permanently set.



Figure 4.3: Explanation of DVD region codes and the limited number of changes allowed.

## 5. COMPATIBILITY

### Supported Operating Systems

- Mac OS (all versions)
- Windows 11 / 10 / 8.1 / 7 / Vista / XP / 98 / SE / ME / 2000
- Linux

### Supported Hardware Platforms

- Laptops (e.g., MacBook Pro/Air, PC laptops)
- Desktops (e.g., iMac, Mac mini, PC desktops, all-in-one computers)

### Incompatible Devices and Formats

This external DVD player is **not compatible** with the following:

- Chromebooks
- TVs
- Cars
- Tablets
- iPads
- PS4/5
- Xbox
- Switch
- Projectors
- Some Surface models
- Blu-ray discs
- 4K discs
- M-Discs



Figure 5.1: Visual representation of compatible operating systems and devices, along with a list of incompatible devices.

## 6. MAINTENANCE

---

To ensure the longevity and optimal performance of your NOLYTH External CD/DVD Drive, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the drive. Do not use liquid cleaners or abrasive materials. For the disc slot, use a specialized optical drive cleaning disc if necessary.
- **Storage:** Store the drive in a clean, dry environment away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Avoid dropping or subjecting the drive to strong impacts. Handle discs by their edges to prevent fingerprints and scratches.
- **Cable Care:** Do not bend or crimp the attached USB cable excessively.

## 7. TROUBLESHOOTING

---

If you encounter issues with your NOLYTH External CD/DVD Drive, refer to the following common problems

and solutions:

- **Drive Not Recognized:**

- Ensure the USB cable is securely connected to both the drive and your computer.
- Try connecting to a different USB port on your computer.
- If using the USB 3.0 adapter, ensure it is firmly attached.
- Restart your computer.
- Verify that your operating system is supported (refer to Section 5).

- **Disc Not Ejecting:**

- As there is no physical eject button, eject the disc through your computer's operating system (right-click on the drive icon and select 'Eject' on Windows, or drag the disc icon to the Trash/Eject icon on Mac).
- If the disc is still stuck, try gently flipping the drive over (black side up) while attempting to eject via software. This can sometimes help with stubborn discs.

- **Disc Read/Write Errors:**

- Ensure the disc is clean and free of scratches or smudges.
- Verify that the disc format is supported by the drive (refer to Section 4).
- Check if the DVD region code matches the drive's region (refer to Section 4).
- Try a different disc to determine if the issue is with the drive or the disc itself.

- **Slow Performance:**

- Ensure the drive is connected to a USB 3.0 or USB-C port for optimal speed. USB 2.0 ports will result in slower data transfer.
- Close any unnecessary applications running in the background that might be consuming system resources.

If these steps do not resolve the issue, please contact NOLYTH customer support.

## 8. SPECIFICATIONS

---

Feature	Specification
Brand	NOLYTH
Model Number	726133312635
Hard Drive Type	External DVD Drive
Hardware Platform	Laptop/PC/Desktop, Mac/MacBook Pro/MacBook Air/iMac
Operating System Compatibility	Mac OS/macOS/Windows 11/10/8/7/98/XP/2000/Vista/Linux
Item Weight	14 ounces
Product Dimensions (LxWxH)	5.43 x 5.43 x 0.63 inches
Color	Grey
Optical Storage Write Speed	CD 24x / DVD±R 8x / DVD±R DL 6x
Optical Storage Read Speed	CD 24x / DVD 8x
Special Features	Backward Compatible/Error Correction, Noise Reduction Technology, Plug & Play/Portable/Slim/Lightweight, Shock Resistant, Slip Resistant/full aluminum alloy/with a free USB 3.0 adapter, Slot-loading/no eject button/USB C data cable
Hardware Interface	USB 3.0, USB 3.0 Type C

## 9. WARRANTY AND SUPPORT

NOLYTH provides comprehensive support for its products:

- **Warranty:** The product includes a 24-month replacement warranty.
- **Customer Support:** 24-hour support is available for any inquiries or issues.

### How to Contact Support

For after-sales service or support, please contact the seller directly through the Amazon platform:

1. Go to the product page on Amazon.
2. Click on the seller's name (e.g., "Sold by Confoly Tech").
3. Click the "Ask a question" button to send a message to the seller.



Figure 9.1: Visual guide for contacting the seller via Amazon for support inquiries.