Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Intoval V3

Intoval 3-in-1 Wireless Charger (Model V3) User Manual

Efficient and versatile charging for your devices.

1. Product Overview

The Intoval 3-in-1 Wireless Charger (Model V3) is designed to provide a streamlined charging experience for multiple devices simultaneously. This station supports wireless charging for compatible smartphones, Fitbit smartwatches (Sense/Versa series), and wireless earbuds.



Figure 1: The Intoval 3-in-1 Wireless Charger with a smartphone, Fitbit smartwatch, and wireless earbuds in charging positions.

Package Contents:

- Intoval 3-in-1 Wireless Charging Stand
- USB-C to USB-A Charging Cable
- Power Adapter
- User Manual

2. Setup Instructions

1. **Unpack the Charger:** Carefully remove all components from the packaging.
2. **Connect Power:** Insert the USB-C end of the provided charging cable into the port on the back of the charging stand. Connect the USB-A end of the cable to the provided power adapter.
3. **Plug into Outlet:** Plug the power adapter into a standard wall outlet. The charging station is now ready for use.




Figure 2: The charging station set up and ready to charge devices.

3. Operating Instructions

The Intoval 3-in-1 Wireless Charger features dedicated charging areas for your smartphone, Fitbit smartwatch, and wireless earbuds.

Charging a Smartphone:

- Place your Qi-compatible smartphone on the upright charging pad.
- The phone can be placed in either a vertical or horizontal orientation.
- Ensure your phone case is less than 5mm thick for optimal charging.
- A soft green LED indicator on the front of the station will illuminate for approximately 10 seconds to confirm charging has begun.



Figure 3: Smartphone charging vertically on the stand.

Charging a Fitbit Smartwatch:

- Place your Fitbit Sense 2/1 or Versa 4/3 onto the dedicated watch charging module at the top of the stand.
- Ensure the watch is properly aligned with the charging pins for a stable and snug fit.
- The watch display will indicate charging status.




Figure 4: Proper placement of a Fitbit smartwatch on the charging module.



Figure 5: Detail of the stable and snug fit for the Fitbit smartwatch.

Charging Wireless Earbuds:

- Place your Qi-compatible wireless earbud case on the flat charging pad at the base of the stand.
- Ensure the earbud case is centered on the charging area.
- A soft green LED indicator on the front of the station will illuminate for approximately 10 seconds to confirm charging has begun.

4. Maintenance

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the charging cable excessively to prevent damage.

5. Troubleshooting

Issue	Possible Cause	Solution
Device not charging	Incorrect placement, phone case too thick, power not connected, incompatible device.	Ensure the device is centered on the charging pad. Remove phone case if thicker than 5mm. Verify the power adapter is securely plugged into the wall and the charging cable is connected to the station. Confirm your device supports Qi wireless charging.
Charging is slow	Improper alignment, background apps, phone case.	Re-position the device to ensure optimal alignment. Close unnecessary background applications on your phone. Remove phone case.
LED indicator flashes	Foreign object detection, overheating, short-circuit.	Remove any metal objects, credit cards, or other foreign materials from the charging pad. Disconnect power, allow the unit to cool down, then reconnect. If the issue persists, contact customer support.

6. Specifications

- **Model:** V3
- **Input:** 18W (Max)
- **Output (Phone):** Up to 15W (varies by device)
- **Output (Fitbit Watch):** 2.5W
- **Output (Earbuds):** 5W
- **Dimensions:** 14 x 12.4 x 7.7 cm
- **Weight:** 0.33 kg
- **Color:** Black
- **Compatibility:** Qi-certified phones (iPhone, Samsung Galaxy Note/S series), Fitbit Sense 2/1, Versa 4/3, Airpods Pro 2/Pro/3, Galaxy Buds 2/1/+/Live.
- **Safety Features:** Over-temperature protection, over-voltage protection, short-circuit protection, foreign object detection.

7. Warranty and Support

The Intoval 3-in-1 Wireless Charger (Model V3) comes with a**1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

For technical assistance, warranty claims, or any other inquiries, please contact our customer support team. Our tech team is available 24/7 to assist you with any queries or issues.

Please retain your proof of purchase for warranty validation.

© 2023 Intoval. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1BQRDDF

More documents and user manuals: **https://manuals.plus/**