Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Csasan J90 pro

Csasan Wireless Earbuds J90 Pro User Manual

Model: J90 Pro

Introduction

Thank you for choosing the Csasan J90 Pro Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.3 connectivity, HiFi stereo sound, long battery life, and IP7 waterproofing. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: The Csasan J90 Pro Wireless Earbuds in their charging case, showcasing the sleek black design and LED power display.

What's in the Box

- 2x Wireless Headphones (L/R)
- 1 x Fast Charging Case
- 1 x Type-C Charging Cable
- 3 x Pairs of Earplugs (S, M, L)
- 1 x Instruction Manual




Image: A visual representation of all items included in the Csasan J90 Pro Wireless Earbuds package, including the earbuds, charging case, USB-C cable, and various ear tip sizes.

Product Overview

The J90 Pro earbuds feature a sleek design with advanced audio components. The charging case includes an LED digital display to show battery levels for both the case and individual earbuds.

Key Features:

- **Bluetooth 5.3:** Provides faster transfer speeds and a more stable connection with minimal delay.
- **Immersive HiFi Stereo Sound:** Equipped with 13mm composite diaphragms and AAC codec for professional-grade audio.
- **ENC Noise Cancelling Mics:** Dual microphones reduce background noise by 80% for clear calls.
- **40 Hours Playtime:** 6-8 hours on a single charge, with an additional 4 charges from the case.
- **Smart LED Digital Display:** Monitor battery levels of earbuds and charging case.
- **Touch Control:** Manage music, calls, and volume directly from the earbuds.
- **IP7 Waterproof:** Nano-coating technology protects against sweat and rain.



Image: An overview of the Csasan J90 Pro's main features, highlighting its audio quality, connectivity, battery life, and durability.

Image: Close-up of the Bluetooth 5.3 chip and the charging case's LED display, indicating battery levels and connection status.

Image: An exploded diagram illustrating the 13mm super large dynamic speaker components responsible for the powerful stereo sound.

Setup

Initial Pairing:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
4. Search for "J90 Pro" in the list of available devices and select it to connect.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

Re-connection:

After the initial pairing, simply open the charging case, and the earbuds will automatically connect to the last paired device (if Bluetooth is enabled on the device).

Image: A visual guide demonstrating the one-step auto-pairing process of the earbuds with a mobile device, showing the "J90 Pro" appearing in the Bluetooth device list.

Your browser does not support the video tag.

Video: An official seller video showcasing the "2023 new earbuds," including a demonstration of opening the case and the earbuds' LED display.

Operating Instructions

The J90 Pro earbuds feature sensitive touch controls on both the left and right earbuds for easy management of various functions.

Touch Control Functions:

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause	Tap Twice	Tap Twice
Volume Up	N/A	Tap Once
Volume Down	Tap Once	N/A
Next Track	N/A	Press and Hold 2s
Previous Track	Press and Hold 2s	N/A
Answer/End Call	Tap Once	Tap Once
Reject Call	Press and Hold 2s	Press and Hold 2s
Activate Voice Assistant	Tap 3 Times	Tap Once

Action	Left Earbud (L)	Right Earbud (R)

Image: Icons illustrating the various smart touch control functions available on the earbuds, including play/pause, call answer/hang up, volume adjustment, and track switching.

Your browser does not support the video tag.

Video: An official seller video demonstrating the features of the "bluetooth wireless earbuds," including the touch controls and how they function.

Charging

The J90 Pro earbuds offer extended playtime with their charging case. The LED display on the case provides real-time battery status.

- **Earbud Playtime:** 6-8 hours on a single charge.
- **Total Playtime (with case):** Up to 40 hours.
- **Charging Time:** Approximately 1.5 hours for both earbuds and charging case.

Charging the Earbuds:

Place the earbuds into the charging case. They will automatically begin charging. The LED display will show the individual earbud battery levels.

Charging the Case:

Connect the provided Type-C charging cable to the charging port on the case and plug the other end into a USB power source. The LED display will show the charging progress of the case.

Image: Visualizing the 40-hour total playtime, 6-8 hours per single charge, and 1.5-hour fast charging capability of the earbuds and case.

Maintenance & Care

- **Cleaning:** Regularly clean the earbuds and charging contacts with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Waterproofing (IP7):** The earbuds are IP7 waterproof, meaning they can withstand sweat and rain. However, they are not designed for swimming or prolonged submersion. Ensure they are dry before placing them back in the charging case.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.
- **Battery Longevity:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly.




Image: A person being splashed with water, visually representing the IP7 waterproof capability of the earbuds, suitable for workouts and light rain.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing/connecting.	Ensure Bluetooth is enabled on your device. Make sure earbuds are charged. Forget "J90 Pro" in your device's Bluetooth settings and re-pair. Place earbuds back in the case, close, then open again to reset.
Only one earbud working.	Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. This should re-sync them. Check if the earbuds are in "single ear mode" (refer to operating instructions for binaural mode).
Low volume or poor sound quality.	Adjust volume on both your device and the earbuds. Ensure ear tips are properly sealed in your ear canal. Try different sized ear tips. Clean any debris from the earbud speakers.
Charging issues.	Ensure the charging cable is securely connected to both the case and power source. Try a different USB port or power adapter. Clean the charging contacts on both the earbuds and inside the case.

Specifications

- **Model Name:** J90 Pro
- **Bluetooth Version:** 5.3
- **Audio Driver Size:** 13mm Dynamic Driver
- **Frequency Range:** 20 Hz - 20,000 Hz
- **Battery Life (Earbuds):** 6-8 hours

- **Battery Life (Total with Case):** 40 hours
- **Charging Time:** 1.5 hours (Earbuds & Case)
- **Water Resistance:** IP7 Waterproof
- **Control Type:** Touch Control
- **Noise Control:** Passive Noise Cancellation (ENC for Mics)
- **Compatible Devices:** Most iOS and Android devices with Bluetooth
- **Product Dimensions:** 2.76 x 1.97 x 1.57 inches
- **Item Weight:** 3.52 ounces (0.1 Kilograms)

Warranty & Support

Csasan offers a 2-year warranty for the J90 Pro Wireless Earbuds. For any product inquiries, technical support, or warranty claims, please contact Csasan customer service. You can find contact information on the official Csasan website or through your purchase platform.
Csasan is committed to minimizing environmental impact and supports SDG initiatives. For more information, please visit the Csasan Store on Amazon.




Image: Details about Csasan's 2-year warranty and commitment to environmental sustainability, including a Climate Pledge Friendly badge.

© 2023 Csasan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1C141MS

More documents and user manuals: **https://manuals.plus/**