

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Play-Doh](#) /

> [Play-Doh Fantasy Unicorn Modelling Clay Set Instruction Manual](#)

Play-Doh Fantasy Unicorn

Play-Doh Fantasy Unicorn Modelling Clay Set Instruction Manual

Model: Fantasy Unicorn

1. INTRODUCTION

This manual provides comprehensive instructions for the Play-Doh Fantasy Unicorn Modelling Clay Set. This set allows users to create and customize a unicorn figure using Play-Doh compound and various accessories. Follow these guidelines for safe and enjoyable play.

2. PACKAGE CONTENTS

Ensure all the following components are present in your Play-Doh Fantasy Unicorn Modelling Clay Set:

- 1 x Unicorn Figure
- 1 x Dragon Stamp Roller
- 3 x Horn Molds
- 1 x Chopping Wheel (Magic Wand Shape)
- 1 x Ring
- 5 x Pots of Play-Doh Modelling Compound (Net weight: 283g)



Figure 2.1: Front view of the Play-Doh Fantasy Unicorn Modelling Clay Set packaging, showing the unicorn figure and included accessories.

3. SETUP

1. **Unpack Components:** Carefully remove all items from the packaging. Dispose of packaging materials responsibly.
2. **Prepare Play-Doh:** Open the desired pots of Play-Doh modelling compound. Knead the compound briefly to soften it, making it easier to mold and extrude.
3. **Assemble Unicorn:** Attach any removable parts to the unicorn figure as shown in the illustrations on the packaging. The unicorn typically comes with detachable wings and a horn attachment.



Figure 3.1: Back view of the product packaging, illustrating a child engaging with the unicorn set and demonstrating various play features.

4. OPERATING INSTRUCTIONS

4.1 Creating the Unicorn's Mane

1. Open the top section of the unicorn's head where the horn is located.
2. Place a small amount of Play-Doh compound into the opening.
3. Close the top section and press down firmly on the horn. Play-Doh will extrude from the top of the unicorn's head, forming a mane.
4. Use the chopping wheel (magic wand) or other tools to style the mane.

4.2 Creating the Unicorn's Tail

1. Locate the tail mechanism at the rear of the unicorn. This section should open to allow Play-Doh insertion.
2. Insert a small amount of Play-Doh compound into the tail opening.
3. Close the tail mechanism securely. Press down on the tail to extrude Play-Doh, forming a tail.
4. **Note:** Some users have reported that the tail mechanism can be stiff or difficult to open and close initially. Gentle but firm pressure may be required. Ensure the mechanism is fully closed before attempting to extrude Play-Doh to prevent compound from getting stuck.

4.3 Making Horns and Other Shapes

- Use the three horn molds to create different horn designs. Press Play-Doh into the molds and carefully remove.
- The dragon stamp roller can be used to create six different jewel shapes. Roll the dragon over flattened Play-Doh to stamp designs.

- The magic wand-shaped chopping wheel can be used to cut and shape Play-Doh.
- Decorate the included ring by pressing small pieces of Play-Doh into its surface.

5. MAINTENANCE

5.1 Cleaning the Unicorn and Tools

- After each use, remove any excess Play-Doh from the unicorn figure and accessories.
- Allow any small, stuck pieces of Play-Doh to dry completely. Once dry, they can often be easily scraped or brushed off.
- For stubborn residue, use a soft brush or a toothpick to gently dislodge dried Play-Doh. Avoid using water directly on the mechanisms, as this can cause the Play-Doh to become sticky and harder to remove.

5.2 Storing Play-Doh Compound

- Always return Play-Doh compound to its airtight container immediately after use to prevent it from drying out.
- Store containers in a cool, dry place away from direct sunlight.

6. TROUBLESHOOTING

- **Play-Doh not extruding from mane or tail:**
 - Ensure enough Play-Doh compound has been inserted into the mechanism.
 - Apply firm and steady pressure.
 - Check for any dried Play-Doh blocking the extrusion holes. Clean as per Maintenance instructions.
 - For the tail mechanism, ensure it is fully closed and locked (if applicable) before pressing. If it pops open during extrusion, the compound may not come out properly.
- **Tail mechanism difficult to open/close:**
 - This can occur due to dried Play-Doh or manufacturing tolerances.
 - Gently try to pry it open with a blunt, non-damaging tool if necessary, being careful not to damage the plastic.
 - Ensure all Play-Doh is removed from the internal parts of the mechanism.

7. SPECIFICATIONS

Feature	Detail
Brand	Play-Doh
Model Name	Fantasy Unicorn
Age Range (Description)	3+
Material	Plastic
Item Weight	283 Grams (10 ounces)
Number of Items	5 pots of compound, plus accessories
Educational Objective	Creative Skill, Dexterity

8. SAFETY INFORMATION

- Play-Doh compound is non-toxic but not intended for consumption.
- Adult supervision is recommended, especially for younger children.
- Keep Play-Doh away from carpets and fabrics, as it may stain.
- Wash hands thoroughly after playing with Play-Doh.
- Small parts may be a choking hazard for children under 3 years.

9. WARRANTY AND SUPPORT

For product support, questions, or warranty information, please refer to the contact details provided on the product packaging or visit the official Play-Doh website. Keep your purchase receipt for warranty claims.