

## DURACELL Micro 5

# DURACELL Micro 5 Mobile Power Bank User Manual

Model: Micro 5

## 1. INTRODUCTION

Thank you for choosing the DURACELL Micro 5 Mobile Power Bank. This device is designed to provide portable power for your mobile devices, featuring MagSafe compatible wireless charging and USB-C wired charging. It includes a 5,000mAh battery capacity and a convenient retractable kickstand. Please read this manual thoroughly before use to ensure proper operation and safety.

## 2. SAFETY INFORMATION

- Do not expose the power bank to water, moisture, or extreme temperatures.
- Avoid dropping, disassembling, or attempting to repair the device yourself.
- Keep out of reach of children.
- Do not use if the power bank is damaged or swollen.
- Dispose of the power bank according to local regulations.
- This device is TSA carry-on compliant for air travel.

## 3. PACKAGE CONTENTS

- DURACELL Micro 5 Mobile Power Bank
- USB-C to USB-C Charging Cable



Image: DURACELL Micro 5 Power Bank and its retail packaging.

#### 4. PRODUCT FEATURES AND COMPONENTS

The DURACELL Micro 5 Mobile Power Bank features a compact design with essential components for convenient charging.

- **MagSafe Compatible Charging Surface:** For wireless charging of compatible devices.
- **USB-C Port:** Used for both charging the power bank and charging external devices.
- **LED Indicator Lights:** Display the power bank's battery level and charging status.
- **Retractable Kickstand:** Allows the power bank to prop up a device for hands-free viewing while charging.



Image: Front view of the DURACELL Micro 5 Power Bank with its retractable kickstand extended.



Image: Various angles of the power bank, highlighting the USB-C port and overall design.

## 5. SETUP

Before initial use, it is recommended to fully charge your DURACELL Micro 5 Mobile Power Bank.

1. Connect the included USB-C to USB-C cable to the USB-C port on the power bank.
2. Connect the other end of the USB-C cable to a compatible USB wall adapter (not included).
3. The LED indicator lights will illuminate to show the charging progress. The power bank is fully charged when all LED indicators are solid.

## 6. OPERATING INSTRUCTIONS

### 6.1. Charging the Power Bank

To recharge the power bank:

1. Use the provided USB-C cable.
2. Connect one end to the power bank's USB-C input port.
3. Connect the other end to a USB-C power source (e.g., wall adapter, computer USB-C port).
4. The LED indicators will show the charging status. A full charge typically takes under 3 hours.

## **6.2. Charging Devices Wirelessly (MagSafe Compatible)**

For devices with MagSafe compatibility:

1. Align your MagSafe compatible device with the magnetic charging surface on the power bank.
2. The magnets will securely attach, and wireless charging will begin automatically.
3. The power bank provides up to 7.5W wireless charging.



Image: A smartphone magnetically attached and wirelessly charging on the power bank.

### 6.3. Charging Devices via USB-C Cable

For wired charging of any USB-C compatible device:

1. Connect one end of a USB-C cable (the included cable or your device's cable) to the power bank's USB-C output port.
2. Connect the other end to your device's charging port.
3. Charging will begin automatically. The power bank provides up to 12W output via USB-C.

#### 6.4. Using the Retractable Stand

The integrated kickstand allows for convenient hands-free viewing while your device charges.

1. Gently pull out the kickstand from the back of the power bank until it locks into place.
2. Place your device (either wirelessly attached or cable-connected) onto the power bank, resting against the kickstand.
3. Adjust the angle as needed for optimal viewing.
4. To retract, push the kickstand back into its slot until it is flush with the power bank.



Image: A smartphone positioned on the power bank's kickstand for video conferencing.

# MAGNETIC POWER BANK



**MagSafe**  
Compatible



**7.5W Wireless**  
Charging



Image: A smartphone using the power bank's kickstand to watch a video in landscape orientation.

## 6.5. Pass-Through Charging

The power bank supports pass-through charging, allowing you to charge both the power bank and a connected device simultaneously.

1. Connect the power bank to a power source using the USB-C input.
2. Connect your device to the power bank (either wirelessly or via USB-C cable).
3. Both the power bank and your device will charge.





Image: Illustration of pass-through charging, showing the power bank charging itself and a phone simultaneously.

## 7. MAINTENANCE

---

- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the power bank to approximately 50% every three months to maintain battery health.

## 8. TROUBLESHOOTING

---

- **Power bank not charging:** Ensure the USB-C cable is securely connected to both the power bank and the power source. Try a different USB-C cable or wall adapter.
- **Device not charging wirelessly:** Ensure your device is MagSafe compatible and properly aligned with the charging surface. Remove any thick cases that might interfere with wireless charging.
- **Device not charging via USB-C:** Ensure the USB-C cable is securely connected to both the power bank and your device. Try a different USB-C cable.
- **Slow charging:** Ensure you are using a compatible power adapter for the power bank. For device charging, check if your device supports faster charging rates and if the cables are appropriate.
- **Overheating:** It is normal for the power bank to become slightly warm during charging or discharging. If it becomes excessively hot, disconnect it immediately and contact customer support. Avoid using your phone heavily while wirelessly charging, as this can generate additional heat.

## 9. SPECIFICATIONS

| Feature            | Specification  |
|--------------------|--|
| Model Number       | Micro 5  |
| Battery Capacity   | 5000 Milliamp Hours (mAh)                            |
| Connector Type     | USB Type C   |
| Input (USB-C)      | 18W Max  |
| Output (USB-C)     | 12W Max  |
| Wireless Output    | 7.5W   |
| Product Dimensions | 9 x 2.2 x 0.33 inches                                |
| Item Weight        | 0.634 ounces   |
| Battery Type       | Lithium Polymer                                      |
| Special Features   | Fast Charging, LED Indicator Lights, Travel-Friendly |

## 10. WARRANTY AND SUPPORT

DURACELL products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official DURACELL website for customer service contact details.