

[Manuals.plus](#) /

› [Shark](#) /

› SHARK WD101 HydroVac XL 3-in-1 Multi-Surface Cleaner Instruction Manual

Shark WD101

SHARK WD101 HydroVac XL 3-in-1 Multi-Surface Cleaner Instruction Manual

Model: WD101 | Brand: Shark

INTRODUCTION

The SHARK WD101 HydroVac XL is a versatile 3-in-1 multi-surface cleaner designed to vacuum, mop, and self-clean simultaneously. This corded system is engineered for deep cleaning on various sealed hard floors, including hardwood, tile, marble, and laminate, and is also effective for cleaning area rugs. Its powerful suction and hydro mopping capabilities efficiently remove dirt, debris, wet messes, stains, and grime, leaving surfaces streak-free and quick to dry.

WHAT'S INCLUDED

Your SHARK WD101 HydroVac XL package includes the following components:

- Shark HydroVac XL Corded 3-in-1 multi-surface cleaner
- 1 brushroll* (treated with substance to preserve roller and resist odors)
- 1 foam filter
- 1 storage tray

Note: Cleaning solution is not included and must be purchased separately.

What's in the box:



Image: All components included in the Shark HydroVac XL package.

SETUP

Assembly

1. Carefully remove all components from the packaging.
2. Insert the handle into the main body of the cleaner until it clicks securely into place.

Filling the Clean Water Tank

1. Press the 'Clean Solution Tank Removal' button located on the top of the main unit to detach the clean water tank.
2. Unscrew the cap of the clean water tank.
3. Fill the tank with warm water up to the 'WATER' fill line.
4. Add the appropriate amount of Shark HydroVac Multi-Surface Concentrate up to the 'HYDROVAC CONCENTRATE' fill line.
5. Securely screw the cap back onto the tank and reinsert the tank into the main unit until it clicks.

Video: Demonstrates unboxing, assembly, and initial filling of the clean water tank for first use.



Image: Illustration of the two-tank system, highlighting the XL Clean Solution Tank (500 ml) and Dirty Water Tank (360 ml).

OPERATING INSTRUCTIONS

1. Plug the power cord into a suitable electrical outlet.
2. Press the power button located on the handle to turn on the unit.
3. Select the appropriate cleaning mode (Hard Floor or Area Rug) using the button on the LED display. The LED display will indicate the selected surface type and tank levels.
4. Tilt the unit back to engage the brushroll and begin cleaning.
5. Move the cleaner slowly and steadily across the desired surface. The LED headlights will illuminate hidden dirt and grime.



3-in-1 cleaning system

Vacs, mops, and cleans itself
at the same time.

Image: The 3-in-1 cleaning system in action, vacuuming and mopping simultaneously.



Multi-surface cleaning
For hard floors, area rugs, tile & laminate.

Image: Demonstrates multi-surface cleaning on hard floors and area rugs.



Image: LED headlights help to identify hidden dirt and debris during operation.

Video: A full tutorial demonstrating how the Shark HydroVac XL works, including operational steps.

MAINTENANCE

Self-Cleaning Cycle

After each use, place the HydroVac XL on its storage tray and activate the self-clean mode. This continuous self-cleaning system helps prevent dirt from being redeposited on your floors and keeps the brushroll fresh.

1. Ensure the HydroVac is plugged in and placed on the storage tray.
2. Press the self-clean button (indicated by a circular arrow icon) on the handle.
3. The unit will perform a cleaning cycle to rinse the brushroll and internal pathways.



Easy maintenance

Cleans itself on its dock.

Image: The HydroVac XL on its dock, illustrating its easy maintenance and self-cleaning feature.



Self-cleaning Brushroll

Never clean with a dirty brushroll.

Image: The self-cleaning brushroll ensures a clean start for every use.

Emptying the Dirty Water Tank

The debris filtration technology in the dirty water tank separates solids from liquids for easy disposal.

1. Press the dirty water tank release button to remove the tank.
2. Open the tank lid and carefully pour out the liquid waste.
3. Remove any solid debris from the filter and rinse the tank thoroughly with water.
4. Reinstall the dirty water tank into the unit.

Video: Demonstrates the process of emptying and cleaning the dirty water tank.

TROUBLESHOOTING

Unit Not Dispensing Liquid

- Ensure the clean water tank is properly filled and securely seated in the unit.

- Check for any blockages in the solution dispensing nozzles.
- Run a self-clean cycle while the unit is on its storage tray. This can help flush out any blockages in the internal lines.

SPECIFICATIONS

Feature	Detail
Brand	Shark
Model Name	Shark Corded HydroVac
Item Model Number	WD101
Special Feature	Bagless
Filter Type	Foam
Included Components	1 brushroll, 1 foam filter, 1 storage tray
Is Cordless?	No (Corded Electric)
Capacity	500 Milliliters (Clean Tank)
Form Factor	Stick
Color	Navy
Noise Level	80 Decibels
Control Method	Touch, Push Button
Portable	Yes
Indoor/Outdoor Usage	Indoor
Vacuum Collection Technology	Suction and Hydro Mopping
UPC	657768379536
Product Dimensions	12 x 4.5 x 55.5 inches
Item Weight	10.27 pounds
Surface Recommendation	Hard Floors, Hardwood

WARRANTY & SUPPORT

This Shark HydroVac XL unit comes with a 90-day limited warranty. For support or warranty claims, please refer to the official Shark product documentation or contact Shark customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question