

Manuals.plus /
› BNSPLY /
› BNSPLY 10'x30' Outdoor Party Tent Instruction Manual

BNSPLY 10'x30' Outdoor Party Tent

BNSPLY 10'x30' Outdoor Party Tent Instruction Manual

Model: 10'x30' Outdoor Party Tent

1. INTRODUCTION

This manual provides essential instructions for the safe and effective assembly, operation, and maintenance of your BNSPLY 10'x30' Outdoor Party Tent. Please read all instructions carefully before setup and retain this manual for future reference.

2. SAFETY INFORMATION AND WARNINGS

Important Safety Precautions:

- This tent is designed for **temporary use** in good weather conditions.
- **Do not use the tent during extreme bad weather conditions** including heavy rain, strong winds, or storms.
- After setup, always use the provided ropes and ground pegs for **added stability**.
- Ensure all connections are **tight and secure** before use.



Image 2.1: Visual warning against using the tent in adverse weather and emphasizing the need for secure setup.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x Tent Canopy and Sidewalls
- 1 x Set of Iron Tube Frame Components
- Ropes and Ground Pegs for Stability
- 1 x User's Manual (this document)

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. It is recommended to have at least two people for assembly.

1. Step 1: Assemble the Top Frame

Begin by connecting the iron tubes to form the top frame structure of the tent. Ensure all connections are secure.

2. Step 2: Cover with Top Tarp Material

Carefully drape the canopy tarp over the assembled top frame.

3. Step 3: Attach Side Panels and Secure

Attach the side panels to the frame. Once the main structure is complete, use the provided ropes and ground pegs to anchor the tent securely to the ground.

EASY TO ASSEMBLE

◀ STEP 1

Assemble the top frame first



STEP 2 ▶

Cover it with the top tarp material



◀ STEP 3

Put it up and attach the side panels

Image 4.1: Visual guide illustrating the three main steps for assembling the party tent.



Image 4.2: Close-up details of key tent components, highlighting material quality and design features for stability and durability.

5. OPERATION AND USAGE

5.1 Space and Capacity

The 10'x30' outdoor canopy tent offers a large space suitable for various outdoor activities. It can accommodate approximately 30-50 people or provide space for 3 tables (85x70 inches) and 35 chairs, making it ideal for:

- Garden weddings
- Outdoor events
- Birthday parties
- Backyard barbecues
- Baby showers



Image 5.1: The 10'x30' tent in use for an outdoor gathering, demonstrating its spaciousness.

5.2 Removable Sidewalls

The tent includes 8 removable sidewalls, two of which feature zippers for easy access. The sidewalls can be easily removed to adjust for different needs, offering:

- Increased shade
- Improved air ventilation
- Enhanced privacy

REMOVABLE SIDEWALLS



Bright

Sidewalls with clear windows provides maximum light and unobstructed viewing



Well-Ventilated

All sidewalls are removable boosts air circulation to keep you cool.




Image 5.2: Illustration of the tent with and without sidewalls, emphasizing their removable nature and impact on ventilation.

5.3 Weather Protection

The canopy is made of polyethylene, providing water and UV resistance. The powder-coated steel framework is rust and corrosion resistant, ensuring sturdiness and stability under normal weather conditions.




Image 5.3: Visual representation of the tent's UV protection and waterproof capabilities.

5.4 Product Video

Your browser does not support the video tag.

Video 5.4: An official product video showcasing the BNSPLY 10'x30' Outdoor Party Tent in various settings and highlighting its features, including stable support design and pervious-to-light side windows.

6. MAINTENANCE

- **Cleaning:** Clean the canopy and sidewalls with mild soap and water. Avoid harsh chemicals that may damage the fabric. Allow all parts to dry completely before storage to prevent mildew.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place, away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect the frame, canopy, ropes, and pegs for any signs of wear, damage, or corrosion.

Replace damaged parts as needed.

7. TROUBLESHOOTING

- **Tent Instability:** Ensure all frame connections are fully engaged. Verify that ropes are taut and ground pegs are firmly secured into the ground. Add additional weights to the legs if necessary, especially in slightly breezy conditions (but avoid strong winds).
- **Water Leakage:** Check the canopy for any tears or punctures. Ensure the canopy is properly stretched and secured over the frame to prevent water pooling.
- **Difficulty Assembling:** Refer to the assembly steps and diagrams. Ensure all numbered parts are correctly matched. It is often easier with two people.
- **Missing Parts:** If any components are missing upon arrival, please contact customer support immediately.

8. SPECIFICATIONS

Feature	Detail
Brand	BNSPLY
Model Size	10'x30'
Material	Iron Tube & PE Cloth
Color	White with 8 Sidewalls
Frame Material	Alloy Steel
Water Resistance Level	Waterproof
Ultraviolet Light Protection	UV Protection
Closure Type	Zipper (on some sidewalls)
Required Assembly	Yes
Included Components	1 x Tent, 1 x User's Manual
ASIN	B0C1FBDSCR
GTIN/UPC	780280430086

9. WARRANTY AND SUPPORT

BNSPLY offers a **12-month warranty** for this product. Additionally, a **30-day return or replacement period** is provided. For any questions, concerns, or support needs, please do not hesitate to contact BNSPLY customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C1FBDSCR>

More documents and user manuals: <https://manuals.plus/>